

Standard ECMA-285  
2nd Edition - June 2000

# ECMA

Standardizing Information and Communication Systems

---

---

## **Protocol for Computer Supported Telecommunications Applications (CSTA) Phase III**

---

---





Standardizing Information and Communication Systems

---

---

**Protocol for Computer Supported  
Telecommunications Applications  
(CSTA) Phase III**

---

---



## Brief History

This Standard defines Phase III of Protocol for Computer Supported Telecommunications Applications (CSTA) for OSI Layer 7 communication between a computing network and a telecommunications network. This Standard is part of a Suite of Standards and Technical Reports for Phase III of CSTA. All of the Standards and Technical Reports in the Suite are based on practical experience of ECMA member companies and each one represents a pragmatic and widely-based consensus.

The evolution of this Suite began with CSTA Phase I, which included only the CSTA Services and Protocol Standards (ECMA-179 and ECMA-180). In Phase II, Technical Report ECMA TR/68 was added illustrating how CSTA services and events may be used in typical call scenarios.

Phase III of CSTA extends the previous Phase II Standards (ECMA-217 and ECMA-218) in major theme directions as well as numerous details. This incorporates technology based upon the *versit* CTI Encyclopedia (Version 1.0), which was contributed to ECMA by *versit*. Major areas of advancement include:

- New categories of services and events such as capabilities exchange, charging, media attach services, call data recording (CDR), etc.
- Additional services and events for call and device control.
- Enhancement to existing services and events.
- Organization of services and events to reflect a grouping based on function (call control, device control, etc.).

This ECMA Standard is technically aligned with the International Standard ISO/IEC 18052 published by ISO/IEC in July 2000.

Adopted as 2nd Edition of Standard ECMA-285 by the General Assembly of June 2000.



## **ASN.1 Tools Acknowledgement**

The ASN.1 specified in this Standard has been checked for conformance with the ASN.1 Standard by the OSS ASN.1 Tools.





## Table of Contents

<b>1</b>	<b>Scope</b>	<b>1</b>
<b>2</b>	<b>Conformance</b>	<b>1</b>
2.1	Static Requirements	1
2.2	Dynamic Requirements	1
2.3	PICS Requirement	1
<b>3</b>	<b>References</b>	<b>1</b>
<b>4</b>	<b>Definitions and Abbreviations</b>	<b>2</b>
<b>5</b>	<b>CSTA Service Definition Model</b>	<b>2</b>
5.1	CSTA Application Layer Structure	2
5.2	Remote Operations	2
5.3	The CSTA Service Response	2
5.4	Cross Referencing of Event Reports	3
5.5	Handling of Private Data	3
<b>6</b>	<b>Interconnection service boundary</b>	<b>3</b>
<b>7</b>	<b>Security</b>	<b>3</b>
<b>8</b>	<b>Association Management</b>	<b>3</b>
8.1	Implicit association	3
8.2	Dynamic association management using ACSE	3
8.2.1	Encoding of application context name	4
8.2.2	Encoding of application context information	4
<b>9</b>	<b>CSTA parameter types</b>	<b>8</b>
9.1	Switching function objects	8
9.2	Device Identifiers	9
9.3	Call and connection identifiers	11
9.4	Connection states	12
9.5	Status reporting	13
9.6	Device and feature types and other parameters	15
9.7	Security	20
9.8	Common extensions	21
9.9	Call control	22
9.10	Capability Exchange	24
9.11	Call Detail Record	73
9.12	Charge information	75

9.13	Data call types	76
9.14	Escape types	77
9.15	Media services	78
9.16	Physical device features	80
9.17	Data Collection	82
9.18	Event Cause	83
9.19	Error Value	85
<b>10</b>	<b>Event Report Service</b>	<b>90</b>
<b>11</b>	<b>Capability exchange services</b>	<b>95</b>
11.1	Services	95
11.1.1	Get logical device information	95
11.1.2	Get physical device information	97
11.1.3	Get switching function capabilities	98
11.1.4	Get switching function devices	101
11.1.5	Switching function devices	102
<b>12</b>	<b>System services</b>	<b>103</b>
12.1	Registration services	103
12.1.1	Change system status filter	103
12.1.2	System register	104
12.1.3	System register abort	105
12.1.4	System register cancel	106
12.2	Services	107
12.2.1	Request system status	107
12.2.2	System status	108
12.2.3	Switching function capabilities changed	109
12.2.4	Switching function devices changed	110
<b>13</b>	<b>Monitoring services</b>	<b>111</b>
13.1	Services	111
13.1.1	Change monitor filter	111
13.1.2	Monitor start	112
13.1.3	Monitor stop	113
<b>14</b>	<b>Snapshot services</b>	<b>114</b>
14.1	Services	114
14.1.1	Snapshot call	114
14.1.2	Snapshot device	116
14.1.3	Snapshot calldata	117
14.1.4	Snapshot devicedata	118

<b>15</b>	<b>Call control services and events</b>	<b>119</b>
15.1	Services	119
15.1.1	Accept call	119
15.1.2	Alternate call	120
15.1.3	Answer call	121
15.1.4	Call back call-related	122
15.1.5	Call back message call-related	123
15.1.6	Camp on call	124
15.1.7	Clear call	125
15.1.8	Clear Connection	126
15.1.9	Conference call	127
15.1.10	Consultation call	128
15.1.11	Deflect call	129
15.1.12	Dial digits	130
15.1.13	Directed pickup call	131
15.1.14	Group pickup call	132
15.1.15	Hold call	133
15.1.16	Intrude call	134
15.1.17	Join call	135
15.1.18	Make call	136
15.1.19	Make predictive call	137
15.1.20	Park call	139
15.1.21	Reconnect call	140
15.1.22	Retrieve call	141
15.1.23	Single step conference call	142
15.1.24	Single step transfer call	143
15.1.25	Transfer call	144
15.2	Events	145
15.2.1	Bridged	145
15.2.2	Call cleared	146
15.2.3	Conferenced	147
15.2.4	Connection cleared	148
15.2.5	Delivered	149
15.2.6	Digits dialed	150
15.2.7	Diverted	151
15.2.8	Established	152
15.2.9	Failed	153
15.2.10	Held	154
15.2.11	Network capabilities changed	155
15.2.12	Network reached	156
15.2.13	Offered	157
15.2.14	Originated	158
15.2.15	Queued	159
15.2.16	Retrieved	160
15.2.17	Service initiated	161

15.2.18	Transferred	162
<b>16</b>	<b>Call associated features</b>	<b>163</b>
16.1	Services	163
16.1.1	Associate data	163
16.1.2	Cancel telephony tones	164
16.1.3	Generate digits	165
16.1.4	Generate telephony tones	166
16.1.5	Send user information	167
16.2	Events	168
16.2.1	Call information	168
16.2.2	Charging	169
16.2.3	Digits generated	170
16.2.4	Telephony tones generated	171
16.2.5	Service completion failure	172
<b>17</b>	<b>Media attachment services and events</b>	<b>173</b>
17.1	Services	173
17.1.1	Attach media service	173
17.1.2	Detach media service	174
17.2	Events	175
17.2.1	Media attached	175
17.2.2	Media detached	176
<b>18</b>	<b>Routeing services</b>	<b>177</b>
18.1	Registration services	177
18.1.1	Route register	177
18.1.2	Route register abort	178
18.1.3	Route register cancel	179
18.2	Services	180
18.2.1	Re-Route	180
18.2.2	Route end	181
18.2.3	Route reject	182
18.2.4	Route request	183
18.2.5	Route select	184
18.2.6	Route used	185
<b>19</b>	<b>Physical device features</b>	<b>186</b>
19.1	Services	186
19.1.1	Button press	186
19.1.2	Get auditory apparatus information	187
19.1.3	Get button information	188
19.1.4	Get display	189
19.1.5	Get hookswitch status	190
19.1.6	Get lamp information	191

19.1.7	Get lamp mode	192
19.1.8	Get message waiting indicator	193
19.1.9	Get microphone gain	194
19.1.10	Get microphone mute	195
19.1.11	Get ringer status	196
19.1.12	Get speaker mute	197
19.1.13	Get speaker volume	198
19.1.14	Set button information	199
19.1.15	Set display	200
19.1.16	Set hookswitch status	201
19.1.17	Set lamp mode	202
19.1.18	Set message waiting indicator	203
19.1.19	Set microphone gain	204
19.1.20	Set microphone mute	205
19.1.21	Set ringer status	206
19.1.22	Set speaker mute	207
19.1.23	Set speaker volume	208
19.2	Events	209
19.2.1	Button information	209
19.2.2	Button press	210
19.2.3	Display updated	211
19.2.4	Hookswitch	212
19.2.5	Lamp mode	213
19.2.6	Message waiting	214
19.2.7	Microphone gain	215
19.2.8	Microphone mute	216
19.2.9	Ringer status	217
19.2.10	Speaker mute	218
19.2.11	Speaker volume	219
<b>20</b>	<b>Logical device features</b>	<b>220</b>
20.1	Services	220
20.1.1	Call back non-call-related	220
20.1.2	Call back message non-call-related	221
20.1.3	Cancel call back	222
20.1.4	Cancel call back message	223
20.1.5	Get agent state	224
20.1.6	Get auto answer	225
20.1.7	Get auto work mode	226
20.1.8	Get caller id status	227
20.1.9	Get do not disturb	228
20.1.10	Get forwarding	229
20.1.11	Get last number dialed	230
20.1.12	Get routeing mode	231
20.1.13	Set agent state	232

20.1.14	Set auto answer	233
20.1.15	Set auto work mode	234
20.1.16	Set caller id status	235
20.1.17	Set do not disturb	236
20.1.18	Set forwarding	237
20.1.19	Set routeing mode	238
20.2	Events	239
20.2.1	Agent busy	239
20.2.2	Agent logged off	240
20.2.3	Agent logged on	241
20.2.4	Agent not ready	242
20.2.5	Agent ready	243
20.2.6	Agent working after call	244
20.2.7	Auto answer	245
20.2.8	Auto work mode	246
20.2.9	Call back	247
20.2.10	Call back message	248
20.2.11	Caller id status	249
20.2.12	Do not disturb	250
20.2.13	Forwarding	251
20.2.14	Routeing mode	252
<b>21</b>	<b>Device maintenance events</b>	<b>253</b>
21.1	Events	253
21.1.1	Back in service	253
21.1.2	Device capabilities changed	254
21.1.3	Out of service	255
<b>22</b>	<b>I/O services</b>	<b>256</b>
22.1	Registration services	256
22.1.1	I/O register	256
22.1.2	I/O register abort	257
22.1.3	I/O register cancel	258
22.2	Services	259
22.2.1	Data path resumed	259
22.2.2	Data path suspended	260
22.2.3	Fast data	261
22.2.4	Resume data path	262
22.2.5	Send broadcast data	263
22.2.6	Send data	264
22.2.7	Send multicast data	265
22.2.8	Start data path	266
22.2.9	Stop data path	267
22.2.10	Suspend data path	268

<b>23</b>	<b>Data Collection Services</b>	<b>269</b>
23.1	Services	269
23.1.1	Data Collected	269
23.1.2	Data Collection Resumed	271
23.1.3	Data Collection Suspended	272
23.1.4	Resume Data Collection	273
23.1.5	Start Data Collection	274
23.1.6	Stop Data Collection	275
23.1.7	Suspend Data Collection	276
<b>24</b>	<b>Voice unit services and events</b>	<b>277</b>
24.1	Services	277
24.1.1	Concatenate message	277
24.1.2	Delete message	278
24.1.3	Play message	279
24.1.4	Query voice attribute	280
24.1.5	Record message	281
24.1.6	Reposition	282
24.1.7	Resume	283
24.1.8	Review	284
24.1.9	Set voice attribute	285
24.1.10	Stop	286
24.1.11	Suspend	287
24.1.12	Synthesize message	288
24.2	Events	289
24.2.1	Play	289
24.2.2	Record	290
24.2.3	Review	291
24.2.4	Stop	292
24.2.5	Suspend play	293
24.2.6	Suspend record	294
24.2.7	Voice attribute changed	295
<b>25</b>	<b>Call detail record services</b>	<b>296</b>
25.1	Services	296
25.1.1	Call detail records notification	296
25.1.2	Call detail records report	297
25.1.3	Send stored call detail records	298
25.1.4	Start call detail records transmission	299
25.1.5	Stop call detail records transmission	300
<b>26</b>	<b>Vendor specific extensions services and events</b>	<b>301</b>
26.1	Registration services	301
26.1.1	Escape register	301
26.1.2	Escape register abort	302

26.1.3	Escape register cancel	303
26.2	Services	304
26.2.1	Escape	304
26.2.2	Private data version selection	305
26.3	Events	306
26.3.1	Private event	306
<b>Annex A - Protocol Implementation Conformance Statement (PICS) Proforma</b>		<b>307</b>
A.1	Introduction	307
A.2	Conformance	307
A.3	Instructions for completing the PICS proforma	307
A.4	Implementation identification	308
A.5	PICS proforma	308



## 1 Scope

This Standard specifies application protocol data units (APDUs) for the services described in ECMA-269, Services for Computer Supported Telecommunications Applications (CSTA) Phase III.

Clause 5 to clause 7 inclusive describes the concepts underlying the Remote Operations model, notation and service.

Clause 8 to clause 26 inclusive contains CSTA-specific protocol details and forms the main part of this Standard.

The protocol in this Standard operates in the context of an application association.

## 2 Conformance

A manufacturer may select any part of the CSTA protocol, as specified in this Standard, for implementation on a system as long as it satisfies the minimum conformance requirements as specified in clause 2 of ECMA-269.

A Protocol Implementation Conformance Statement (PICS) shall be used to specify the operations which are provided by a particular implementation. A PICS shall also specify the parameter options which are used.

### 2.1 Static Requirements

To conform to this Standard, a system shall support the transfer syntax (derived from the encoding rules specified in ITU-T X.690) named {joint-iso-ccitt asn1(1) basic-encoding(1)}; for the purpose of generating and interpreting CSTA protocol information as defined by the abstract syntax “CSTA-ASN.1-Object-Descriptor” for the operations supported.

### 2.2 Dynamic Requirements

To conform to this Standard, a system shall:

- a. follow the procedures as specified in this Standard, and ECMA-269, relevant to each CSTA operation that the system claims to implement; and
- b. satisfy the definitions, as specified in ECMA-269, relevant to each CSTA service that the system claims to implement.

### 2.3 PICS Requirement

To conform to this Standard, the following shall be stated by the implementer when defining a PICS corresponding to an application or implementation:

- a. which CSTA operations, as defined in ECMA-269, are supported by the system for the particular implementation; and
- b. which optional parameters are supported by the PDUs belonging to the supported operations.

A PICS proforma is given in Annex A of this Standard.

## 3 References

<b>ECMA-269</b>	Services for Computer Supported Telecommunications Applications (CSTA) Phase III, 4th edition (June 2000)
<b>ECMA TR/72</b>	Glossary of definitions and terminology for Computer Supported Telecommunications Applications (CSTA) Phase III, 3rd edition (June 2000)
<b>ISO/IEC 8649:1996</b>	Information technology - Open Systems Interconnection - Service definition for the Association Control Service Element (this corresponds to ITU-T Rec. X.217 1995)
<b>ISO/IEC 8650-1:1996</b>	Information technology - Open Systems Interconnection - Connection-oriented protocol for the Association Control Service Element: Protocol specification (this corresponds to ITU-T Rec. X.227 4/95)
<b>ISO/IEC 9545:1994</b>	Information technology - Open Systems Interconnection - Application Layer structure
<b>ISO/IEC 13712-1:1995</b>	Information technology - Remote Operations: Concepts, model, and notation (this corresponds to ITU-T Rec. X.880, 1994)

<b>ISO/IEC 13712-2:1994</b>	Information technology - Remote Operations: OSI realisations - Remote Operations Service Element (ROSE) <i>service definition</i> (this corresponds to ITU-T Rec. X.881, 1994)
<b>ISO/IEC 13712-3:1994</b>	Information technology - Remote Operations: OSI realisations - Remote Operations Service Element (ROSE) protocol specification (this corresponds to ITU-T Rec. X.882, 1994)
<b>ITU-T X.680</b>	Information technology - Abstract Syntax Notation One (ASN.1): Specification of basic notation
<b>ITU-T X.690</b>	Information technology - ASN.1 encoding rules - Specification of Basic Encoding Rules (BER), Canonical Encoding Rules (CER) and Distinguished Encoding Rules (DER)

## 4 Definitions and Abbreviations

CSTA-specific terminology is defined in ECMA TR/72. For the purposes of this Standard, the following additional definitions, defined in other standards, shall apply:

- Remote Operations (as per ISO/IEC 13712-1)
- Application Association (as per ISO/IEC 8649)
- Application Context (as per ISO/IEC 8649)

## 5 CSTA Service Definition Model

### 5.1 CSTA Application Layer Structure

The CSTA Application Layer structure conforms to the model described in ISO/IEC 9545.

### 5.2 Remote Operations

The services of CSTA are modeled as Remote Operations as described in ISO/IEC 13712-1. Typically, one entity requests that a particular operation be performed; the other entity attempts to perform the operation and responds to the requestor. Consequently the operation of the protocol is an elementary request/reply interaction, supported within the OSI Application Layer, and carried out within the context of an application association.

For some of the CSTA services, the entity to which the request is sent generates a reply which can indicate success or failure. For these services, CSTA shall adopt the operations Class 2, defined in ISO/IEC 13712-2 as:

- Asynchronous, reporting success or failure (result or error).

For some of the CSTA services, the entity to which the request is sent generates a reply which can only indicate failure. For these services, CSTA shall adopt the operations Class 3, defined in ISO/IEC 13712-2 as:

- Asynchronous, reporting failure (error) only, if any.

For some of the CSTA services, particularly the ongoing reporting of events, no reply is generated. For these services, CSTA shall adopt the operations Class 5, defined in ISO/IEC 13712-2 as:

- Asynchronous, outcome not reported.

The protocol description for the particular service defines the relevant class of the operation used for that service.

CSTA shall correlate the single response, denoting success or failure, with the originating request by using the mechanisms within the ROSE protocol.

### 5.3 The CSTA Service Response

CSTA employs a generic response mechanism which is, in principle, decoupled from the specifics of the switching activity. The following points describe the operation of the CSTA service response:

- a. Specific services may have an unconfirmed mode where responses to correct requests are not returned.

- b. The server shall check the correctness of the request (e.g. syntactical checks) before issuing the response. Incorrect requests shall result in an error response, even in the unconfirmed mode.

#### **5.4 Cross Referencing of Event Reports**

A computer application process may need to cross reference a CSTAEventReport to one of the following:

- a. a CSTA Object ID (Call ID or Device ID),
- b. an earlier Monitor request; or
- c. one of many Monitor requests (pertaining to the same CSTA Object).

For the above scenarios the necessary cross referencing function may be fulfilled by use of the parameter "MonitorCrossRefID". The content of MonitorCrossRefID depends upon the context and it may be one of the following: Call ID, Device ID or another independently switch managed static identifier. The independent identifier may have a unique correlation to either: one device, one call, or one monitor request.

The switching system limit on the number of monitor requests on one CSTA Object (Call or Device) is an implementation option. This Standard does not stipulate how many monitor requests on one object are to be supported by the switch. If using Static Device or Call identifiers the limit can only be one.

#### **5.5 Handling of Private Data**

If an entity receives the parameter CSTAPrivateData, and it can not recognize the information contained, the parameter shall be discarded, and the rest of the message shall be processed.

### **6 Interconnection service boundary**

The protocol in this Standard is an OSI Application Layer protocol and uses the Remote Operations protocol defined in ISO/IEC 13712-3. The Remote Operations protocol assumes certain services are provided by the underlying layers, and these services are also assumed by the protocol for CSTA.

### **7 Security**

This protocol also provides a mechanism for secure transmission of CSTA PDUs as defined in this Standard.

### **8 Association Management**

The protocol in this Standard operates in the context of an application association. This application association can be either:

- an implicit association achieved via off-line agreement; or
- a dynamically negotiated association realized through the use of ACSE.

#### **8.1 Implicit association**

An a-priori agreement exists between switching and computing functions: the application context is implicit, dynamic negotiation is not possible.

#### **8.2 Dynamic association management using ACSE**

ACSE requires the use of an application context Name (as defined by ISO 8649). This is an object id that uniquely identifies CSTA independently of the different versions of the protocol.

The CSTA protocol version information is carried within the User Information field of the A-ASSOCIATE request and response PDUs.

An application context is established (using ACSE) as follows:

- the system generating the A-ASSOCIATE request includes the CSTA application context name and a list of all protocol versions that it is prepared to offer in the User Information field;
- on receipt of the A-ASSOCIATE request, the receiving system selects the protocol version to be used by identifying the highest version that is common to both systems;

- the protocol version selected is conveyed to the requestor in the User Information field of the A-ASSOCIATE response.

In addition to negotiating the protocol version, it is necessary for the requesting and responding systems to specify the CSTA services that they support. As with the protocol version information, this is also achieved by carrying additional information in the User Information field of the A-ASSOCIATE request and response PDUs. The application association requestor shall:

- list the services required from the serving application;
- list the services it can supply.

The responder shall include similar information for the responding application. At this point the association requestor will either accept or reject the association.

### 8.2.1 Encoding of application context name

```
CSTA-application-context-name
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta( 218) }
-- Common to all CSTA protocol versions
```

### 8.2.2 Encoding of application context information

```
CSTA-application-context-information-csta3
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) application-context-information( 200) }
```

```
DEFINITIONS ::=
BEGIN
```

```
IMPORTS
```

```
CSTAFunctionality FROM CSTA-application-context-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta2( 218) application-context-information( 200) };
```

```
ACSEUserInformationForCSTA ::= CHOICE
{   oldDefinition          OldACSEUserInformationForCSTA,
    newDefinition [0] IMPLICIT NewACSEUserInformationForCSTA }
```

```
OldACSEUserInformationForCSTA ::= SEQUENCE
{   cSTAVersion          CSTAVersion,
    cSTAFunctionsRequiredByApplication  CSTAFunctionality,
    cSTAFunctionsThatCanBeSupplied      CSTAFunctionality }
```

```
NewACSEUserInformationForCSTA ::= SEQUENCE
{   cSTAVersion          CSTAVersion,
  --
  --Note that the following two parameters are defined in ECMA-218 (CSTA Phase II).
  --They are defined in the context of CSTA Phase II Services and Events for
  --backward compatibility considerations.
  --For CSTA Phase III (and later), implementations should use CSTA Capability Exchange Services
  --to determine the Services and Events supported by a switching function.
  --
```

```
    cSTAFunctionsRequiredByApplication [0] IMPLICIT CSTAFunctionality OPTIONAL,
    cSTAFunctionsThatCanBeSupplied      [1] IMPLICIT CSTAFunctionality OPTIONAL,
    cSTAPrivateDataVersionList          [2] IMPLICIT CSTAPrivateDataVersionList OPTIONAL }
```

```
CSTAPrivateDataVersionList ::= SEQUENCE OF INTEGER
```

```
CSTAVersion ::= BIT STRING
{   versionOne          (0), -- CSTA protocol version defined in ECMA-180
    versionTwo          (1), -- CSTA protocol version defined in ECMA-218
    versionThree        (2), -- CSTA protocol version defined in ECMA-285, 1st Edition
    versionFour         (3), -- CSTA protocol version defined in ISO/IEC 18052
    versionFive         (4), -- CSTA protocol version defined in ECMA-285, 2nd Edition
    versionSix          (5), -- Reserved for future use
    versionSeven        (6), -- Reserved for future use
    versionEight        (7), -- Reserved for future use }
```

```
versionNine          (8), -- Reserved for future use
versionTen           (9), -- Reserved for future use
versionEleven        (10), -- Reserved for future use
versionTwelve        (11), -- Reserved for future use
versionThirteen      (12), -- Reserved for future use
versionFourteen      (13), -- Reserved for future use
versionFifteen       (14), -- Reserved for future use
versionSixteen       (15)} -- Reserved for future use

CallControlServices ::= BIT STRING
{
    acceptCall          (0),
    alternateCall       (1),
    answerCall          (2),
    callBack            (3),
    callBackMessage     (4),
    campOnCall          (5),
    clearCall           (6),
    clearConnection     (7),
    conferenceCall      (8),
    consultationCall    (9),
    deflectCall         (10),
    dialDigits          (11),
    directedPickupCall  (12),
    groupPickupCall     (13),
    holdCall            (14),
    intrudeCall         (15),
    joinCall            (16),
    makeCall            (17),
    makePredictiveCall  (18),
    parkCall           (19),
    reconnectCall       (20),
    retrieveCall        (21),
    singleStepConference (22),
    singleStepTransfer  (23),
    transferCall        (24)}

CallAssociatedServices ::= BIT STRING
{
    associateData        (0),
    cancelTelephonyTones (1),
    generateDigits       (2),
    generateTelephonyTones (3),
    sendUserInformation  (4)}

MediaAttachmentServices ::= BIT STRING
{
    attachMediaService   (0),
    detachMediaService   (1)}

RouteingServices ::= BIT STRING
{
    routeRegister        ( 0),
    routeRegisterCancel  ( 1),
    routeRegisterAbort   ( 2),
    reRoute              ( 3),
    routeEnd             ( 4),
    routeReject          ( 5),
    routeRequest         ( 6),
    routeSelect          ( 7),
    routeUsed            ( 8)}

VoiceUnitServices ::= BIT STRING
{
    concatenateMessage   (0),
    deleteMessage       (1),
    playMessage          (2),
    queryVoiceAttribute  (3),
    recordMessage        (4),
    reposition           (5),
    resume               (6),
    review               (7),
```

```
        setVoiceAttribute      (8),
        stop                   (9),
        suspend                 (10),
        synthesiseMessage      (11)}

CallControlEvents ::= BIT STRING
{bridged                      (15),
 callCleared                  (0),
 conferenced                  (1),
 connectionCleared            (2),
 delivered                    (3),
 digitsDialed                  (14),
 diverted                     (4),
 established                   (5),
 failed                       (6),
 held                         (7),
 networkCapabilitiesChanged    (16),
 networkReached                (8),
 offered                      (17),
 originated                   (9),
 queued                       (10),
 retrieved                    (11),
 serviceInitiated              (12),
 transferred                   (13) }

CallAssociatedEvents ::= BIT STRING
{    callInformation           (0),
    charging                   (1),
    dTMFDigitsDetected         (2),
    telephonyTonesDetected     (3),
    serviceCompletionFailure    (4)}

MediaAttachmentEvents ::= BIT STRING
{    mediaAttached (0),
    mediaDetached (1)}

PhysicalDeviceFeatureEvents ::= BIT STRING
{buttonInformation (0),
 buttonPress       (1),
 displayUpdated    (2),
 hookswitch        (3),
 lampMode          (4),
 messageWaiting    (5),
 microphoneGain     (6),
 microphoneMute     (7),
 ringerStatus       (8),
 speakerMute        (9),
 speakerVolume      (10)}

LogicalDeviceFeatureEvents ::= BIT STRING
{    agentBusy           ( 0),
    agentLoggedOn        ( 1),
    agentLoggedOff       ( 2),
    agentNotReady        ( 3),
    agentReady           ( 4),
    agentWorkingAfterCall ( 5),
    autoAnswer           ( 6),
    autoWorkMode         ( 7),
    callBack             ( 8),
    callBackMessage      ( 9),
    callerIDStatus       (10),
    doNotDisturb         (11),
    forwarding           (12),
    routeingMode         (13)}

DeviceMaintenanceEvents ::= BIT STRING
{    backInService       (0),
    deviceCapabilityChanged (2),
```

```
        outOfService                (1)          }

VoiceUnitEvents ::= BIT STRING
    {
        play                (1),
        record              (3),
        review              (5),
        stop                (0),
        suspendPlay         (2),
        suspendRecord       (4),
        voiceAttributesChange (6)          }

VendorSpecEvents ::= BIT STRING
    {
        privateEvent        (0)}

END -- of CSTA-application-context-information
```

## 9 CSTA parameter types

The major parameters have been assigned distinct application tags to facilitate parsing. The data is defined in logical groups in ascending order of application tag. Application tags used are:

- APPLICATION 1 - 8: . . . . . Device identifiers
- APPLICATION 11 - 14: . . . . Connection identifiers and local connection states
- APPLICATION 21 - 24: . . . Status reporting
- APPLICATION 29 - 30: . . . CSTACommonArguments

### 9.1 Switching function objects

```
CSTA-switching-function-objects
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) switching-function-objects( 122) }
DEFINITIONS ::=
BEGIN

EXPORTS
CSTAObject;

IMPORTS
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) };

CSTAObject ::= CHOICE
    {deviceObject    DeviceID,
     callObject      ConnectionID}

END -- of CSTA-switching-function-objects
```



## 9.2 Device Identifiers

```
CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }

DEFINITIONS ::=
BEGIN

EXPORTS
DeviceID, NumberDigits, CallingDeviceID, CalledDeviceID,
SubjectDeviceID, RedirectionDeviceID, AssociatedCallingDeviceID,
AssociatedCalledDeviceID, NetworkCallingDeviceID, NetworkCalledDeviceID;

IMPORTS
MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

CallingDeviceID ::= [APPLICATION 1] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT      NULL}

CalledDeviceID ::= [APPLICATION 2] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT      NULL}

SubjectDeviceID ::= [APPLICATION 3] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT      NULL}

RedirectionDeviceID ::= [APPLICATION 4] CHOICE
{numberdialed          DeviceID,
 notKnown              [7] IMPLICIT      NULL,
 notRequired           [8] IMPLICIT      NULL,
 notSpecified          [9] IMPLICIT      NULL}

AssociatedCallingDeviceID ::= [APPLICATION 5] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT      NULL}

AssociatedCalledDeviceID ::= [APPLICATION 6] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT      NULL}

NetworkCallingDeviceID ::= [APPLICATION 7] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT      NULL}

NetworkCalledDeviceID ::= [APPLICATION 8] CHOICE
{deviceIdentifier      DeviceID,
 notKnown              [7] IMPLICIT      NULL}

DeviceID ::= SEQUENCE
{
  deviceIdentifier      CHOICE
  {
    dialingNumber       [0] IMPLICIT      NumberDigits,
    deviceNumber         [1] IMPLICIT      DeviceNumber,
    implicitPublic       [2] IMPLICIT      NumberDigits,
    explicitPublic       [3] IMPLICIT      PublicTON,
    implicitPrivate      [4] IMPLICIT      NumberDigits,
    explicitPrivate      [5] IMPLICIT      PrivateTON,
    other                [6] IMPLICIT      OtherPlan},
  mediaCallCharacteristics MediaCallCharacteristics OPTIONAL}

PublicTON ::= CHOICE
{
  unknown              [0] IMPLICIT      IA5String,
  international        [1] IMPLICIT      IA5String,
  national              [2] IMPLICIT      IA5String,
```

```

        networkspecific      [3] IMPLICIT      IA5String,
        subscriber           [4] IMPLICIT      IA5String,
        abbreviated          [5] IMPLICIT      IA5String  }

PrivateTON ::= CHOICE
{
        unknown              [0] IMPLICIT      IA5String,
        level3RegionalNumber [1] IMPLICIT      IA5String,
        level2RegionalNumber [2] IMPLICIT      IA5String,
        level1RegionalNumber [3] IMPLICIT      IA5String,
        pTNSpecificNumber    [4] IMPLICIT      IA5String,
        localNumber          [5] IMPLICIT      IA5String,
        abbreviated          [6] IMPLICIT      IA5String  }

OtherPlan ::= OCTET STRING      -- Allows future expansion to cover other numbering
                                -- plans

NumberDigits ::= IA5String

DeviceNumber ::= INTEGER

END  -- of CSTA-device-identifiers
```

### 9.3 Call and connection identifiers

```
CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }

DEFINITIONS ::=
BEGIN

EXPORTS
CallID, ConnectionID;

IMPORTS
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) };

ConnectionID ::= [APPLICATION 11] CHOICE
{
  callID      [0] IMPLICIT      CallID,
  deviceID    [1]                LocalDeviceID,
  both        SEQUENCE
  {
    callID      [0] IMPLICIT      CallID,
    deviceID    [1]                LocalDeviceID
  }
}

CallID ::= OCTET STRING (SIZE(0..8))

LocalDeviceID ::= CHOICE
{
  staticID      DeviceID,
  dynamicID     [3] IMPLICIT      OCTET STRING (SIZE(0..32)) }

END -- of CSTA-call-connection-identifiers
```

## 9.4 Connection states

```
CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }

DEFINITIONS ::=
BEGIN

EXPORTS
ConnectionList, LocalConnectionState;

IMPORTS
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

ConnectionList ::= SEQUENCE OF SEQUENCE
{
  newConnection [0] ConnectionID      OPTIONAL,
  oldConnection [1] ConnectionID      OPTIONAL,
  endpoint [2] CHOICE
  {
    deviceID      DeviceID,
    notKnown      NULL}      OPTIONAL,
  associatedNID [3] CHOICE
  {
    deviceID      DeviceID,
    notKnown      NULL}      OPTIONAL,
  resultingConnectionInfo ConnectionInformation OPTIONAL}

LocalConnectionState ::= [APPLICATION 14] IMPLICIT ENUMERATED
{
  null          (0),
  initiated     (1),
  alerting      (2),
  connected     (3),
  hold          (4),
  queued        (5),
  fail          (6)}

END -- CSTA-connection-states
```

## 9.5 Status reporting

```
CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }

DEFINITIONS ::=
BEGIN

EXPORTS
MonitorObject, MonitorCrossRefID, MonitorFilter, MonitorType,
MonitorMediaClass, SnapshotCallData, SnapshotDeviceData;

IMPORTS
CallControlEvents, CallAssociatedEvents, MediaAttachmentEvents,
PhysicalDeviceFeatureEvents, LogicalDeviceFeatureEvents,
DeviceMaintenanceEvents, VoiceUnitEvents, VendorSpecEvents
FROM CSTA-application-context-information-csta3
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) application-context-information( 200) }
ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control(130) }
CSTAObject FROM CSTA-switching-function-objects
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) switching-function-objects( 122) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
ConnectionInformation, MediaCallCharacteristics, MediaServiceType,
MediaServiceInstanceID, MediaStreamID FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) }
;

MonitorObject ::= CSTAObject;

MonitorCrossRefID ::= [APPLICATION 21] IMPLICIT OCTET STRING (SIZE(0..4))

MonitorFilter ::= SEQUENCE-- default is no filter (i.e. all events)
{ callControl          [0] IMPLICIT CallControlEvents          DEFAULT {},
  callAssociated        [6] IMPLICIT CallAssociatedEvents        DEFAULT {},
  mediaAttachment       [7] IMPLICIT MediaAttachmentEvents       DEFAULT {},
  physicalDeviceFeature [8] IMPLICIT PhysicalDeviceFeatureEvents DEFAULT {},
  logicalDeviceFeature  [9] IMPLICIT LogicalDeviceFeatureEvents  DEFAULT {},
  maintenance           [3] IMPLICIT DeviceMaintenanceEvents     DEFAULT {},
  voiceUnit             [5] IMPLICIT VoiceUnitEvents             DEFAULT {},
  private               [4] IMPLICIT VendorSpecEvents            DEFAULT {} }

-- setting the relevant bit requests the filter for the appropriate events

MonitorType ::= ENUMERATED
{
  call          (0),
  device        (1)
}

MonitorMediaClass ::= BIT STRING
{
  voice          (0),
  data           (1),
  image          (2),
  audio          (4),
  other          (3) }
```

SnapshotDeviceData ::= [APPLICATION 22] IMPLICIT SEQUENCE OF SnapshotDeviceResponseInfo

```
SnapshotDeviceResponseInfo ::= SEQUENCE
{
    connectionIdentifier      ConnectionID,
    localCallState            CallState,
    servicesPermitted          [0] IMPLICIT ServicesPermitted      OPTIONAL,
    mediaServiceInfoList      [1] IMPLICIT DeviceMediaInfoList      OPTIONAL,
    mediaCallCharacteristics   [2] IMPLICIT MediaCallCharacteristics OPTIONAL}

```

```
DeviceMediaInfoList ::= SEQUENCE OF SEQUENCE
{
    mediaStreamID      MediaStreamID      OPTIONAL,
    connectionInformation ConnectionInformation OPTIONAL}

```

SnapshotCallData ::= [APPLICATION 23] IMPLICIT SEQUENCE OF SnapshotCallResponseInfo

```
SnapshotCallResponseInfo ::= SEQUENCE
{
    deviceOnCall      SubjectDeviceID,
    callIdentifier     ConnectionID      OPTIONAL,
    localConnectionState LocalConnectionState OPTIONAL,
    servicesPermitted  [0] IMPLICIT ServicesPermitted      OPTIONAL,
    mediaServiceInfoList [1] IMPLICIT CallMediaInfoList      OPTIONAL
}

```

```
CallMediaInfoList ::= SEQUENCE OF SEQUENCE
{
    mediaServiceType      [0] IMPLICIT MediaServiceType,
    mediaServiceVersion    [1] IMPLICIT INTEGER          OPTIONAL,
    mediaServiceInstance   [2] IMPLICIT MediaServiceInstanceID OPTIONAL,
    mediaStreamID          [3] IMPLICIT MediaStreamID      OPTIONAL,
    connectionInformation   [4] IMPLICIT ConnectionInformation OPTIONAL}

```

```
CallState ::= CHOICE
{
    compoundCallState      [0] IMPLICIT CompoundCallState,
    simpleCallState        [1] IMPLICIT SimpleCallState,
    unknown                 [2] IMPLICIT NULL}

```

CompoundCallState ::= SEQUENCE OF LocalConnectionState

```
SimpleCallState ::= ENUMERATED
{
    callNull          (0),      -- '00'H - null-null
    callPending       (1),      -- '01'H - null-initiate
    callOriginated    (3),      -- '03'H - null-connect
    callDelivered     (35),     -- '23'H - alerting-connect
    callDeliveredHeld (36),     -- '24'H - alerting-held
    callReceived      (50),     -- '32'H - connect-alerting
    callEstablished   (51),     -- '33'H - connect-connect
    callEstablishedHeld (52),   -- '34'H - connected-held
    callReceivedOnHold (66),    -- '42'H - held-alerting
    callEstablishedOnHold (67), -- '43'H - held-connect
    callQueued        (83),     -- '53'H - queued-connect
    callQueuedHeld    (84),     -- '54'H - queued-held
    callFailed        (99),     -- '63'H - failed-connect
    callFailedHeld    (100),    -- '64'H - failed-held
    callBlocked       (96)}     -- '60'H - failed-null

```

-- This represents the main call states in a simplified encoding. The semantics  
-- are identical to the sequence of connection states but they are represented by  
-- an item from an enumerated list.

END -- of CSTA-status-reporting

## 9.6 Device and feature types and other parameters

```
CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }

DEFINITIONS ::=
BEGIN

EXPORTS
AccountInfo, AgentID, AgentPassword, AgentState, AuthCode, CallOrigination, CorrelatorData,
DataPathType, DisplayAttributeList, ForwardList, IOCrossRefID, IORegisterReqID,
MessageID, ParticipationType, PendingAgentState, RetryValue, RouteRegisterReqID,
RouteingCrossRefID, SelectValue, SysStatRegisterID, SystemStatus, TerminatingConditions,
ForwardingType, ForwardDefault, AttributeInfo,
EncodingAlgorithm, ControlData, UserData, TelephonyTone;

IMPORTS
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) };

AccountInfo ::= OCTET STRING (SIZE(0..32))

AgentID ::= OCTET STRING (SIZE(0..32))

AgentPassword ::= OCTET STRING (SIZE(0..32))

AgentState ::= ENUMERATED
{
    agentNotReady      (0),
    agentNull          (1),
    agentReady         (2),
    agentBusy          (3),
    agentWorkingAfterCall (4)}

AuthCode ::= OCTET STRING (SIZE(0..32))

CorrelatorData ::= OCTET STRING (SIZE(0..32))

IOCrossRefID ::= CHOICE
{
    switchProvided      [0] OCTET STRING (SIZE(0..4)),
    computerProvided    [1] OCTET STRING (SIZE(0..4))}

IORegisterReqID ::= OCTET STRING (SIZE(0..4))

MessageID ::= OCTET STRING

ParticipationType ::= ENUMERATED
{
    silent      (0),
    active     (1) }

RouteRegisterReqID ::= OCTET STRING (SIZE(0..4))

RouteingCrossRefID ::= [APPLICATION 24] IMPLICIT OCTET STRING (SIZE(0..4))

SelectValue ::= ENUMERATED
{
    normal      (0),
    leastCost   (1),
    emergency   (2),
    aCD         (3),
    userDefined (4) }

RetryValue ::= CHOICE-- used in RouteSelect Request service
{
    noListAvailable      [0] IMPLICIT BOOLEAN,
    noCountAvailable     [1] IMPLICIT BOOLEAN,
    retryCount           [2] IMPLICIT INTEGER }
```

```
SysStatRegisterID ::= OCTET STRING (SIZE(0..4))

SystemStatus ::= ENUMERATED
{
    disabled                (4),
    partiallyDisabled       (8),
    enabled                 (1),
    initializing            (0),
    messagesLost            (3),
    normal                  (2),
    overloadImminent        (5),
    overloadReached         (6),
    overloadRelieved        (7)      }

CallOrigination ::= BIT STRING
{
    internal    (0),
    external    (1)}

ForwardList ::= SEQUENCE OF SEQUENCE
{
    forwardingType      ForwardingType      OPTIONAL,
    forwardStatus       BOOLEAN,
    forwardDN           DeviceID            OPTIONAL,
    forwardDefault      ForwardDefault      OPTIONAL,
    ringCount           INTEGER (1..100)    OPTIONAL}

ForwardingType ::= ENUMERATED
{
    forwardImmediate      (0),
    forwardBusy           (1),
    forwardNoAns          (2),
    forwardDND            (9),
    forwardBusyInt        (3),
    forwardBusyExt        (4),
    forwardNoAnsInt       (5),
    forwardNoAnsExt       (6),
    forwardImmInt         (7),
    forwardImmExt         (8),
    forwardDNDInt         (10),
    forwardDNDExt         (11)}

ForwardDefault ::= ENUMERATED
{
    forwardingTypeAndForwardDN (0),
    forwardingType             (1),
    forwardDN                  (2)}

PendingAgentState ::= ENUMERATED
{
    agentNotReady      (0),
    agentNull          (1),
    agentReady         (2),
    agentWorkingAfterCall (3)}

DataPathType ::= ENUMERATED
{
    text    (0),
    voice   (1)}

DisplayAttributeList ::= SEQUENCE
{
    physicalBaseRowNumber      [0] IMPLICIT INTEGER OPTIONAL,
    physicalBaseColumnNumber  [1] IMPLICIT INTEGER OPTIONAL,
    offset                    [2] IMPLICIT INTEGER OPTIONAL}

TerminatingConditions ::= BIT STRING
{
    durationExceeded      (0),
    dTMFDigitDetected    (1),
    endOfMessageDetected  (2),
    speechDetected        (3)}

AttributeInfo ::= CHOICE
{
    encodingAlgorithm      [0] IMPLICIT EncodingAlgorithm,
    samplingRate           [1] IMPLICIT INTEGER,
```



```
duration          [2] IMPLICIT INTEGER,
filename          [3] IMPLICIT IA5String,
currentPosition   [4] IMPLICIT INTEGER,
currentSpeed      [5] IMPLICIT INTEGER,
currentVolume     [6] IMPLICIT INTEGER (0 .. 100),
currentGain       [7] IMPLICIT INTEGER (0 .. 100),
currentState      [8] IMPLICIT CurrentState}

EncodingAlgorithm ::= ENUMERATED
{
    aDPCM6K      (0),
    aDPCM8K      (1),
    muLawPCM6K   (2),
    aLawPCM6K    (3)}

CurrentState ::= ENUMERATED
{
    stop          (0),
    play          (1),
    record        (2),
    suspendPlay   (3),
    suspendRecord (4),
    review        (5)}

ControlData ::= SEQUENCE
{
    gender          ENUMERATED
                    {male          (0),
                     female        (1)},
    language        OCTET STRING}

UserData ::= [APPLICATION 29] OCTET STRING (SIZE(0..256))

TelephonyTone ::= ENUMERATED
{
    beep          ( 0),
    billing        ( 1),
    busy           ( 2),
    carrier        ( 3),
    confirmation   ( 4),
    dial           ( 5),
    faxCNG         ( 6),
    hold           ( 7),
    howler         ( 8),
    intrusion      ( 9),
    modemCNG       (10),
    park           (11),
    recordWarning  (12),
    reorder        (13),
    ringback       (14),
    silence        (15),
    sitVC          (16),
    sitIC          (17),
    sitRO          (18),
    sitNC          (19),
    switchSpec0    (20),
    switchSpec1    (21),
    switchSpec2    (22),
    switchSpec3    (23),
    switchSpec4    (24),
    switchSpec5    (25),
    switchSpec6    (26),
    switchSpec7    (27),
    switchSpec8    (28),
    switchSpec9    (29),
    switchSpec10   (30),
    switchSpec11   (31),
    switchSpec12   (32),
    switchSpec13   (33),
    switchSpec14   (34),
    switchSpec15   (35),
```

switchSpec16	(36),
switchSpec17	(37),
switchSpec18	(38),
switchSpec19	(39),
switchSpec20	(40),
switchSpec21	(41),
switchSpec22	(42),
switchSpec23	(43),
switchSpec24	(44),
switchSpec25	(45),
switchSpec26	(46),
switchSpec27	(47),
switchSpec28	(48),
switchSpec29	(49),
switchSpec30	(50),
switchSpec31	(51),
switchSpec32	(52),
switchSpec33	(53),
switchSpec34	(54),
switchSpec35	(55),
switchSpec36	(56),
switchSpec37	(57),
switchSpec38	(58),
switchSpec39	(59),
switchSpec40	(60),
switchSpec41	(61),
switchSpec42	(62),
switchSpec43	(63),
switchSpec44	(64),
switchSpec45	(65),
switchSpec46	(66),
switchSpec47	(67),
switchSpec48	(68),
switchSpec49	(69),
switchSpec50	(70),
switchSpec51	(71),
switchSpec52	(72),
switchSpec53	(73),
switchSpec54	(74),
switchSpec55	(75),
switchSpec56	(76),
switchSpec57	(77),
switchSpec58	(78),
switchSpec59	(79),
switchSpec60	(80),
switchSpec61	(81),
switchSpec62	(82),
switchSpec63	(83),
switchSpec64	(84),
switchSpec65	(85),
switchSpec66	(86),
switchSpec67	(87),
switchSpec68	(88),
switchSpec69	(89),
switchSpec70	(90),
switchSpec71	(91),
switchSpec72	(92),
switchSpec73	(93),
switchSpec74	(94),
switchSpec75	(95),
switchSpec76	(96),
switchSpec77	(97),
switchSpec78	(98),
switchSpec79	(99),
switchSpec80	(100),
switchSpec81	(101),
switchSpec82	(102),
switchSpec83	(103),

```
switchSpec84      (104),  
switchSpec85      (105),  
switchSpec86      (106),  
switchSpec87      (107),  
switchSpec88      (108),  
switchSpec89      (109),  
switchSpec90      (110),  
switchSpec91      (111),  
switchSpec92      (112),  
switchSpec93      (113),  
switchSpec94      (114),  
switchSpec95      (115),  
switchSpec96      (116),  
switchSpec97      (117),  
switchSpec98      (118),  
switchSpec99      (119),  
switchSpec100     (120)}
```

```
END  -- of CSTA-device-feature-types
```

## 9.7 Security

```
CSTA-security
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) security( 128) }

DEFINITIONS ::=
BEGIN

EXPORTS
CSTASecurityData,TimeInfo;

CSTASecurityData ::= SEQUENCE
{
    messageSequenceNumber[0] IMPLICIT INTEGER      OPTIONAL,
    timestamp                TimeInfo              OPTIONAL,
    securityInfo              SecurityInfo           OPTIONAL}

SecurityInfo ::= CHOICE
{
    string      OCTET STRING,
    private     NULL}      -- The actual encoding is added here,
                          -- replacing NULL with another valid ASN.1 type.

TimeInfo ::= GeneralizedTime

END -- of CSTA-security
```

## 9.8 Common extensions

```
CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }

DEFINITIONS ::=
BEGIN

EXPORTS
CSTACommonArguments, CSTAPrivateData;

IMPORTS
CSTASecurityData FROM CSTA-security
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) security( 128) };

CSTACommonArguments ::= [APPLICATION 30] IMPLICIT SEQUENCE
    { security      [0] IMPLICIT  CSTASecurityData      OPTIONAL,
      privateData   [1] IMPLICIT  SEQUENCE OF CSTAPrivateData  OPTIONAL }

CSTAPrivateData ::= CHOICE
{
    string      OCTET STRING,
    private     NULL}      -- The actual encoding is added here,
                          -- replacing NULL with another valid ASN.1 type.

END -- of CSTA-extension-types
```

## 9.9 Call control

```
CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }

DEFINITIONS ::=
BEGIN

EXPORTS
AutoOriginate, CallCharacteristics, CallLinkageData, CallLinkageDataList, CallQualifyingData,
ConsultOptions, NetworkCapability,
ProgressIndicator, ServicesPermitted;

IMPORTS
TimeInfo FROM CSTA-security
{ iso( 1) identified-organization( 3) icd-ecma( 12) standard( 0)
  csta3( 285) security( 128) }
CallControlServices, CallAssociatedServices, MediaAttachmentServices, RouteingServices,
VoiceUnitServices FROM CSTA-application-context-information-csta3
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) application-context-information( 200) };

AutoOriginate ::= ENUMERATED
{
    prompt          (0),
    doNotPrompt     (1) }

CallCharacteristics ::= BIT STRING
{
    acdCall          (0),
    priorityCall     (1),
    maintenanceCall  (2),
    directAgent      (3),
    assistCall       (4),
    voiceUnitCall    (5)}

CallQualifyingData ::= OCTET STRING (SIZE(0..32))

ConsultOptions ::= ENUMERATED
{
    unrestricted     (0),
    consultOnly      (1),
    transferOnly     (2),
    conferenceOnly   (3) }

NetworkCapability ::= SEQUENCE
{
    networkType ENUMERATED
    {
        iSDNPublic      (0),
        nonISDNPublic   (1),
        iSDNPrivate     (2),
        nonISDNPrivate  (3),
        other            (4) },
    eventsProvided BIT STRING
    {
        bridged          (0),
        callCleared      (1),
        conferenced      (2),
        connectionCleared (3),
        delivered        (4),
        digitsDialed     (5),
        diverted         (6),
        established      (7),
        failed           (8),
        held             (9),
        networkCapabilitiesChange (10),
        networkReached   (11),
        offered          (12),
        originated       (13),
        queued           (14),
        retrieved        (15),
        serviceInitiated (16),
```

```
transferred (17) } OPTIONAL}

ProgressIndicator ::= SEQUENCE
{
    progressLocation ENUMERATED
    {
        user (0),
        privateNetServingLocal (1),
        publicNetServingLocal (2),
        transitNetwork (3),
        publicNetServingRemote (4),
        privateNetServingRemote (5),
        localInterface (6),
        internationalNetwork (7),
        networkBeyondInterwk (8),
        other (9) },
    progressDescription ENUMERATED
    {
        iSDNProgressDesc (0),
        qSIGProgressDesc (1),
        other (2) }}

ServicesPermitted ::= SEQUENCE
{
    callControlServices CallControlServices,
    callAssociatedServices CallAssociatedServices,
    mediaAttachmentServices MediaAttachmentServices,
    routingServices RoutingServices,
    voiceUnitServices VoiceUnitServices}

CallLinkageDataList ::= SEQUENCE
{
    newCallLinkageData CallLinkageData,
    oldCallLinkageData CallLinkageData}

CallLinkageData ::= SEQUENCE
{
    globalCallData GlobalCallData,
    threadData ThreadData OPTIONAL }

GlobalCallData ::= SEQUENCE
{
    globalCallSwitchingSubDomainName IA5String (SIZE(1..64)) OPTIONAL,
    globalCallLinkageID GlobalCallLinkageID,
    callLinkageIDTimestamp TimeInfo OPTIONAL }

GlobalCallLinkageID ::= CHOICE
{
    subDomainCallLinkageID [0] IMPLICIT OCTET STRING (SIZE(1..8)),
    globallyUniqueCallLinkageID [1] IMPLICIT OCTET STRING (SIZE(1..16)) }

ThreadData ::= SEQUENCE
{
    threadSwitchingSubDomainName IA5String (SIZE(1..64)) OPTIONAL,
    threadLinkageID ThreadLinkageID,
    threadIDTimeStamp TimeInfo OPTIONAL }

ThreadLinkageID ::= CHOICE
{
    subDomainThreadID [0] IMPLICIT OCTET STRING (SIZE(1..8)),
    globallyUniqueThreadID [1] IMPLICIT OCTET STRING (SIZE(1..16)) }

END -- of CSTA-call-control
```

## 9.10 Capability Exchange

```
CSTA-capability-exchange
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) capability-exchange( 131) }

DEFINITIONS ::=
BEGIN

EXPORTS
CapExchangeServList, SystemStatusServList, MonitoringServList, SnapshotServList,
CallControlServList, CallControlEvtsList, CallAssociatedServList,
CallAssociatedEvtsList, MediaServList, MediaEvtsList, RouteingServList, PhysDevEvtsList,
PhysDevServList, LogicalEvtsList, LogicalServList, DeviceMaintEvtsList, IOServicesServList,
DataCollectionServList, VoiceUnitServList, VoiceUnitEvtsList, CDRServList,
VendorSpecificServList, VendorSpecificEvtsList, DeviceIDFormat, SwDomainFeatures,
SwAppearanceAddressability, SwAppearanceTypes, IgnoreUnsupportedParameters, PauseTime,
TimeStampMode, MiscMonitorCaps, MaxLengthParameters, FilterThreshold, ServiceCrossRefID,
DeviceCategory, GroupDeviceAttributes, NamedDeviceTypes, ACDModels, AgentLogOnModels,
AppearanceType, TransAndConfSetup, MediaServiceCapsList, LogDevServList, LogDevEvtsList;

IMPORTS
MediaServiceType, MediaServiceInstanceID, ConnectionMode, ConnectionModeBMap
FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

ServiceCrossRefID ::= OCTET STRING (SIZE(0..4))

-- Capability Bitmaps

LogDevServList ::= SEQUENCE
{
    callControlServList      [0] IMPLICIT CallControlServList      OPTIONAL,
    callAssociatedServList   [1] IMPLICIT CallAssociatedServList   OPTIONAL,
    logicalServList          [2] IMPLICIT LogicalServList          OPTIONAL,
    mediaServList            [3] IMPLICIT MediaServList            OPTIONAL,
    ioservicesServList       [4] IMPLICIT IOServicesServList       OPTIONAL,
    dataCollectionServList   [5] IMPLICIT DataCollectionServList   OPTIONAL,
    voiceUnitServList        [6] IMPLICIT VoiceUnitServList        OPTIONAL}

LogDevEvtsList ::= SEQUENCE
{
    callControlEvtsList      [0] IMPLICIT CallControlEvtsList      OPTIONAL,
    callAssociatedEvtsList   [1] IMPLICIT CallAssociatedEvtsList   OPTIONAL,
    logicalEvtsList          [2] IMPLICIT LogicalEvtsList          OPTIONAL,
    mediaEvtsList            [3] IMPLICIT MediaEvtsList            OPTIONAL,
    voiceUnitEvtsList        [4] IMPLICIT VoiceUnitEvtsList        OPTIONAL}

CapExchangeServList ::= SEQUENCE
{
    getLogicalDeviceInformation [0] IMPLICIT GetLogicalDeviceInformation OPTIONAL,
    getPhysicalDeviceInformation [1] IMPLICIT GetPhysicalDeviceInformation OPTIONAL,
    getSwitchingFunctionCaps    NULL,
    getSwitchingFunctionDevices [2] IMPLICIT GetSwitchingFunctionDevices OPTIONAL,
    switchingFunctionDevices     [3] IMPLICIT SwitchingFunctionDevices OPTIONAL}

GetLogicalDeviceInformation ::= BIT STRING
{
    privateDataInReq          ( 0),
    namedDeviceTypeInAck      ( 1),
    shortFormDeviceIDInAck    ( 2),
    miscMonitorCapsInAck      ( 3),
    maxCallBacksInAck         ( 4),
    maxAutoAnswerRingsInAck   ( 5),
    maxActiveCallsInAck       ( 6),
    maxHeldCallsInAck         ( 7),
    maxFwdSettingsInAck       ( 8),
    maxDevicesInConfInAck     ( 9),
    transAndConfSetupParameter (10),
    transAndConfSetupConsultationInAck (11),
```



```
transAndConfSetupHoldMakeInAck          (12),
transAndConfSetupAlternateInAck          (13),
transAndConfSetupTwoCallsHoldInAck       (14),
transAndConfSetupTwoCallsConnectedInAck  (15),
mediaClassSupportInAck                   (16),
connectionRateListInAck                   (17),
delayToleranceListInAck                   (18),
numberOfChannelsInAck                     (19),
maxChannelBindInAck                       (20),
privateDataInAck                          (21)}

GetPhysicalDeviceInformation ::= BIT STRING
{
    privateDataInReq          ( 0),
    namedDeviceTypesInAck     ( 1),
    otherLogicalDeviceListInAck ( 2),
    deviceModelNameInAck      ( 3),
    maxDisplaysInAck          ( 4),
    maxButtonsInAck           ( 5),
    maxLampsInAck             ( 6),
    maxRingPatternsInAck      ( 7),
    privateDataInAck          ( 8)}

GetSwitchingFunctionDevices ::= BIT STRING
{
    requestedDeviceID          ( 0),
    requestedDeviceCategoryACD ( 1),
    requestedDeviceCategoryACDGroup ( 2),
    requestedDeviceCategoryHuntGroup ( 3),
    requestedDeviceCategoryPickGroup ( 4),
    requestedDeviceCategoryOtherGroup ( 5),
    requestedDeviceCategoryNetwInterface ( 6),
    requestedDeviceCategoryPark ( 7),
    requestedDeviceCategoryRouteingDevice ( 8),
    requestedDeviceCategoryStation ( 9),
    requestedDeviceCategoryVoiceUnit (10),
    requestedDeviceCategoryOther (11),
    privateData                (12),
    privateDataInAck           (13)}

SwitchingFunctionDevices ::= BIT STRING
{
    segmentID          ( 0),
    deviceListDeviceCategory ( 1),
    deviceListNamedDeviceTypes ( 2),
    deviceListDeviceAttributes ( 3),
    deviceListDeviceModelName ( 4),
    privateData          ( 5)}

SystemStatusServList ::= SEQUENCE
{
    changeSystemStatusFilter [ 0] IMPLICIT ChangeSystemStatusFilter OPTIONAL,
    systemRegister           [ 1] IMPLICIT SystemRegister          OPTIONAL,
    systemStatusRegisterAbort [ 2] IMPLICIT SystemStatusRegisterAbort OPTIONAL,
    systemStatusRegisterCancel [ 3] IMPLICIT SystemStatusRegisterCancel OPTIONAL,
    requestSystemStatus       [ 4] IMPLICIT RequestSystemStatus     OPTIONAL,
    systemStatus              [ 5] IMPLICIT SystemStatus            OPTIONAL,
    swFunctionCapsChanged     [ 6] IMPLICIT SwFunctionCapsChanged   OPTIONAL,
    swFunctionDevicesChanged  [ 7] IMPLICIT SwFunctionDevicesChanged OPTIONAL}

ChangeSystemStatusFilter ::= BIT STRING
{
    requestedStatusFilterInitializing ( 0), -- optional parameters
    requestedStatusFilterEnabled      ( 1), -- optional parameters
    requestedStatusFilterNormal       ( 2), -- optional parameters
    requestedStatusFilterMessageLost  ( 3), -- optional parameters
    requestedStatusFilterDisabled     ( 4), -- optional parameters
    requestedStatusFilterPartiallyDisabled ( 5), -- optional parameters
    requestedStatusFilterOverloadImminent ( 6), -- optional parameters
    requestedStatusFilterOverloadReached ( 7), -- optional parameters
    requestedStatusFilterOverloadRelieved ( 8), -- optional parameters
    privateData                      ( 9), -- optional parameters
```

```
privateDataInAck (10)} -- optional parameters

SystemRegister ::= BIT STRING
{
    requestTypesSystemStatus ( 0), -- optional parameters
    requestTypesRequestSystemStatus ( 1), -- optional parameters
    requestTypesSwitchingFunctionCapsChanged ( 2), -- optional parameters
    requestTypesSwitchingFunctionDevicesChanged ( 3), -- optional parameters
    statusFilterInitializing ( 4), -- optional parameters
    statusFilterEnabled ( 5), -- optional parameters
    statusFilterNormal ( 6), -- optional parameters
    statusFilterMessageLost ( 7), -- optional parameters
    statusFilterDisabled ( 8), -- optional parameters
    statusFilterPartiallyDisabled ( 9), -- optional parameters
    statusFilterOverloadImminent (10), -- optional parameters
    statusFilterOverloadReached (11), -- optional parameters
    statusFilterOverloadRelieved (12), -- optional parameters
    privateDataOctetString (13), -- optional parameters
    privateData (14), -- optional parameters
    privateDataOctetStringInAck (15), -- optional parameters
    privateDataInAck (16)} -- optional parameters

SystemStatusRegisterCancel ::= BIT STRING
{
    privateData (0), -- optional parameters
    privateDataInAck (1)} -- optional parameters

SystemStatusRegisterAbort ::= BIT STRING
{
    privateData (0), -- optional parameters
    privateDataInAck (1)} -- optional parameters

RequestSystemStatus ::= BIT STRING
{
    privateDataInReq ( 0), -- optional parameters
    systemStatusInitializing ( 1), -- optional parameters
    systemStatusEnabled ( 2), -- optional parameters
    systemStatusNormal ( 3), -- optional parameters
    systemStatusMessageLost ( 4), -- optional parameters
    systemStatusDisabled ( 5), -- optional parameters
    systemStatusPartiallyDisabled ( 6), -- optional parameters
    systemStatusOverloadImminent ( 7), -- optional parameters
    systemStatusOverloadReached ( 8), -- optional parameters
    systemStatusOverloadRelieved ( 9), -- optional parameters
    privateDataInAck (10), -- optional parameters
    switchingFunctionSupportsSending (11), -- misc characteristics
    switchingFunctionSupportsReceiving (12)} -- misc characteristics

SystemStatus ::= BIT STRING
{
    systemStatusInitializing ( 0), -- optional parameters
    systemStatusEnabled ( 1), -- optional parameters
    systemStatusNormal ( 2), -- optional parameters
    systemStatusMessageLost ( 3), -- optional parameters
    systemStatusDisabled ( 4), -- optional parameters
    systemStatusPartiallyDisabled ( 5), -- optional parameters
    systemStatusOverloadImminent ( 6), -- optional parameters
    systemStatusOverloadReached ( 7), -- optional parameters
    systemStatusOverloadRelieved ( 8), -- optional parameters
    privateData ( 9), -- optional parameters
    privateDataInAck (10), -- optional parameters
    switchingFunctionSupportsSending (11), -- misc characteristics
    switchingFunctionSupportsReceiving (12)} -- misc characteristics

SwFunctionCapsChanged ::= BIT STRING
{
    privateData (0), -- optional parameters
    privateDataInAck (1)} -- optional parameters

SwFunctionDevicesChanged ::= BIT STRING
{
    privateData (0), -- optional parameters
    privateDataInAck (1)} -- optional parameters

MonitoringServList ::= SEQUENCE
```

```
{      changeMonitorFilter      [ 0] IMPLICIT ChangeMonitorFilter      OPTIONAL,
      monitorStart              [ 1] IMPLICIT MonitorStart        OPTIONAL,
      monitorStop               [ 2] IMPLICIT MonitorStop         OPTIONAL}

ChangeMonitorFilter ::= BIT STRING
{      privateData              (0),      -- optional parameters
      privateDataInAck          (1)}      -- optional parameters

MonitorStart ::= BIT STRING
{      monitorObjectDevice      ( 0),      -- optional parameters
      monitorObjectCall         ( 1),      -- optional parameters
      requestedMonitorFilter     ( 2),      -- optional parameters
      monitorTypeCall           ( 3),      -- optional parameters
      monitorTypeDevice         ( 4),      -- optional parameters
      monitorMediaClassParameter ( 5),      -- optional parameters
      monitorMediaClassAudio     ( 6),      -- optional parameters
      monitorMediaClassData      ( 7),      -- optional parameters
      monitorMediaClassImage     ( 8),      -- optional parameters
      monitorMediaClassVoice     ( 9),      -- optional parameters
      monitorExistingCallsInAck  (10),      -- optional parameters
      privateDataInAck           (11),      -- optional parameters
      callIDOnly                (12),      -- miscellaneous characteristics
      swDomainDefaultForMonitorTypeIsDevice (13)} -- miscellaneous characteristics

MonitorStop ::= BIT STRING
{      privateData              ( 0),      -- optional parameters
      privateDataInAck          ( 1),      -- optional parameters
      switchingFunctionSupportsSending ( 2),      -- misc characteristics
      switchingFunctionSupportsReceiving ( 3)} -- misc characteristics

SnapshotServList ::= SEQUENCE
{      snapshotCall             [0] IMPLICIT SnapshotCall,
      snapshotDevice            [1] IMPLICIT SnapshotDevice,
      snapshotCallData          [2] IMPLICIT SnapshotCallData,
      snapshotDeviceData        [3] IMPLICIT SnapshotDeviceData}

SnapshotCall ::= BIT STRING
{      privateData              ( 0),      -- optional parameters
      locaConnectionStateInAck  ( 1),      -- optional parameters
      mediaServiceInfoListInAck ( 2),      -- optional parameters
      mediaServiceVersionInAck  ( 3),      -- optional parameters
      mediaServiceInstanceInAck ( 4),      -- optional parameters
      mediaStreamID             ( 5),      -- optional parameters
      connectionInformation     ( 6),      -- optional parameters
      mediaCallCharacteristicsInAck ( 7),      -- optional parameters
      callCharacteristicsInAck  ( 8),      -- optional parameters
      callingDeviceInAck        ( 9),      -- optional parameters
      calledDeviceInAck         (10),      -- optional parameters
      privateDataInAck          (11),      -- optional parameters
      callIDOnly                (12),      -- miscellaneous characteristics
      reportsWithSnapsCallData  (13)} -- miscellaneous characteristics

SnapshotDevice ::= BIT STRING
{      privateData              ( 0),      -- optional parameters
      localCallStateCompoundCallState ( 1),      -- optional parameters
      localCallStateSimpleCallState ( 2),      -- optional parameters
      localCallStateUnknown     ( 3),      -- optional parameters
      mediaServiceInfoListInAck ( 4),      -- optional parameters
      mediaServiceVersionInAck  ( 5),      -- optional parameters
      mediaServiceInstanceInAck ( 6),      -- optional parameters
      mediaStreamID             ( 7),      -- optional parameters
      connectionInformation     ( 8),      -- optional parameters
      mediaCallCharacteristicsInAck ( 9),      -- optional parameters
      privateDataInAck          (10),      -- optional parameters
      reportsWithSnapsDeviceData (11)} -- miscellaneous characteristics

SnapshotCallData ::= BIT STRING
{      segmentID                ( 0),      -- optional parameters
```

```
localConnectionState      ( 1),  -- optional parameters
mediaServiceInformationList ( 2),  -- optional parameters
mediaServiceVersion       ( 3),  -- optional parameters
mediaServiceInstance      ( 4),  -- optional parameters
mediaStreamID             ( 5),  -- optional parameters
connectionInformation     ( 6),  -- optional parameters
privateData               ( 7)}  -- optional parameters

SnapshotDeviceData ::= BIT STRING
{
    segmentID                ( 0),  -- optional parameters
    localCallStateCompoundCallState ( 1),  -- optional parameters
    localCallStateSimpleCallState ( 2),  -- optional parameters
    localCallStateUnknown    ( 3),  -- optional parameters
    mediaServiceInformationList ( 4),  -- optional parameters
    mediaServiceVersion      ( 5),  -- optional parameters
    mediaServiceInstance     ( 6),  -- optional parameters
    mediaStreamID            ( 7),  -- optional parameters
    connectionInformation    ( 8),  -- optional parameters
    mediaCallCharacteristics ( 9),  -- optional parameters
    privateData              (10)}  -- optional parameters

CallControlServList ::= SEQUENCE
{
    acceptCall      [0] IMPLICIT AcceptCall      OPTIONAL,
    alternateCall   [1] IMPLICIT AlternateCall    OPTIONAL,
    answerCall      [2] IMPLICIT AnswerCall      OPTIONAL,
    callBack        [3] IMPLICIT CallBack        OPTIONAL,
    callBackMessage [4] IMPLICIT CallBackMessage  OPTIONAL,
    campOnCall      [5] IMPLICIT CampOnCall      OPTIONAL,
    clearCall       [6] IMPLICIT ClearCall       OPTIONAL,
    clearConnection [7] IMPLICIT ClearConnection OPTIONAL,
    conferenceCall  [8] IMPLICIT ConferenceCall  OPTIONAL,
    consultationCall [9] IMPLICIT ConsultationCall OPTIONAL,
    deflectCall     [10] IMPLICIT DeflectCall    OPTIONAL,
    dialDigits      [11] IMPLICIT DialDigits     OPTIONAL,
    directedPickupCall [12] IMPLICIT DirectedPickupCall OPTIONAL,
    groupPickupCall [13] IMPLICIT GroupPickupCall OPTIONAL,
    holdCall        [14] IMPLICIT HoldCall       OPTIONAL,
    intrudeCall     [15] IMPLICIT IntrudeCall    OPTIONAL,
    joinCall        [16] IMPLICIT JoinCall       OPTIONAL,
    makeCall        [17] IMPLICIT MakeCall       OPTIONAL,
    makePredictiveCall [18] IMPLICIT MakePredictiveCall OPTIONAL,
    parkCall       [19] IMPLICIT ParkCall       OPTIONAL,
    reconnectCall   [20] IMPLICIT ReconnectCall  OPTIONAL,
    retrieveCall    [21] IMPLICIT RetrieveCall   OPTIONAL,
    singleStepConference [22] IMPLICIT SingleStepConference OPTIONAL,
    singleStepTransfer [23] IMPLICIT SingleStepTransfer OPTIONAL,
    transferCall    [24] IMPLICIT TransferCall   OPTIONAL}

AcceptCall ::= BIT STRING
{
    correlatorData      ( 0),  -- optional parameters
    userData            ( 1),  -- optional parameters
    privateData         ( 2),  -- optional parameters
    privateDataInAck    ( 3),  -- optional parameters
    deviceIDOnly        ( 4),  -- misc characteristics
    ackModelMultiStep   ( 5)}  -- misc characteristics

AlternateCall ::= BIT STRING
{
    alerting          ( 0),  -- initial states heldCall
    hold              ( 1),  -- initial states heldCall
    queued            ( 2),  -- initial states heldCall
    connectionReservation ( 3),  -- optional parameters
    consultOptionConsultOnly ( 4),  -- optional parameters
    consultOptionTransferOnly ( 5),  -- optional parameters
    consultOptionConferenceOnly ( 6),  -- optional parameters
    consultOptionUnrestricted ( 7),  -- optional parameters
    privateData       ( 8),  -- optional parameters
    privateDataInAck   ( 9),  -- optional parameters
    deviceIDOnly       (10),  -- misc characteristics
```

```
    ackModelMultiStep          (11),    -- misc characteristics
    supportsOfferedModeOfAlerting (12)}  -- misc characteristics

AnswerCall ::= BIT STRING
{
    alerting          ( 0),    -- initial states
    initiated         ( 1),    -- initial states
    queued            ( 2),    -- initial states
    correlatorData    ( 3),    -- optional parameters
    userData          ( 4),    -- optional parameters
    privateData       ( 5),    -- optional parameters
    privateDataInAck  ( 6),    -- optional parameters
    deviceIDOnly      ( 7),    -- misc characteristics
    supportsOfferedModeOfAlerting ( 8),    -- misc characteristics
    ackModelMultiStep ( 9)}    -- misc characteristics

CallBack ::= BIT STRING
{
    alerting          ( 0),    -- initial states
    null              ( 1),    -- initial states
    failed            ( 2),    -- initial states
    queued            ( 3),    -- initial states
    callCharacteristics ( 4),    -- optional parameters
    privateData       ( 5),    -- optional parameters
    targetDeviceInAck ( 6),    -- optional parameters
    privateDataInAck  ( 7),    -- optional parameters
    deviceIDOnly      ( 8),    -- misc characteristics
    moreCallBacksNegAck ( 9),    -- misc characteristics
    ackModelMultiStep (10)}    -- misc characteristics

CallBackMessage ::= BIT STRING
{
    alerting          ( 0),    -- initial states
    null              ( 1),    -- initial states
    failed            ( 2),    -- initial states
    queued            ( 3),    -- initial states
    privateData       ( 4),    -- optional parameters
    targetDeviceInAck ( 5),    -- optional parameters
    privateDataInAck  ( 6),    -- optional parameters
    deviceIDOnly      ( 7),    -- misc characteristics
    moreCallBacksNegAck ( 8),    -- misc characteristics
    ackModelMultiStep ( 9)}    -- misc characteristics

CampOnCall ::= BIT STRING
{
    privateData       ( 0),    -- optional parameters
    privateDataInAck  ( 1),    -- optional parameters
    deviceIDOnly      ( 2),    -- misc characteristics
    ackModelMultiStep ( 3)}    -- misc characteristics

ClearCall ::= BIT STRING
{
    alerting          ( 0),    -- initial states
    connected         ( 1),    -- initial states
    failed            ( 2),    -- initial states
    queued            ( 3),    -- initial states
    initiated         ( 4),    -- initial states
    hold              ( 5),    -- initial states
    userData          ( 6),    -- optional parameters
    privateData       ( 7),    -- optional parameters
    privateDataInAck  ( 8),    -- optional parameters
    deviceIDOnly      ( 9),    -- misc characteristics
    callIDOnly        (10),    -- misc characteristics
    ackModelMultiStep (11)}    -- misc characteristics

ClearConnection ::= BIT STRING
{
    alerting          ( 0),    -- initial states
    connected         ( 1),    -- initial states
    fail              ( 2),    -- initial states
    queued            ( 3),    -- initial states
    initiated         ( 4),    -- initial states
    hold              ( 5),    -- initial states
    correlatorData    ( 6),    -- optional parameters
```

```

    userData                ( 7),    -- optional parameters
    privateData             ( 8),    -- optional parameters
    privateDataInAck        ( 9),    -- optional parameters
    deviceIDOnly            (10),    -- misc characteristics
    ackModelMultiStep       (11)}    -- misc characteristics

ConferenceCall ::= BIT STRING
{
    activeCallConnected      ( 0),    -- initial states
    activeCallHold           ( 1),    -- initial states
    heldCallConnected        ( 2),    -- initial states
    heldCallHold             ( 3),    -- initial states
    privateData              ( 4),    -- optional parameters
    connectionParameterInAck ( 5),    -- optional parameters
    endpointDeviceID         ( 6),    -- optional parameters
    resultingConnectionInfo   ( 7),    -- optional parameters
    conferenceCallOnfoInAck   ( 8),    -- optional parameters
    privateDataInAck         ( 9),    -- optional parameters
    protectedAgainstClearing (10),    -- misc characteristics
    deviceIDOnly             (11),    -- misc characteristics
    ackModelMultiStep        (12)}    -- misc characteristics

ConsultationCall ::= BIT STRING
{
    connectionReservation     ( 0),    -- optional parameters
    accountCode               ( 1),    -- optional parameters
    authCode                  ( 2),    -- optional parameters
    correlatorData            ( 3),    -- optional parameters
    userData                  ( 4),    -- optional parameters
    callCharacteristics        ( 5),    -- optional parameters
    callCharacteristicsACDCall ( 6),    -- optional parameters
    callCharacteristicsPriorityCall ( 7),    -- optional parameters
    callCharacteristicsMaintenanceCall ( 8),    -- optional parameters
    callCharacteristicsDirectAgent ( 9),    -- optional parameters
    callCharacteristicsAssistCall (10),    -- optional parameters
    callCharacteristicsVoiceUnitCall (11),    -- optional parameters
    mediaCallCharacteristics   (12),    -- optional parameters
    callingConnectionInfo      (13),    -- optional parameters
    flowDirectionTransmit      (14),    -- optional parameters
    flowDirectionReceive       (15),    -- optional parameters
    flowDirectionTransmitAndReceive (16),    -- optional parameters
    numberOfChannels           (17),    -- optional parameters
    consultOptionConsultOnly    (18),    -- optional parameters
    consultOptionTransferOnly   (19),    -- optional parameters
    consultOptionConferenceOnly (20),    -- optional parameters
    consultOptionUnrestricted   (21),    -- optional parameters
    privateData                (22),    -- optional parameters
    initiatedCallInfoInAck      (23),    -- optional parameters
    privateDataInAck           (24),    -- optional parameters
    deviceIDOnly               (25),    -- misc characteristics
    multiStage                 (26),    -- misc characteristics
    supportsAdjustmentOfMediaCharacteristics (27),    -- misc characteristics
    ackModelMultiStep          (28)}    -- misc characteristics

DeflectCall ::= BIT STRING
{
    alerting                  ( 0),    -- initial states
    connected                 ( 1),    -- initial states
    failed                    ( 2),    -- initial states
    hold                      ( 3),    -- initial states
    queued                    ( 4),    -- initial states
    correlatorData            ( 5),    -- optional parameters
    userData                  ( 6),    -- optional parameters
    privateData               ( 7),    -- optional parameters
    privateDataInAck          ( 8),    -- optional parameters
    deviceIDOnly              ( 9),    -- misc characteristics
    ackModelMultiStep         (10)}    -- misc characteristics

DialDigits ::= BIT STRING
{
    correlatorData            ( 0),    -- optional parameters
    privateData               ( 1),    -- optional parameters
```

```
privateDataInAck          ( 2),  -- optional parameters
deviceIDOnly              ( 3),  -- misc characteristics
ackModelMultiStep         ( 4)}  -- misc characteristics

DirectedPickupCall ::= BIT STRING
{
    alerting                ( 0),  -- initial states
    hold                    ( 1),  -- initial states
    queued                  ( 2),  -- initial states
    connected               ( 3),  -- initial states
    correlatorData          ( 4),  -- optional parameters
    userData                ( 5),  -- optional parameters
    privateData             ( 6),  -- optional parameters
    pickedCallInAck         ( 7),  -- optional parameters
    pickedCallInfoInAck     ( 8),  -- optional parameters
    privateDataInAck        ( 9),  -- optional parameters
    deviceIDOnly            (10),  -- misc characteristics
    supportsOfferedModeOfAlerting (11), -- misc characteristics
    supportsPrompting       (12),  -- misc characteristics
    promptingMode           (13),  -- misc characteristics
    ackModelMultiStep       (14)}  -- misc characteristics

GroupPickupCall ::= BIT STRING
{
    alerting                ( 0),  -- initial states
    connected               ( 1),  -- initial states
    hold                    ( 2),  -- initial states
    queued                  ( 3),  -- initial states
    pickGroup               ( 4),  -- optional parameters
    correlatorData          ( 5),  -- optional parameters
    userData                ( 6),  -- optional parameters
    privateData             ( 7),  -- optional parameters
    pickedCallInAck         ( 8),  -- optional parameters
    pickedCallInfoInAck     ( 9),  -- optional parameters
    privateDataInAck        (10),  -- optional parameters
    supportsPrompting       (11),  -- misc characteristics
    promptingMode           (12),  -- misc characteristics
    supportsOfferedModeOfAlerting (13), -- misc characteristics
    ackModelMultiStep       (14)}  -- misc characteristics

HoldCall ::= BIT STRING
{
    connectionReservation   ( 0),  -- optional parameters
    privateData             ( 1),  -- optional parameters
    privateDataInAck        ( 2),  -- optional parameters
    deviceIDOnly            ( 3),  -- misc characteristics
    ackModelMultiStep       ( 4)}  -- misc characteristics

IntrudeCall ::= BIT STRING
{
    participationTypeSilent ( 0),  -- optional parameters
    participationTypeActive ( 1),  -- optional parameters
    userData                ( 2),  -- optional parameters
    privateData             ( 3),  -- optional parameters
    conferencedCallInfoInAck ( 4),  -- optional parameters
    privateDataInAck        ( 5),  -- optional parameters
    deviceIDOnly            ( 6),  -- misc characteristics
    supportsConference      ( 7),  -- misc characteristics
    supportsAlternate       ( 8),  -- misc characteristics
    ackModelMultiStep       ( 9)}  -- misc characteristics

JoinCall ::= BIT STRING
{
    autoOriginatePrompt     ( 0),  -- optional parameters
    autoOriginateDoNotPrompt ( 1),  -- optional parameters
    participationTypeSilent ( 2),  -- optional parameters
    participationTypeActive ( 3),  -- optional parameters
    accountCode             ( 4),  -- optional parameters
    authCode                ( 5),  -- optional parameters
    correlatorData          ( 6),  -- optional parameters
    userData                ( 7),  -- optional parameters
    conferencedCallInAck     ( 8),  -- optional parameters
    conferencedCallInfoInAck ( 9),  -- optional parameters
```

```
privateDataInAck          (10),  -- optional parameters
deviceIDOnly              (11),  -- misc characteristics
supportsPrompting         (12),  -- misc characteristics
promptingMode             (13),  -- misc characteristics
ackModelMultiStep         (14)}  -- misc characteristics

MakeCall ::= BIT STRING
{
    initiated              ( 0),  -- initials states
    null                   ( 1),  -- initials states
    accountCode            ( 2),  -- optional parameters
    authCode               ( 3),  -- optional parameters
    autoOriginatePrompt    ( 4),  -- optional parameters
    autoOriginateDoNotPrompt ( 5), -- optional parameters
    correlatorData         ( 6),  -- optional parameters
    userData               ( 7),  -- optional parameters
    callCharacteristics     ( 8),  -- optional parameters
    callCharacteristicsACDCall ( 9), -- optional parameters
    callCharacteristicsPriorityCall (10), -- optional parameters
    callCharacteristicsMaintenanceCall (11), -- optional parameters
    callCharacteristicsDirectAgent (12), -- optional parameters
    callCharacteristicsAssistCall (13), -- optional parameters
    callCharacteristicsVoiceUnitCall (14), -- optional parameters
    mediaCallCharacteristics (15), -- optional parameters
    callingConnectionInfo   (16), -- optional parameters
    privateData             (17), -- optional parameters
    initiatedCallInfoInAck  (18), -- optional parameters
    privateDataInAck        (19), -- optional parameters
    multiStage              (20),  -- misc characteristics
    supportsPrompting       (21),  -- misc characteristics
    promptingMode           (22),  -- misc characteristics
    offHook                 (23),  -- misc characteristics
    mediaCharacteristicsAdjustable (24), -- misc characteristics
    ackModelMultiStep       (25)}  -- misc characteristics

MakePredictiveCall ::= BIT STRING
{
    signallingDetection      ( 0),  -- optional parameters
    signallingConditionCallDelivered ( 1), -- optional parameters
    signallingConditionCallEstablished ( 2), -- optional parameters
    signallingConditionActionDestinationDetection ( 3), -- optional parameters
    signallingConditionActionRemainConnected ( 4), -- optional parameters
    destinationDetection     ( 5),  -- optional parameters
    destinationConditionHumanVoice ( 6), -- optional parameters
    destinationConditionAnsweringMachine ( 7), -- optional parameters
    destinationConditionFax   ( 8),  -- optional parameters
    destinationActionClearConnection ( 9), -- optional parameters
    destinationActionRemainConnected (10), -- optional parameters
    defaultActionClearConnection (11), -- optional parameters
    defaultActionRemainConnected (12), -- optional parameters
    accountCode              (13),  -- optional parameters
    authCode                 (14),  -- optional parameters
    autoOriginatePrompt      (15),  -- optional parameters
    autoOriginateDoNotPrompt (16),  -- optional parameters
    alertTime                (17),  -- optional parameters
    correlatorData           (18),  -- optional parameters
    callCharacteristics       (19),  -- optional parameters
    callCharacteristicsACDCall (20),  -- optional parameters
    callCharacteristicsPriorityCall (21), -- optional parameters
    callCharacteristicsMaintenanceCall (22), -- optional parameters
    callCharacteristicsDirectAgent (23), -- optional parameters
    callCharacteristicsAssistCall (24), -- optional parameters
    callCharacteristicsVoiceUnitCall (25), -- optional parameters
    userData                 (26),  -- optional parameters
    privateData              (27),  -- optional parameters
    initiatedCallInfoInAck   (28),  -- optional parameters
    privateDataInAck         (29),  -- optional parameters
    deviceIDOnly             (30),  -- misc characteristics
    supportsPrompting        (31),  -- misc characteristics
    promptingMode            (32),  -- misc characteristics
```



```

    reservesCallingDevice                (33),  -- misc characteristics
    ackModelMultiStep                    (34)}  -- misc characteristics

ParkCall ::= BIT STRING
{
    hold                                ( 0),  -- initial states
    connected                           ( 1),  -- initial states
    correlatorData                       ( 2),  -- optional parameters
    privateData                          ( 3),  -- optional parameters
    parkedToInAck                        ( 4),  -- optional parameters
    privateDataInAck                     ( 5),  -- optional parameters
    deviceIDOnly                         ( 6),  -- misc characteristics
    ackModelMultiStep                    ( 7)}  -- misc characteristics

ReconnectCall ::= BIT STRING
{
    alerting                             ( 0),  -- initial states
    connected                             ( 1),  -- initial states
    fail                                 ( 2),  -- initial states
    initiated                             ( 3),  -- initial states
    queued                               ( 4),  -- initial states
    privateData                          ( 5),  -- optional parameters
    privateDataInAck                     ( 6),  -- optional parameters
    deviceIDOnly                         ( 7),  -- misc characteristics
    ackModelMultiStep                    ( 8)}  -- misc characteristics

RetrieveCall ::= BIT STRING
{
    privateData                          ( 0),  -- optional parameters
    privateDataInAck                     ( 1),  -- optional parameters
    deviceIDOnly                         ( 2),  -- misc characteristics
    ackModelMultiStep                    ( 3)}  -- misc characteristics

SingleStepConference ::= BIT STRING
{
    participationTypeActive              ( 0),  -- optional parameters
    participationTypeSilent              ( 1),  -- optional parameters
    accountCode                          ( 2),  -- optional parameters
    authCode                             ( 3),  -- optional parameters
    correlatorData                       ( 4),  -- optional parameters
    userData                             ( 5),  -- optional parameters
    privateData                          ( 6),  -- optional parameters
    conferencedCallInfoInAck             ( 7),  -- optional parameters
    privateDataInAck                     ( 8),  -- optional parameters
    deviceIDOnly                         ( 9),  -- misc characteristics
    ackModelMultiStep                    (10)}  -- misc characteristics

SingleStepTransfer ::= BIT STRING
{
    accountCode                          ( 0),  -- optional parameters
    authCode                             ( 1),  -- optional parameters
    correlatorData                       ( 2),  -- optional parameters
    userData                             ( 3),  -- optional parameters
    privateData                          ( 4),  -- optional parameters
    connectionParameterInAck             ( 5),  -- optional parameters
    endpointDeviceID                     ( 6),  -- optional parameters
    resultionConnectionInformation        ( 7),  -- optional parameters
    transferredCollInfoInAck             ( 8),  -- optional parameters
    privateDataInAck                     ( 9),  -- optional parameters
    deviceIDOnly                         (10),  -- misc characteristics
    multipleDevices                      (11),  -- misc characteristics
    ackModelMultiStep                    (12)}  -- misc characteristics

TransferCall ::= BIT STRING
{
    activeCallConnected                  ( 0),  -- initial states
    activeCallHold                       ( 1),  -- initial states
    heldCallConnected                    ( 2),  -- initial states
    heldCallHold                         ( 3),  -- initial states
    privateData                          ( 4),  -- optional parameters
    connectionsParameterInAck            ( 5),  -- optional parameters
    endpointDeviceID                     ( 6),  -- optional parameters
    resultingConnectionInformation        ( 7),  -- optional parameters
    transferredCallInfoInAck             ( 8),  -- optional parameters
}
```

```
privateDataInAck          ( 9),  -- optional parameters
deviceIDOnly              (10),  -- misc characteristics
multipleDevices           (11),  -- misc characteristics
ackModelMultiStep         (12)}  -- misc characteristics

CallControlEvtsList ::= SEQUENCE
{
    bridged                [0] IMPLICIT Bridged                OPTIONAL,
    callCleared             [1] IMPLICIT CallCleared            OPTIONAL,
    conferenced             [2] IMPLICIT Conferenced            OPTIONAL,
    connectionCleared       [3] IMPLICIT ConnectionCleared      OPTIONAL,
    delivered               [4] IMPLICIT Delivered              OPTIONAL,
    digitsDialed            [5] IMPLICIT DigitsDialed            OPTIONAL,
    diverted                [6] IMPLICIT Diverted                OPTIONAL,
    established             [7] IMPLICIT Established             OPTIONAL,
    failed                  [8] IMPLICIT Failed                  OPTIONAL,
    held                    [9] IMPLICIT Held                    OPTIONAL,
    netwCapsChanged         [10] IMPLICIT NetwCapsChanged         OPTIONAL,
    netwReached              [11] IMPLICIT NetwReached            OPTIONAL,
    offered                 [12] IMPLICIT Offered                OPTIONAL,
    originated              [13] IMPLICIT Originated              OPTIONAL,
    queued                  [14] IMPLICIT Queued                  OPTIONAL,
    retrieved               [15] IMPLICIT Retrieved              OPTIONAL,
    serviceInitiated        [16] IMPLICIT ServiceInitiated       OPTIONAL,
    transferred             [17] IMPLICIT Transferred            OPTIONAL }

Bridged ::= BIT STRING
{
    correlatorData          ( 0),  -- optional parameters
    userData                ( 1),  -- optional parameters
    servicesPermitted        ( 2),  -- optional parameters
    mediaCallCharacteristics ( 3),  -- optional parameters
    callCharacteristics      ( 4),  -- optional parameters
    bridgedConnectionInfo    ( 5),  -- optional parameters
    callLinkageData          ( 7),  -- optional parameters
    privateData              ( 6)}  -- optional parameters

CallCleared ::= BIT STRING
{
    correlatorData          ( 0),  -- optional parameters
    userData                ( 1),  -- optional parameters
    mediaCallCharacteristics ( 2),  -- optional parameters
    callCharacteristics      ( 3),  -- optional parameters
    callLinkageData          ( 6),  -- optional parameters
    privateData              ( 4),  -- optional parameters
    callIDOnly              ( 5)}  -- miscellaneous characteristics

Conferenced ::= BIT STRING
{
    confereceConnectionsEndpointDeviceID ( 0),  -- optional parameters
    confereceConnectionsresultingConnectionInfo ( 1),  -- optional parameters
    userData                ( 2),  -- optional parameters
    servicesPermitted        ( 3),  -- optional parameters
    mediaCallCharacteristics ( 4),  -- optional parameters
    callCharacteristics      ( 5),  -- optional parameters
    bridgedConnectionInfo    ( 6),  -- optional parameters
    privateData              ( 7)}  -- optional parameters

ConnectionCleared ::= BIT STRING
{
    correlatorData          ( 0),  -- optional parameters
    userData                ( 1),  -- optional parameters
    chargingInfo            ( 2),  -- optional parameters
    numberUnitsNumberOfChargingUnits ( 3),  -- optional parameters
    numberUnitsTypeOfUnits  ( 4),  -- optional parameters
    numberUnitsNumberOfCurrencyUnits ( 5),  -- optional parameters
    typeOfChargingInfoSubTotal ( 6),  -- optional parameters
    typeOfChargingInfoTotal ( 7),  -- optional parameters
    chargingMultiplierATHousandth ( 8),  -- optional parameters
    chargingMultiplierAHundredth ( 9),  -- optional parameters
    chargingMultiplierATenth (10),  -- optional parameters
    chargingMultiplierOne   (11),  -- optional parameters
```

```
chargingMultiplierTen          (12),  -- optional parameters
chargingMultiplierHundred      (13),  -- optional parameters
chargingMultiplierThousand     (14),  -- optional parameters
servicesPermitted              (15),  -- optional parameters
mediaCallCharacteristics       (16),  -- optional parameters
callCharacteristics            (17),  -- optional parameters
droppedConnectionInfo         (18),  -- optional parameters
callLinkageData               (20),  -- optional parameters
privateData                    (19)}  -- optional parameters

Delivered ::= BIT STRING
{
    originatingNIDConnection    ( 0),  -- optional parameters
    userData                   ( 1),  -- optional parameters
    servicesPermitted          ( 2),  -- optional parameters
    netwCallingDevice          ( 3),  -- optional parameters
    netwCalledDevice           ( 4),  -- optional parameters
    mediaCallCharacteristics    ( 5),  -- optional parameters
    callCharacteristics        ( 6),  -- optional parameters
    connectionInfo             ( 7),  -- optional parameters
    privateData                ( 8)}  -- optional parameters

DigitsDialed ::= BIT STRING
{
    servicesPermitted          ( 0),  -- optional parameters
    netwCallingDevice          ( 1),  -- optional parameters
    netwCalledDevice           ( 2),  -- optional parameters
    diallingConnectionInfo     ( 3),  -- optional parameters
    callCharacteristics        ( 4),  -- optional parameters
    privateData                ( 5)}  -- optional parameters

Diverted ::= BIT STRING
{
    callingDevice              ( 0),  -- optional parameters
    calledDevice               ( 1),  -- optional parameters
    userData                   ( 2),  -- optional parameters
    servicesPermitted          ( 3),  -- optional parameters
    mediaCallCharacteristics    ( 4),  -- optional parameters
    callCharacteristics        ( 5),  -- optional parameters
    connectionInfo             ( 6),  -- optional parameters
    netwCallingDevice          ( 7),  -- optional parameters
    netwCalledDevice           ( 8),  -- optional parameters
    privateData                ( 9),  -- optional parameters
    sendsDivertedToAll         (10)}  -- optional parameters

Established ::= BIT STRING
{
    originatingNIDConnection    ( 0),  -- optional parameters
    userData                   ( 1),  -- optional parameters
    servicesPermitted          ( 2),  -- optional parameters
    netwCallingDevice          ( 3),  -- optional parameters
    netwCalledDevice           ( 4),  -- optional parameters
    mediaCallCharacteristics    ( 5),  -- optional parameters
    callCharacteristics        ( 6),  -- optional parameters
    establishedConnectionInfo   ( 7),  -- optional parameters
    privateData                ( 8)}  -- optional parameters

Failed ::= BIT STRING
{
    originatingNIDConnection    ( 0),  -- optional parameters
    userData                   ( 1),  -- optional parameters
    servicesPermitted          ( 2),  -- optional parameters
    netwCallingDevice          ( 3),  -- optional parameters
    netwCalledDevice           ( 4),  -- optional parameters
    mediaCallCharacteristics    ( 5),  -- optional parameters
    callCharacteristics        ( 6),  -- optional parameters
    failedConnectionInfo       ( 7),  -- optional parameters
    privateData                ( 8),  -- optional parameters
    callIDOnly                 ( 9)}  -- miscellaneous characteristics

Held ::= BIT STRING
{
    correlatorData             ( 0),  -- optional parameters
    servicesPermitted          ( 1),  -- optional parameters
```

```
mediaCallCharacteristics      ( 2),  -- optional parameters
callCharacteristics           ( 3),  -- optional parameters
heldConnectionInfo            ( 4),  -- optional parameters
callLinkageData               ( 6),  -- optional parameters
privateData                   ( 5)}  -- optional parameters

NetwCapsChanged ::= BIT STRING
{
    progressLocationUser      ( 0),  -- optional parameters
    progressLocationPrivateServLocal ( 1),  -- optional parameters
    progressLocationPublicServLocal ( 2),  -- optional parameters
    progressLocationTransit   ( 3),  -- optional parameters
    progressLocationPublicServRemote ( 4),  -- optional parameters
    progressLocationPrivateServRemote ( 5),  -- optional parameters
    progressLocationLocal     ( 6),  -- optional parameters
    progressLocationInternational ( 7),  -- optional parameters
    progressLocationNetwBeyondInterworking ( 8),  -- optional parameters
    progressLocationOther     ( 9),  -- optional parameters
    progressDescriptionISDN   (10),  -- optional parameters
    progressDescriptionQSIG   (11),  -- optional parameters
    progressDescriptionOther  (12),  -- optional parameters
    userData                  (13),  -- optional parameters
    typeOfNetworkISDNPublic   (14),  -- optional parameters
    typeOfNetworkNonISDNPublic (15),  -- optional parameters
    typeOfNetworkISDNPrivate  (16),  -- optional parameters
    typeOfNetworkNonISDNPrivate (17),  -- optional parameters
    typeOfNetworkOther       (18),  -- optional parameters
    eventsProvidedParameter   (19),  -- optional parameters
    eventsProvidedBridged     (20),  -- optional parameters
    eventsProvidedCallCleared (21),  -- optional parameters
    eventsProvidedConferenced (22),  -- optional parameters
    eventsProvidedConnectionCleared (23),  -- optional parameters
    eventsProvidedDelivered   (24),  -- optional parameters
    eventsProvidedDigitsDialed (25),  -- optional parameters
    eventsProvidedDiverted    (26),  -- optional parameters
    eventsProvidedEstablished (27),  -- optional parameters
    eventsProvidedFailed      (28),  -- optional parameters
    eventsProvidedHeld        (29),  -- optional parameters
    eventsProvidedNetwCapsChanged (30),  -- optional parameters
    eventsProvidedNetwReached (31),  -- optional parameters
    eventsProvidedOffered     (32),  -- optional parameters
    eventsProvidedOriginated  (33),  -- optional parameters
    eventsProvidedQueued      (34),  -- optional parameters
    eventsProvidedRetrieved   (35),  -- optional parameters
    eventsProvidedServiceInitiated (36),  -- optional parameters
    eventsProvidedTransferred (37),  -- optional parameters
    servicesPermitted         (38),  -- optional parameters
    mediaCallCharacteristics  (39),  -- optional parameters
    callCharacteristics       (40),  -- optional parameters
    outboundConnectionInfo    (41),  -- optional parameters
    privateData               (42)}  -- optional parameters

NetwReached ::= BIT STRING
{
    originatingNIDConnection ( 0),  -- optional parameters
    userData                  ( 1),  -- optional parameters
    typeOfNetworkISDNPublic   ( 2),  -- optional parameters
    typeOfNetworkNonISDNPublic ( 3),  -- optional parameters
    typeOfNetworkISDNPrivate  ( 4),  -- optional parameters
    typeOfNetworkNonISDNPrivate ( 5),  -- optional parameters
    typeOfNetworkOther       ( 6),  -- optional parameters
    eventsProvidedParameter   ( 7),  -- optional parameters
    eventsProvidedBridged     ( 8),  -- optional parameters
    eventsProvidedCallCleared ( 9),  -- optional parameters
    eventsProvidedConferenced (10),  -- optional parameters
    eventsProvidedConnectionCleared (11),  -- optional parameters
    eventsProvidedDelivered   (12),  -- optional parameters
    eventsProvidedDigitsDialed (13),  -- optional parameters
    eventsProvidedDiverted    (14),  -- optional parameters
    eventsProvidedEstablished (15),  -- optional parameters
```

```
eventsProvidedFailed          (16),      -- optional parameters
eventsProvidedHeld            (17),      -- optional parameters
eventsProvidedNetwCapsChanged (18),      -- optional parameters
eventsProvidedNetwReached     (19),      -- optional parameters
eventsProvidedOffered         (20),      -- optional parameters
eventsProvidedOriginated      (21),      -- optional parameters
eventsProvidedQueued          (22),      -- optional parameters
eventsProvidedRetrieved       (23),      -- optional parameters
eventsProvidedServiceInitiated (24),      -- optional parameters
eventsProvidedTransferred     (25),      -- optional parameters
servicesPermitted             (26),      -- optional parameters
mediaCallCharacteristics      (27),      -- optional parameters
callCharacteristics           (28),      -- optional parameters
outboundConnectionInfo       (29),      -- optional parameters
netwCallingDevice             (30),      -- optional parameters
netwCalledDevice              (31),      -- optional parameters
privateData                   (32)}      -- optional parameters

Offered ::= BIT STRING
{
    originatingNIDConnection      ( 0),      -- optional parameters
    userData                      ( 1),      -- optional parameters
    servicesPermitted             ( 2),      -- optional parameters
    netwCallingDevice             ( 3),      -- optional parameters
    netwCalledDevice              ( 4),      -- optional parameters
    mediaCallCharacteristics      ( 5),      -- optional parameters
    callCharacteristics           ( 6),      -- optional parameters
    offeredConnectionInfo         ( 7),      -- optional parameters
    privateData                   ( 8)}      -- optional parameters

Originated ::= BIT STRING
{
    originatingDevice             ( 0),      -- optional parameters
    servicesPermitted             ( 1),      -- optional parameters
    netwCallingDevice             ( 2),      -- optional parameters
    netwCalledDevice              ( 3),      -- optional parameters
    mediaCallCharacteristics      ( 4),      -- optional parameters
    callCharacteristics           ( 5),      -- optional parameters
    originatedConnectionInfo      ( 6),      -- optional parameters
    privateData                   ( 7)}      -- optional parameters

Queued ::= BIT STRING
{
    numberQueued                  ( 0),      -- optional parameters
    callsInFront                  ( 1),      -- optional parameters
    userData                      ( 2),      -- optional parameters
    servicesPermitted             ( 3),      -- optional parameters
    netwCallingDevice             ( 4),      -- optional parameters
    netwCalledDevice              ( 5),      -- optional parameters
    mediaCallCharacteristics      ( 6),      -- optional parameters
    callCharacteristics           ( 7),      -- optional parameters
    queuedConnectionInfo         ( 8),      -- optional parameters
    privateData                   ( 9)}      -- optional parameters

Retrieved ::= BIT STRING
{
    correlatorData                ( 0),      -- optional parameters
    servicesPermitted             ( 1),      -- optional parameters
    mediaCallCharacteristics      ( 2),      -- optional parameters
    callCharacteristics           ( 3),      -- optional parameters
    retrievedConnectionInfo       ( 4),      -- optional parameters
    callLinkageData               ( 6),      -- optional parameters
    privateData                   ( 5)}      -- optional parameters

ServiceInitiated ::= BIT STRING
{
    servicesPermitted             ( 0),      -- optional parameters
    mediaCallCharacteristics      ( 1),      -- optional parameters
    callCharacteristics           ( 2),      -- optional parameters
    initiatedConnectionInfo       ( 3),      -- optional parameters
    netwCallingDevice             ( 4),      -- optional parameters
    netwCalledDevice              ( 5),      -- optional parameters
    privateData                   ( 6)}      -- optional parameters
```

```
Transferred ::= BIT STRING
{
    transferredConnectionsEndpointDeviceID      ( 0),  -- optional parameters
    transferredConnectionsResultingConnectionInfo ( 1),  -- optional parameters
    userData                                    ( 2),  -- optional parameters
    chargingInfo                                ( 3),  -- optional parameters
    numberUnitsNumberOfChargingUnits            ( 4),  -- optional parameters
    numberUnitsTypeOfUnits                      ( 5),  -- optional parameters
    numberUnitsNumberOfCurrencyUnits            ( 6),  -- optional parameters
    typeOfChargingInfoSubTotal                  ( 7),  -- optional parameters
    typeOfChargingInfoTotal                     ( 8),  -- optional parameters
    chargingMultiplierAThousandth              ( 9),  -- optional parameters
    chargingMultiplierAHundredth               (10),  -- optional parameters
    chargingMultiplierATenth                   (11),  -- optional parameters
    chargingMultiplierOne                       (12),  -- optional parameters
    chargingMultiplierTen                      (13),  -- optional parameters
    chargingMultiplierHundred                  (14),  -- optional parameters
    chargingMultiplierThousand                 (15),  -- optional parameters
    servicesPermitted                          (16),  -- optional parameters
    mediaCallCharacteristics                   (17),  -- optional parameters
    callCharacteristics                        (18),  -- optional parameters
    connectionInfo                             (19),  -- optional parameters
    privateData                                (20)}  -- optional parameters

CallAssociatedServList ::= SEQUENCE
{
    associateData          [0] IMPLICIT AssociateData          OPTIONAL,
    cancelTelephonyTones   [1] IMPLICIT CancelTelephonyTones   OPTIONAL,
    generateDigits          [2] IMPLICIT GenerateDigits         OPTIONAL,
    generateTelephonyTones  [3] IMPLICIT GenerateTelephonyTones OPTIONAL,
    sendUserInformation     [4] IMPLICIT SendUserInformation    OPTIONAL}

AssociateData ::= BIT STRING
{
    accountCode      ( 0),  -- optional parameters
    authCode         ( 1),  -- optional parameters
    correlatorData   ( 2),  -- optional parameters
    callQualifyingData ( 3),  -- optional parameters
    privateData      ( 4),  -- optional parameters
    privateDataInAck ( 5),  -- optional parameters
    deviceIDOnly     ( 6),  -- misc characteristics
    rejectsRequestsWithOldConnectionID ( 7),  -- misc characteristics
    ackModelMultiStep ( 8)}  -- misc characteristics

CancelTelephonyTones ::= BIT STRING
{
    privateData      ( 0),  -- optional parameters
    privateDataInAck ( 1),  -- optional parameters
    ackModelMultiStep ( 2)}  -- misc characteristics

GenerateDigits ::= BIT STRING
{
    digitModeDTMF      ( 0),  -- optional parameters
    digitModePulse     ( 1),  -- optional parameters
    toneDuration       ( 2),  -- optional parameters
    pulseRate          ( 3),  -- optional parameters
    pauseDuration      ( 4),  -- optional parameters
    privateData        ( 5),  -- optional parameters
    privateDataInAck   ( 6),  -- optional parameters
    deviceIDOnly       ( 7),  -- misc characteristics
    supportsDTMFTonesABCD ( 8),  -- misc characteristics
    supportsPauseToneChar ( 9),  -- misc characteristics
    ackModelMultiStep  (10)}  -- misc characteristics

GenerateTelephonyTones ::= BIT STRING
{
    toneToSendBeep      ( 0),  -- optional parameters
    toneToSendBilling   ( 1),  -- optional parameters
    toneToSendBusy      ( 2),  -- optional parameters
    toneToSendCarrier    ( 3),  -- optional parameters
    toneToSendConfirmation ( 4),  -- optional parameters
```

toneToSendDial	( 5 ),	-- optional parameters
toneToSendFaxCNG	( 6 ),	-- optional parameters
toneToSendHold	( 7 ),	-- optional parameters
toneToSendHowler	( 8 ),	-- optional parameters
toneToSendIntrusion	( 9 ),	-- optional parameters
toneToSendModemCNG	(10),	-- optional parameters
toneToSendPark	(11),	-- optional parameters
toneToSendRecordWarning	(12),	-- optional parameters
toneToSendReorder	(13),	-- optional parameters
toneToSendRingback	(14),	-- optional parameters
toneToSendSilence	(15),	-- optional parameters
toneToSendSitVC	(16),	-- optional parameters
toneToSendSitIC	(17),	-- optional parameters
toneToSendSitRO	(18),	-- optional parameters
toneToSendSitNC	(19),	-- optional parameters
toneToSendSf0	(20),	-- optional parameters
toneToSendSf1	(21),	-- optional parameters
toneToSendSf2	(22),	-- optional parameters
toneToSendSf3	(23),	-- optional parameters
toneToSendSf4	(24),	-- optional parameters
toneToSendSf5	(25),	-- optional parameters
toneToSendSf6	(26),	-- optional parameters
toneToSendSf7	(27),	-- optional parameters
toneToSendSf8	(28),	-- optional parameters
toneToSendSf9	(29),	-- optional parameters
toneToSendSf10	(30),	-- optional parameters
toneToSendSf11	(31),	-- optional parameters
toneToSendSf12	(32),	-- optional parameters
toneToSendSf13	(33),	-- optional parameters
toneToSendSf14	(34),	-- optional parameters
toneToSendSf15	(35),	-- optional parameters
toneToSendSf16	(36),	-- optional parameters
toneToSendSf17	(37),	-- optional parameters
toneToSendSf18	(38),	-- optional parameters
toneToSendSf19	(39),	-- optional parameters
toneToSendSf20	(40),	-- optional parameters
toneToSendSf21	(41),	-- optional parameters
toneToSendSf22	(42),	-- optional parameters
toneToSendSf23	(43),	-- optional parameters
toneToSendSf24	(44),	-- optional parameters
toneToSendSf25	(45),	-- optional parameters
toneToSendSf26	(46),	-- optional parameters
toneToSendSf27	(47),	-- optional parameters
toneToSendSf28	(48),	-- optional parameters
toneToSendSf29	(49),	-- optional parameters
toneToSendSf30	(50),	-- optional parameters
toneToSendSf31	(51),	-- optional parameters
toneToSendSf32	(52),	-- optional parameters
toneToSendSf33	(53),	-- optional parameters
toneToSendSf34	(54),	-- optional parameters
toneToSendSf35	(55),	-- optional parameters
toneToSendSf36	(56),	-- optional parameters
toneToSendSf37	(57),	-- optional parameters
toneToSendSf38	(58),	-- optional parameters
toneToSendSf39	(59),	-- optional parameters
toneToSendSf40	(60),	-- optional parameters
toneToSendSf41	(61),	-- optional parameters
toneToSendSf42	(62),	-- optional parameters
toneToSendSf43	(63),	-- optional parameters
toneToSendSf44	(64),	-- optional parameters
toneToSendSf45	(65),	-- optional parameters
toneToSendSf46	(66),	-- optional parameters
toneToSendSf47	(67),	-- optional parameters
toneToSendSf48	(68),	-- optional parameters
toneToSendSf49	(69),	-- optional parameters
toneToSendSf50	(70),	-- optional parameters
toneToSendSf51	(71),	-- optional parameters
toneToSendSf52	(72),	-- optional parameters

```
toneToSendSf53      (73),  -- optional parameters
toneToSendSf54      (74),  -- optional parameters
toneToSendSf55      (75),  -- optional parameters
toneToSendSf56      (76),  -- optional parameters
toneToSendSf57      (77),  -- optional parameters
toneToSendSf58      (78),  -- optional parameters
toneToSendSf59      (79),  -- optional parameters
toneToSendSf60      (80),  -- optional parameters
toneToSendSf61      (81),  -- optional parameters
toneToSendSf62      (82),  -- optional parameters
toneToSendSf63      (83),  -- optional parameters
toneToSendSf64      (84),  -- optional parameters
toneToSendSf65      (85),  -- optional parameters
toneToSendSf66      (86),  -- optional parameters
toneToSendSf67      (87),  -- optional parameters
toneToSendSf68      (88),  -- optional parameters
toneToSendSf69      (89),  -- optional parameters
toneToSendSf70      (90),  -- optional parameters
toneToSendSf71      (91),  -- optional parameters
toneToSendSf72      (92),  -- optional parameters
toneToSendSf73      (93),  -- optional parameters
toneToSendSf74      (94),  -- optional parameters
toneToSendSf75      (95),  -- optional parameters
toneToSendSf76      (96),  -- optional parameters
toneToSendSf77      (97),  -- optional parameters
toneToSendSf78      (98),  -- optional parameters
toneToSendSf79      (99),  -- optional parameters
toneToSendSf80      (100), -- optional parameters
toneToSendSf81      (101), -- optional parameters
toneToSendSf82      (102), -- optional parameters
toneToSendSf83      (103), -- optional parameters
toneToSendSf84      (104), -- optional parameters
toneToSendSf85      (105), -- optional parameters
toneToSendSf86      (106), -- optional parameters
toneToSendSf87      (107), -- optional parameters
toneToSendSf88      (108), -- optional parameters
toneToSendSf89      (109), -- optional parameters
toneToSendSf90      (110), -- optional parameters
toneToSendSf91      (111), -- optional parameters
toneToSendSf92      (112), -- optional parameters
toneToSendSf93      (113), -- optional parameters
toneToSendSf94      (114), -- optional parameters
toneToSendSf95      (115), -- optional parameters
toneToSendSf96      (116), -- optional parameters
toneToSendSf97      (117), -- optional parameters
toneToSendSf98      (118), -- optional parameters
toneToSendSf99      (119), -- optional parameters
toneToSendSf100     (120), -- optional parameters
toneDuration        (121), -- optional parameters
privateData          (122), -- optional parameters
privateDataInAck     (123), -- optional parameters
deviceIDOnly         (124), -- misc characteristics
ackModelMultiStep    (125)} -- misc characteristics

SendUserInformation ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck     ( 1),  -- optional parameters
    deviceIDOnly         ( 2),  -- misc characteristics
    ackModelMultiStep    ( 3)}  -- misc characteristics

CallAssociatedEvtsList ::= SEQUENCE
{
    callInformation      [0] IMPLICIT CallInformation      OPTIONAL,
    charging             [1] IMPLICIT Charging             OPTIONAL,
    digitsGenerated      [2] IMPLICIT DigitsGenerated      OPTIONAL,
    telephonyTonesGenerated [3] IMPLICIT TelephonyTonesGenerated OPTIONAL,
    serviceCompletionFailure [4] IMPLICIT ServiceCompletionFailure OPTIONAL}

CallInformation ::= BIT STRING
```



```
{      callingDevice      ( 0),  -- optional parameters
      accountInfo         ( 1),  -- optional parameters
      authorisatinonCode  ( 2),  -- optional parameters
      correlatorData      ( 3),  -- optional parameters
      servicesPermitted   ( 4),  -- optional parameters
      userData            ( 5),  -- optional parameters
      callQualifyingData  ( 6),  -- optional parameters
      connectionInfo      ( 7),  -- optional parameters
      callLinkageData     (10),  -- optional parameters
      privateData         ( 8),  -- optional parameters
      genCallInfoForOutdatedConnID ( 9)} -- misc characteristics

Charging ::= BIT STRING
{      numberUnitsNumberOfChargingUnits ( 0),  -- optional parameters
      numberUnitsTypeOfUnits            ( 1),  -- optional parameters
      numberUnitsNumberOfCurrencyUnits  ( 2),  -- optional parameters
      typeOfChargingInfoSubTotal        ( 3),  -- optional parameters
      typeOfChargingInfoTotal           ( 4),  -- optional parameters
      chargingMultiplierATHousandth    ( 5),  -- optional parameters
      chargingMultiplierAHundredth     ( 6),  -- optional parameters
      chargingMultiplierATenth          ( 7),  -- optional parameters
      chargingMultiplierOne             ( 8),  -- optional parameters
      chargingMultiplierTen             ( 9),  -- optional parameters
      chargingMultiplierHundred        (10),  -- optional parameters
      chargingMultiplierThousand       (11),  -- optional parameters
      privateData                      (12)} -- optional parameters

DigitsGenerated ::= BIT STRING
{      digitsDurationList ( 0),  -- optional parameters
      pauseDurationList   ( 1),  -- optional parameters
      connectionInfo      ( 2),  -- optional parameters
      privateData         ( 3)} -- optional parameters

TelephonyTonesGenerated ::= BIT STRING
{      toneToSendBeep      ( 0),  -- optional parameters
      toneToSendBilling    ( 1),  -- optional parameters
      toneToSendBusy       ( 2),  -- optional parameters
      toneToSendCarrier    ( 3),  -- optional parameters
      toneToSendConfirmation ( 4),  -- optional parameters
      toneToSendDial       ( 5),  -- optional parameters
      toneToSendFaxCNG     ( 6),  -- optional parameters
      toneToSendHold       ( 7),  -- optional parameters
      toneToSendHowler     ( 8),  -- optional parameters
      toneToSendIntrusion  ( 9),  -- optional parameters
      toneToSendModemCNG   (10),  -- optional parameters
      toneToSendPark       (11),  -- optional parameters
      toneToSendRecordWarning (12),  -- optional parameters
      toneToSendReorder    (13),  -- optional parameters
      toneToSendRingback   (14),  -- optional parameters
      toneToSendSilence    (15),  -- optional parameters
      toneToSendSitVC      (16),  -- optional parameters
      toneToSendSitIC      (17),  -- optional parameters
      toneToSendSitRO      (18),  -- optional parameters
      toneToSendSitNC      (19),  -- optional parameters
      toneToSendSf0        (20),  -- optional parameters
      toneToSendSf1        (21),  -- optional parameters
      toneToSendSf2        (22),  -- optional parameters
      toneToSendSf3        (23),  -- optional parameters
      toneToSendSf4        (24),  -- optional parameters
      toneToSendSf5        (25),  -- optional parameters
      toneToSendSf6        (26),  -- optional parameters
      toneToSendSf7        (27),  -- optional parameters
      toneToSendSf8        (28),  -- optional parameters
      toneToSendSf9        (29),  -- optional parameters
      toneToSendSf10       (30),  -- optional parameters
      toneToSendSf11       (31),  -- optional parameters
      toneToSendSf12       (32),  -- optional parameters
      toneToSendSf13       (33),  -- optional parameters
```

[illegible]

```

toneToSendSf82                (102), -- optional parameters
toneToSendSf83                (103), -- optional parameters
toneToSendSf84                (104), -- optional parameters
toneToSendSf85                (105), -- optional parameters
toneToSendSf86                (106), -- optional parameters
toneToSendSf87                (107), -- optional parameters
toneToSendSf88                (108), -- optional parameters
toneToSendSf89                (109), -- optional parameters
toneToSendSf90                (110), -- optional parameters
toneToSendSf91                (111), -- optional parameters
toneToSendSf92                (112), -- optional parameters
toneToSendSf93                (113), -- optional parameters
toneToSendSf94                (114), -- optional parameters
toneToSendSf95                (115), -- optional parameters
toneToSendSf96                (116), -- optional parameters
toneToSendSf97                (117), -- optional parameters
toneToSendSf98                (118), -- optional parameters
toneToSendSf99                (119), -- optional parameters
toneToSendSf100               (120), -- optional parameters
toneFrequency                  (121), -- optional parameters
toneDuration                   (122), -- optional parameters
pauseDurationList              (123), -- optional parameters
connectionInfo                 (124), -- optional parameters
privateData                    (125)} -- optional parameters

ServiceCompletionFailure ::= BIT STRING
{
    primaryCallConnectionInfo      ( 0), -- optional parameters
    secondaryCallConnectionInfo    ( 1), -- optional parameters
    otherDevicesPrimaryCallList    ( 2), -- optional parameters
    otherDevicesSecondaryCallList  ( 3), -- optional parameters
    mediaCallCharacteristics       ( 4), -- optional parameters
    privateData                    ( 5)} -- optional parameters

MediaServList ::= SEQUENCE
{
    attachMediaService      [0] IMPLICIT AttachMediaService      OPTIONAL,
    detachMediaService      [1] IMPLICIT DetachMediaService      OPTIONAL}

AttachMediaService ::= BIT STRING
{
    mediaServiceVersion          ( 0), -- optional parameters
    mediaServiceInstanceID       ( 1), -- optional parameters
    connectionModeConsultConference ( 2), -- optional parameters
    connectionModeConsultConferenceHold ( 3), -- optional parameters
    connectionModeDeflect        ( 4), -- optional parameters
    connectionModeDirectedPickup ( 5), -- optional parameters
    connectionModeJoin           ( 6), -- optional parameters
    connectionModeSingleStepConference ( 7), -- optional parameters
    connectionModeSingleStepConferenceHold ( 8), -- optional parameters
    connectionModeSingleStepTransfer ( 9), -- optional parameters
    connectionModeTransfer       (10), -- optional parameters
    connectionModeDirect         (11), -- optional parameters
    requestedConnectionState      (12), -- optional parameters
    privateData                   (13), -- optional parameters
    mediaServiceInstanceIDInAck   (14), -- optional parameters
    mediaConnectionInfoInAck      (15), -- optional parameters
    privateDataInAck              (16), -- optional parameters
    deviceIDOnly                  (17), -- misc characteristics
    ackModelMultiStep             (18)} -- misc characteristics

DetachMediaService ::= BIT STRING
{
    alerting                    ( 0), -- initial states
    connected                   ( 1), -- initial states
    fail                        ( 2), -- initial states
    hold                        ( 3), -- initial states
    queued                      ( 4), -- initial states
    privateData                 ( 5), -- optional parameters
    privateDataInAck            ( 6), -- optional parameters
    deviceIDOnly                ( 7), -- misc characteristics
    ackModelMultiStep           ( 8)} -- misc characteristics

```

```
MediaEvtsList ::= SEQUENCE
{
    mediaAttached    [0] IMPLICIT    MediaAttached    OPTIONAL,
    mediaDetached    [1] IMPLICIT    MediaDetached    OPTIONAL}

MediaAttached    ::= BIT STRING
{
    mediaServiceVersion    ( 0),    -- optional parameters
    mediaServiceInstanceID ( 1),    -- optional parameters
    mediaStreamID          ( 2),    -- optional parameters
    mediaCallCharacteristics ( 3),    -- optional parameters
    callCharacteristics     ( 4),    -- optional parameters
    mediaConnectionInfo    ( 5),    -- optional parameters
    privateData            ( 6)}    -- optional parameters

MediaDetached    ::= BIT STRING
{
    mediaServiceVersion    ( 0),    -- optional parameters
    mediaServiceInstanceID ( 1),    -- optional parameters
    mediaStreamID          ( 2),    -- optional parameters
    mediaCallCharacteristics ( 3),    -- optional parameters
    callCharacteristics     ( 4),    -- optional parameters
    mediaConnectionInfo    ( 5),    -- optional parameters
    privateData            ( 6)}    -- optional parameters

RouteingServList ::= SEQUENCE
{
    routeRegister    [ 0] IMPLICIT RouteRegister    OPTIONAL,
    routeRegisterCancel [ 1] IMPLICIT RouteRegisterCancel    OPTIONAL,
    routeRegisterAbort [ 2] IMPLICIT RouteRegisterAbort    OPTIONAL,
    reRoute          [ 3] IMPLICIT ReRoute          OPTIONAL,
    routeEnd          [ 4] IMPLICIT RouteEnd          OPTIONAL,
    routeReject       [ 5] IMPLICIT RouteReject       OPTIONAL,
    routeRequest       [ 6] IMPLICIT RouteRequest      OPTIONAL,
    routeSelect        [ 7] IMPLICIT RouteSelect      OPTIONAL,
    routeUsed          [ 8] IMPLICIT RouteUsed        OPTIONAL}

RouteRegister ::= BIT STRING
{
    routeingDevice    ( 0),    -- optional parameters
    requestedMonitorMediaClass ( 1),    -- optional parameters
    requestedMonitorMediaClassAudio ( 2),    -- optional parameters
    requestedMonitorMediaClassData ( 3),    -- optional parameters
    requestedMonitorMediaClassImage ( 4),    -- optional parameters
    requestedMonitorMediaClassVoice ( 5),    -- optional parameters
    privateData        ( 6),    -- optional parameters
    actualRouteingMediaClassInAck ( 7),    -- optional parameters
    privateDataInAck    ( 8),    -- optional parameters
    allRouteingDevices  ( 9)}    -- misc characteristics

RouteRegisterAbort ::= BIT STRING
{
    privateData    ( 0)}    -- optional parameters

RouteRegisterCancel ::= BIT STRING
{
    privateData    ( 0),    -- optional parameters
    privateDataInAck ( 1)}    -- optional parameters

ReRoute ::= BIT STRING
{
    replyTimeout    ( 1),    -- optional parameters
    correlatorData   ( 2),    -- optional parameters
    privateData      ( 3)}    -- optional parameters

RouteEnd ::= BIT STRING
{
    errorValue    ( 1),    -- optional parameters
    correlatorData ( 2),    -- optional parameters
    privateData    ( 3),    -- optional parameters
    supportsSending ( 4),    -- misc characteristics
    supportsReceiving ( 5)}    -- misc characteristics

RouteReject ::= BIT STRING
{
    rejectCauseBusyOverflow ( 0),    -- optional parameters
    rejectCauseQueueTimeOverflow ( 1),    -- optional parameters
```

```
rejectCauseCapacityOverflow      ( 2),  -- optional parameters
rejectCauseCalendarOverflow      ( 3),  -- optional parameters
rejectCauseUnknownOverflow      ( 4),  -- optional parameters
correlatorData                  ( 5),  -- optional parameters
privateData                     ( 6)}  -- optional parameters

RouteRequest ::= BIT STRING
{
    callingDevice                ( 0),  -- optional parameters
    calledDevice                 ( 1),  -- optional parameters
    routeSelAlgorithmACD         ( 2),  -- optional parameters
    routeSelAlgorithmEmergency   ( 3),  -- optional parameters
    routeSelAlgorithmLeastCost   ( 4),  -- optional parameters
    routeSelAlgorithmNormal      ( 5),  -- optional parameters
    routeSelAlgorithmUserDefined ( 6),  -- optional parameters
    priority                     ( 7),  -- optional parameters
    replyTimeout                 ( 8),  -- optional parameters
    correlatorData               ( 9),  -- optional parameters
    mediaCallCharacteristics     (10),  -- optional parameters
    callCharacteristics          (11),  -- optional parameters
    routedCallInfo               (12),  -- optional parameters
    privateData                  (13),  -- optional parameters
    nonCallRelatedRouteing      (14)}  -- misc characteristics

RouteSelect ::= BIT STRING
{
    alternateRoutes              ( 0),  -- optional parameters
    remainRetriesNoListAvailable ( 1),  -- optional parameters
    remainRetriesNoCountAvailable ( 2),  -- optional parameters
    remainRetriesRetryCount      ( 3),  -- optional parameters
    routeUsed                    ( 4),  -- optional parameters
    correlatorData               ( 5),  -- optional parameters
    privateData                  ( 6)}  -- optional parameters

RouteUsed ::= BIT STRING
{
    callingDevice                ( 0),  -- optional parameters
    domain                      ( 1),  -- optional parameters
    correlatorData               ( 2),  -- optional parameters
    privateData                  ( 3)}  -- optional parameters

PhysDevServList ::= SEQUENCE
{
    buttonPress                  [ 0] IMPLICIT ButtonPress          OPTIONAL,
    getAuditoryApparatusInfo     [ 1] IMPLICIT GetAuditoryApparatusInfo OPTIONAL,
    getButtonInformation         [ 2] IMPLICIT GetButtonInformation  OPTIONAL,
    getDisplay                   [ 3] IMPLICIT GetDisplay            OPTIONAL,
    getHookSwitchStatus          [ 4] IMPLICIT GetHookSwitchStatus  OPTIONAL,
    getLampInfo                  [ 5] IMPLICIT GetLampInfo           OPTIONAL,
    getLampMode                  [ 6] IMPLICIT GetLampMode           OPTIONAL,
    getMessageWaitingIndicator    [ 7] IMPLICIT GetMessageWaitingIndicator OPTIONAL,
    getMicrophoneGain            [ 8] IMPLICIT GetMicrophoneGain     OPTIONAL,
    getMicrophoneMute            [ 9] IMPLICIT GetMicrophoneMute     OPTIONAL,
    getRingerStatus              [10] IMPLICIT GetRingerStatus       OPTIONAL,
    getSpeakerMute               [11] IMPLICIT GetSpeakerMute        OPTIONAL,
    getSpeakerVolume             [12] IMPLICIT GetSpeakerVolume      OPTIONAL,
    setButtonInformation         [13] IMPLICIT SetButtonInformation  OPTIONAL,
    setDisplay                   [14] IMPLICIT SetDisplay            OPTIONAL,
    setHookSwitchStatus          [15] IMPLICIT SetHookSwitchStatus  OPTIONAL,
    setLampMode                  [16] IMPLICIT SetLampMode           OPTIONAL,
    setMessageWaitingIndicator    [17] IMPLICIT SetMessageWaitingIndicator OPTIONAL,
    setMicrophoneGain            [18] IMPLICIT SetMicrophoneGain     OPTIONAL,
    setMicrophoneMute            [19] IMPLICIT SetMicrophoneMute     OPTIONAL,
    setRingerStatus              [20] IMPLICIT SetRingerStatus       OPTIONAL,
    setSpeakerMute               [21] IMPLICIT SetSpeakerMute        OPTIONAL,
    setSpeakerVolume             [22] IMPLICIT SetSpeakerVolume      OPTIONAL}

ButtonPress ::= BIT STRING
{
    privateData                  ( 0),  -- optional parameters
    privateDataInAck             ( 1),  -- optional parameters
    ackModelMultiStep            ( 2)}  -- misc characteristics
```

```
GetAuditoryApparatusInfo ::= BIT STRING
{
    auditoryApparatus          ( 0), -- optional parameters
    privateData                ( 1), -- optional parameters
    auditoryApparatusTypeSpeakerphone ( 2), -- optional parameters
    auditoryApparatusTypeHandset   ( 3), -- optional parameters
    auditoryApparatusTypeHeadset   ( 4), -- optional parameters
    auditoryApparatusTypeSpeakerOnlyPhone ( 5), -- optional parameters
    auditoryApparatusTypeeothers   ( 6), -- optional parameters
    speakerPresent              ( 7), -- optional parameters
    speakerVolumeSettable        ( 8), -- optional parameters
    speakerVolumeReadable        ( 9), -- optional parameters
    speakerMuteSettable          (10), -- optional parameters
    speakerMuteReadable          (11), -- optional parameters
    microphonePresent            (12), -- optional parameters
    microphoneGainSettable       (13), -- optional parameters
    microphoneGainReadable       (14), -- optional parameters
    microphoneMuteSettable       (15), -- optional parameters
    microphoneMuteReadable       (16), -- optional parameters
    hookswitchSettable           (17), -- optional parameters
    hookswitchOnHook             (18), -- optional parameters
    privateDataInAck             (19)} -- optional parameters

GetButtonInformation ::= BIT STRING
{
    button                      ( 0), -- optional parameters
    privateData                 ( 1), -- optional parameters
    buttonLabelInAck            ( 2), -- optional parameters
    buttonLabelSettableInAck    ( 3), -- optional parameters
    buttonFunctionInAck         ( 4), -- optional parameters
    buttonAssociatedNumberInAck ( 5), -- optional parameters
    buttonAssociatedNumberSettableInAck ( 6), -- optional parameters
    listOfLampsInAck           ( 7), -- optional parameters
    privateDataInAck            ( 8)} -- optional parameters

GetDisplay ::= BIT STRING
{
    displayID                   ( 0), -- optional parameters
    privateData                 ( 1), -- optional parameters
    characterSetASCII           ( 2), -- optional parameters
    characterSetUnicode         ( 3), -- optional parameters
    characterSetProprietary     ( 4), -- optional parameters
    privateDataInAck            ( 5)} -- optional parameters

GetHookSwitchStatus ::= BIT STRING
{
    hookSwitch                  ( 0), -- optional parameters
    privateData                 ( 1), -- optional parameters
    privateDataInAck            ( 2)} -- optional parameters

GetLampInfo ::= BIT STRING
{
    lamp                        ( 0), -- optional parameters
    privateData                 ( 1), -- optional parameters
    lampLabelInAck              ( 2), -- optional parameters
    buttonInAck                 ( 3), -- optional parameters
    lampColorInAck              ( 4), -- optional parameters
    privateDataInAck            ( 5)} -- optional parameters

GetLampMode ::= BIT STRING
{
    lamp                        ( 0), -- optional parameters
    privateData                 ( 1), -- optional parameters
    lampModeInAck               ( 2), -- optional parameters
    lampBrightnessNormal        ( 3), -- optional parameters
    lampBrightnessDim           ( 4), -- optional parameters
    lampBrightnessBright        ( 5), -- optional parameters
    lampColorInAck              ( 6), -- optional parameters
    buttonInAck                 ( 7), -- optional parameters
    privateDataInAck            ( 8)} -- optional parameters

GetMessageWaitingIndicator ::= BIT STRING
{
    privateData                 ( 0), -- optional parameter
    deviceForMsgInAck           ( 1), -- optional parameter
```

```
    lampIsPresentInAck      ( 2),    -- optional parameter
    privateDataInAck        ( 3)}    -- optional parameters

GetMicrophoneGain ::= BIT STRING
{
    auditoryApparatus      ( 0),    -- optional parameters
    privateData            ( 1),    -- optional parameters
    micGainAbsInAck        ( 2),    -- optional parameters
    privateDataInAck        ( 3)}    -- optional parameters

GetMicrophoneMute ::= BIT STRING
{
    auditoryApparatus      ( 0),    -- optional parameters
    privateData            ( 1),    -- optional parameters
    privateDataInAck        ( 2)}    -- optional parameters

GetRingerStatus ::= BIT STRING
{
    ringer                  ( 0),    -- optional parameters
    privateData            ( 1),    -- optional parameters
    ringCountInAck          ( 2),    -- optional parameters
    ringPatternInAck        ( 3),    -- optional parameters
    ringVolumeInAck         ( 4),    -- optional parameters
    ringVolumeAbsInAck      ( 5),    -- optional parameters
    privateDataInAck        ( 6)}    -- optional parameters

GetSpeakerMute ::= BIT STRING
{
    auditoryApparatus      ( 0),    -- optional parameters
    privateDataInAck        ( 1),    -- optional parameters
    privateData            ( 2)}    -- optional parameters

GetSpeakerVolume ::= BIT STRING
{
    auditoryApparatus      ( 0),    -- optional parameters
    privateData            ( 1),    -- optional parameters
    speakerVolAbsInAck      ( 2),    -- optional parameters
    privateDataInAck        ( 3)}    -- optional parameters

SetButtonInformation ::= BIT STRING
{
    buttonLabel              ( 0),    -- optional parameters
    buttonAssociatedNumber    ( 1),    -- optional parameters
    privateData              ( 2),    -- optional parameters
    privateDataInAck          ( 3),    -- optional parameters
    ackModelMultiStep         ( 4)}    -- misc characteristics

SetDisplay ::= BIT STRING
{
    physBaseRowNumber        ( 0),    -- optional parameters
    physColumnRowNumber      ( 1),    -- optional parameters
    offset                    ( 2),    -- optional parameters
    privateData              ( 3),    -- optional parameters
    privateDataInAck          ( 4),    -- optional parameters
    supportsModifyingPosition ( 5),    -- misc characteristics
    ackModelMultiStep         ( 6)}    -- misc characteristics

SetHookSwitchStatus ::= BIT STRING
{
    privateData              ( 0),    -- optional parameters
    ackModelMultiStep         ( 1)}    -- misc characteristics

SetLampMode ::= BIT STRING
{
    lampModeBrokenFlutter    ( 0),    -- optional parameter
    lampModeFlutter          ( 1),    -- optional parameter
    lampModeOff              ( 2),    -- optional parameter
    lampModeSteady           ( 3),    -- optional parameter
    lampModeWink             ( 4),    -- optional parameter
    lampModeReserved         ( 5),    -- optional parameter
    lampModeSf0              ( 6),    -- optional parameters
    lampModeSf1              ( 7),    -- optional parameters
    lampModeSf2              ( 8),    -- optional parameters
    lampModeSf3              ( 9),    -- optional parameters
    lampModeSf4              (10),    -- optional parameters
    lampModeSf5              (11),    -- optional parameters
    lampModeSf6              (12),    -- optional parameters
```

lampModeSf7	(13),	-- optional parameters
lampModeSf8	(14),	-- optional parameters
lampModeSf9	(15),	-- optional parameters
lampModeSf10	(16),	-- optional parameters
lampModeSf11	(17),	-- optional parameters
lampModeSf12	(18),	-- optional parameters
lampModeSf13	(19),	-- optional parameters
lampModeSf14	(20),	-- optional parameters
lampModeSf15	(21),	-- optional parameters
lampModeSf16	(22),	-- optional parameters
lampModeSf17	(23),	-- optional parameters
lampModeSf18	(24),	-- optional parameters
lampModeSf19	(25),	-- optional parameters
lampModeSf20	(26),	-- optional parameters
lampModeSf21	(27),	-- optional parameters
lampModeSf22	(28),	-- optional parameters
lampModeSf23	(29),	-- optional parameters
lampModeSf24	(30),	-- optional parameters
lampModeSf25	(31),	-- optional parameters
lampModeSf26	(32),	-- optional parameters
lampModeSf27	(33),	-- optional parameters
lampModeSf28	(34),	-- optional parameters
lampModeSf29	(35),	-- optional parameters
lampModeSf30	(36),	-- optional parameters
lampModeSf31	(37),	-- optional parameters
lampModeSf32	(38),	-- optional parameters
lampModeSf33	(39),	-- optional parameters
lampModeSf34	(40),	-- optional parameters
lampModeSf35	(41),	-- optional parameters
lampModeSf36	(42),	-- optional parameters
lampModeSf37	(43),	-- optional parameters
lampModeSf38	(44),	-- optional parameters
lampModeSf39	(45),	-- optional parameters
lampModeSf40	(46),	-- optional parameters
lampModeSf41	(47),	-- optional parameters
lampModeSf42	(48),	-- optional parameters
lampModeSf43	(49),	-- optional parameters
lampModeSf44	(50),	-- optional parameters
lampModeSf45	(51),	-- optional parameters
lampModeSf46	(52),	-- optional parameters
lampModeSf47	(53),	-- optional parameters
lampModeSf48	(54),	-- optional parameters
lampModeSf49	(55),	-- optional parameters
lampModeSf50	(56),	-- optional parameters
lampModeSf51	(57),	-- optional parameters
lampModeSf52	(58),	-- optional parameters
lampModeSf53	(59),	-- optional parameters
lampModeSf54	(60),	-- optional parameters
lampModeSf55	(61),	-- optional parameters
lampModeSf56	(62),	-- optional parameters
lampModeSf57	(63),	-- optional parameters
lampModeSf58	(64),	-- optional parameters
lampModeSf59	(65),	-- optional parameters
lampModeSf60	(66),	-- optional parameters
lampModeSf61	(67),	-- optional parameters
lampModeSf62	(68),	-- optional parameters
lampModeSf63	(69),	-- optional parameters
lampModeSf64	(70),	-- optional parameters
lampModeSf65	(71),	-- optional parameters
lampModeSf66	(72),	-- optional parameters
lampModeSf67	(73),	-- optional parameters
lampModeSf68	(74),	-- optional parameters
lampModeSf69	(75),	-- optional parameters
lampModeSf70	(76),	-- optional parameters
lampModeSf71	(77),	-- optional parameters
lampModeSf72	(78),	-- optional parameters
lampModeSf73	(79),	-- optional parameters
lampModeSf74	(80),	-- optional parameters



lampModeSf75	(81),	-- optional parameters
lampModeSf76	(82),	-- optional parameters
lampModeSf77	(83),	-- optional parameters
lampModeSf78	(84),	-- optional parameters
lampModeSf79	(85),	-- optional parameters
lampModeSf80	(86),	-- optional parameters
lampModeSf81	(87),	-- optional parameters
lampModeSf82	(88),	-- optional parameters
lampModeSf83	(89),	-- optional parameters
lampModeSf84	(90),	-- optional parameters
lampModeSf85	(91),	-- optional parameters
lampModeSf86	(92),	-- optional parameters
lampModeSf87	(93),	-- optional parameters
lampModeSf88	(94),	-- optional parameters
lampModeSf89	(95),	-- optional parameters
lampModeSf90	(96),	-- optional parameters
lampModeSf91	(97),	-- optional parameters
lampModeSf92	(98),	-- optional parameters
lampModeSf93	(99),	-- optional parameters
lampModeSf94	(100),	-- optional parameter
lampBrightnessNormal	(101),	-- optional parameter
lampBrightnessDim	(102),	-- optional parameter
lampBrightnessBright	(103),	-- optional parameter
lampColorNoColor	(104),	-- optional parameter
lampColorRed	(105),	-- optional parameter
lampColorYellow	(106),	-- optional parameter
lampColorGreen	(107),	-- optional parameter
lampColorBlue	(108),	-- optional parameter
lampColorReserved	(109),	-- optional parameter
lampColorSf0	(110),	-- optional parameters
lampColorSf1	(111),	-- optional parameters
lampColorSf2	(112),	-- optional parameters
lampColorSf3	(113),	-- optional parameters
lampColorSf4	(114),	-- optional parameters
lampColorSf5	(115),	-- optional parameters
lampColorSf6	(116),	-- optional parameters
lampColorSf7	(117),	-- optional parameters
lampColorSf8	(118),	-- optional parameters
lampColorSf9	(119),	-- optional parameters
lampColorSf10	(120),	-- optional parameters
lampColorSf11	(121),	-- optional parameters
lampColorSf12	(122),	-- optional parameters
lampColorSf13	(123),	-- optional parameters
lampColorSf14	(124),	-- optional parameters
lampColorSf15	(125),	-- optional parameters
lampColorSf16	(126),	-- optional parameters
lampColorSf17	(127),	-- optional parameters
lampColorSf18	(128),	-- optional parameters
lampColorSf19	(129),	-- optional parameters
lampColorSf20	(130),	-- optional parameters
lampColorSf21	(131),	-- optional parameters
lampColorSf22	(132),	-- optional parameters
lampColorSf23	(133),	-- optional parameters
lampColorSf24	(134),	-- optional parameters
lampColorSf25	(135),	-- optional parameters
lampColorSf26	(136),	-- optional parameters
lampColorSf27	(137),	-- optional parameters
lampColorSf28	(138),	-- optional parameters
lampColorSf29	(139),	-- optional parameters
lampColorSf30	(140),	-- optional parameters
lampColorSf31	(141),	-- optional parameters
lampColorSf32	(142),	-- optional parameters
lampColorSf33	(143),	-- optional parameters
lampColorSf34	(144),	-- optional parameters
lampColorSf35	(145),	-- optional parameters
lampColorSf36	(146),	-- optional parameters
lampColorSf37	(147),	-- optional parameters
lampColorSf38	(148),	-- optional parameters

```
lampColorSf39      (149), -- optional parameters
lampColorSf40      (150), -- optional parameters
lampColorSf41      (151), -- optional parameters
lampColorSf42      (152), -- optional parameters
lampColorSf43      (153), -- optional parameters
lampColorSf44      (154), -- optional parameters
lampColorSf45      (155), -- optional parameters
lampColorSf46      (156), -- optional parameters
lampColorSf47      (157), -- optional parameters
lampColorSf48      (158), -- optional parameters
lampColorSf49      (159), -- optional parameters
lampColorSf50      (160), -- optional parameters
lampColorSf51      (161), -- optional parameters
lampColorSf52      (162), -- optional parameters
lampColorSf53      (163), -- optional parameters
lampColorSf54      (164), -- optional parameters
lampColorSf55      (165), -- optional parameters
lampColorSf56      (166), -- optional parameters
lampColorSf57      (167), -- optional parameters
lampColorSf58      (168), -- optional parameters
lampColorSf59      (169), -- optional parameters
lampColorSf60      (170), -- optional parameters
lampColorSf61      (171), -- optional parameters
lampColorSf62      (172), -- optional parameters
lampColorSf63      (173), -- optional parameters
lampColorSf64      (174), -- optional parameters
lampColorSf65      (175), -- optional parameters
lampColorSf66      (176), -- optional parameters
lampColorSf67      (177), -- optional parameters
lampColorSf68      (178), -- optional parameters
lampColorSf69      (179), -- optional parameters
lampColorSf70      (180), -- optional parameters
lampColorSf71      (181), -- optional parameters
lampColorSf72      (182), -- optional parameters
lampColorSf73      (183), -- optional parameters
lampColorSf74      (184), -- optional parameters
lampColorSf75      (185), -- optional parameters
lampColorSf76      (186), -- optional parameters
lampColorSf77      (187), -- optional parameters
lampColorSf78      (188), -- optional parameters
lampColorSf79      (189), -- optional parameters
lampColorSf80      (190), -- optional parameters
lampColorSf81      (191), -- optional parameters
lampColorSf82      (192), -- optional parameters
lampColorSf83      (193), -- optional parameters
lampColorSf84      (194), -- optional parameters
lampColorSf85      (195), -- optional parameters
lampColorSf86      (196), -- optional parameters
lampColorSf87      (197), -- optional parameters
lampColorSf88      (198), -- optional parameters
lampColorSf89      (199), -- optional parameters
lampColorSf90      (200), -- optional parameters
lampColorSf91      (201), -- optional parameters
lampColorSf92      (202), -- optional parameters
lampColorSf93      (203), -- optional parameters
lampColorSf94      (204), -- optional parameters
privateData        (205), -- optional parameters
privateDataInAck   (206), -- optional parameters
ackModelMultiStep  (207)} -- misc characteristics

SetMessageWaitingIndicator ::= BIT STRING
{
    deviceForMsg      ( 0), -- optional parameters
    privateData       ( 1), -- optional parameters
    privateDataInAck  ( 2), -- optional parameters
    ackModelMultiStep ( 3)} -- misc characteristics

SetMicrophoneGain ::= BIT STRING
{
    microphoneGainAbs (0), -- optional parameters
```

```

        microphoneGainInc          (1),    -- optional parameters
        privateData                (2),    -- optional parameters
        privateDataInAck           (3),    -- optional parameters
        ackModelMultiStep          (4)}    -- misc characteristics

SetMicrophoneMute ::= BIT STRING
{
    privateData                ( 0),    -- optional parameters
    privateDataInAck           ( 1),    -- optional parameters
    ackModelMultiStep          ( 2)}    -- misc characteristics

SetRingerStatus ::= BIT STRING
{
    ringerModeRinging          ( 0),    -- optional parameters
    ringerModeNotRinging       ( 1),    -- optional parameters
    ringVolumeAbs              ( 2),    -- optional parameters
    ringVolumeInc              ( 3),    -- optional parameters
    privateData                ( 4),    -- optional parameters
    privateDataInAck           ( 5),    -- optional parameters
    ackModelMultiStep          ( 6)}    -- misc characteristics

SetSpeakerMute ::= BIT STRING
{
    privateData                ( 0),    -- optional parameters
    privateDataInAck           ( 1),    -- optional parameters
    ackModelMultiStep          ( 2)}    -- misc characteristics

SetSpeakerVolume ::= BIT STRING
{
    speakerVolumeAbs           ( 0),    -- optional parameters
    speakerVolumeInc           ( 1),    -- optional parameters
    privateData                ( 2),    -- optional parameters
    privateDataInAck           ( 3),    -- optional parameters
    ackModelMultiStep          ( 4),    -- misc characteristics
    resettedAfterCall          ( 5),    -- misc characteristics
    notSettableWhileActive     ( 6)}    -- misc characteristics

PhysDevEvtsList ::= SEQUENCE
{
    buttonInformation           [0] IMPLICIT ButtonInformation    OPTIONAL,
    buttonPress                 [1] IMPLICIT ButtonPressEvent    OPTIONAL,
    displayUpdated              [2] IMPLICIT DisplayUpdated      OPTIONAL,
    hookswitch                  [3] IMPLICIT Hookswitch          OPTIONAL,
    lampMode                    [4] IMPLICIT LampMode            OPTIONAL,
    messageWaiting              [5] IMPLICIT MessageWaiting      OPTIONAL,
    microphoneGain              [6] IMPLICIT MicrophoneGain      OPTIONAL,
    microphoneMute              [7] IMPLICIT MicrophoneMute      OPTIONAL,
    ringerStatus                [8] IMPLICIT RingerStatus        OPTIONAL,
    speakerMute                 [9] IMPLICIT SpeakerMute         OPTIONAL,
    speakerVolume               [10] IMPLICIT SpeakerVolume      OPTIONAL}

ButtonInformation ::= BIT STRING
{
    buttonLabel                 ( 0),    -- optional parameters
    buttonAssociatedNumber      ( 1),    -- optional parameters
    buttonPressIndicator        ( 2),    -- optional parameters
    privateData                 ( 3)}    -- optional parameters

ButtonPressEvent ::= BIT STRING
{
    buttonLabel                 ( 0),    -- optional parameters
    buttonAssociatedNumber      ( 1),    -- optional parameters
    privateData                 ( 2)}    -- optional parameters

DisplayUpdated ::= BIT STRING
{
    characterSetASCII           ( 0),    -- optional parameters
    characterSetUnicode         ( 1),    -- optional parameters
    characterSetProprietary     ( 2),    -- optional parameters
    privateData                 ( 3)}    -- optional parameters

Hookswitch ::= BIT STRING
{
    privateData                 ( 0)}    -- optional parameters

LampMode ::= BIT STRING
{
    lampModeBrokenFlutter       ( 0),    -- optional parameter

```

lampModeFlutter	( 1),	-- optional parameter
lampModeOff	( 2),	-- optional parameter
lampModeSteady	( 3),	-- optional parameter
lampModeWink	( 4),	-- optional parameter
lampModeReserved	( 5),	-- optional parameter
lampModeSf0	( 6),	-- optional parameters
lampModeSf1	( 7),	-- optional parameters
lampModeSf2	( 8),	-- optional parameters
lampModeSf3	( 9),	-- optional parameters
lampModeSf4	(10),	-- optional parameters
lampModeSf5	(11),	-- optional parameters
lampModeSf6	(12),	-- optional parameters
lampModeSf7	(13),	-- optional parameters
lampModeSf8	(14),	-- optional parameters
lampModeSf9	(15),	-- optional parameters
lampModeSf10	(16),	-- optional parameters
lampModeSf11	(17),	-- optional parameters
lampModeSf12	(18),	-- optional parameters
lampModeSf13	(19),	-- optional parameters
lampModeSf14	(20),	-- optional parameters
lampModeSf15	(21),	-- optional parameters
lampModeSf16	(22),	-- optional parameters
lampModeSf17	(23),	-- optional parameters
lampModeSf18	(24),	-- optional parameters
lampModeSf19	(25),	-- optional parameters
lampModeSf20	(26),	-- optional parameters
lampModeSf21	(27),	-- optional parameters
lampModeSf22	(28),	-- optional parameters
lampModeSf23	(29),	-- optional parameters
lampModeSf24	(30),	-- optional parameters
lampModeSf25	(31),	-- optional parameters
lampModeSf26	(32),	-- optional parameters
lampModeSf27	(33),	-- optional parameters
lampModeSf28	(34),	-- optional parameters
lampModeSf29	(35),	-- optional parameters
lampModeSf30	(36),	-- optional parameters
lampModeSf31	(37),	-- optional parameters
lampModeSf32	(38),	-- optional parameters
lampModeSf33	(39),	-- optional parameters
lampModeSf34	(40),	-- optional parameters
lampModeSf35	(41),	-- optional parameters
lampModeSf36	(42),	-- optional parameters
lampModeSf37	(43),	-- optional parameters
lampModeSf38	(44),	-- optional parameters
lampModeSf39	(45),	-- optional parameters
lampModeSf40	(46),	-- optional parameters
lampModeSf41	(47),	-- optional parameters
lampModeSf42	(48),	-- optional parameters
lampModeSf43	(49),	-- optional parameters
lampModeSf44	(50),	-- optional parameters
lampModeSf45	(51),	-- optional parameters
lampModeSf46	(52),	-- optional parameters
lampModeSf47	(53),	-- optional parameters
lampModeSf48	(54),	-- optional parameters
lampModeSf49	(55),	-- optional parameters
lampModeSf50	(56),	-- optional parameters
lampModeSf51	(57),	-- optional parameters
lampModeSf52	(58),	-- optional parameters
lampModeSf53	(59),	-- optional parameters
lampModeSf54	(60),	-- optional parameters
lampModeSf55	(61),	-- optional parameters
lampModeSf56	(62),	-- optional parameters
lampModeSf57	(63),	-- optional parameters
lampModeSf58	(64),	-- optional parameters
lampModeSf59	(65),	-- optional parameters
lampModeSf60	(66),	-- optional parameters
lampModeSf61	(67),	-- optional parameters
lampModeSf62	(68),	-- optional parameters

lampModeSf63	(69),	-- optional parameters
lampModeSf64	(70),	-- optional parameters
lampModeSf65	(71),	-- optional parameters
lampModeSf66	(72),	-- optional parameters
lampModeSf67	(73),	-- optional parameters
lampModeSf68	(74),	-- optional parameters
lampModeSf69	(75),	-- optional parameters
lampModeSf70	(76),	-- optional parameters
lampModeSf71	(77),	-- optional parameters
lampModeSf72	(78),	-- optional parameters
lampModeSf73	(79),	-- optional parameters
lampModeSf74	(80),	-- optional parameters
lampModeSf75	(81),	-- optional parameters
lampModeSf76	(82),	-- optional parameters
lampModeSf77	(83),	-- optional parameters
lampModeSf78	(84),	-- optional parameters
lampModeSf79	(85),	-- optional parameters
lampModeSf80	(86),	-- optional parameters
lampModeSf81	(87),	-- optional parameters
lampModeSf82	(88),	-- optional parameters
lampModeSf83	(89),	-- optional parameters
lampModeSf84	(90),	-- optional parameters
lampModeSf85	(91),	-- optional parameters
lampModeSf86	(92),	-- optional parameters
lampModeSf87	(93),	-- optional parameters
lampModeSf88	(94),	-- optional parameters
lampModeSf89	(95),	-- optional parameters
lampModeSf90	(96),	-- optional parameters
lampModeSf91	(97),	-- optional parameters
lampModeSf92	(98),	-- optional parameters
lampModeSf93	(99),	-- optional parameters
lampModeSf94	(100),	-- optional parameter
lampBrightnessNormal	(101),	-- optional parameter
lampBrightnessDim	(102),	-- optional parameter
lampBrightnessBright	(103),	-- optional parameter
lampColorNoColor	(104),	-- optional parameter
lampColorRed	(105),	-- optional parameter
lampColorYellow	(106),	-- optional parameter
lampColorGreen	(107),	-- optional parameter
lampColorBlue	(108),	-- optional parameter
lampColorReserved	(109),	-- optional parameter
lampColorSf0	(110),	-- optional parameters
lampColorSf1	(111),	-- optional parameters
lampColorSf2	(112),	-- optional parameters
lampColorSf3	(113),	-- optional parameters
lampColorSf4	(114),	-- optional parameters
lampColorSf5	(115),	-- optional parameters
lampColorSf6	(116),	-- optional parameters
lampColorSf7	(117),	-- optional parameters
lampColorSf8	(118),	-- optional parameters
lampColorSf9	(119),	-- optional parameters
lampColorSf10	(120),	-- optional parameters
lampColorSf11	(121),	-- optional parameters
lampColorSf12	(122),	-- optional parameters
lampColorSf13	(123),	-- optional parameters
lampColorSf14	(124),	-- optional parameters
lampColorSf15	(125),	-- optional parameters
lampColorSf16	(126),	-- optional parameters
lampColorSf17	(127),	-- optional parameters
lampColorSf18	(128),	-- optional parameters
lampColorSf19	(129),	-- optional parameters
lampColorSf20	(130),	-- optional parameters
lampColorSf21	(131),	-- optional parameters
lampColorSf22	(132),	-- optional parameters
lampColorSf23	(133),	-- optional parameters
lampColorSf24	(134),	-- optional parameters
lampColorSf25	(135),	-- optional parameters
lampColorSf26	(136),	-- optional parameters

lampColorSf27	(137),	-- optional parameters
lampColorSf28	(138),	-- optional parameters
lampColorSf29	(139),	-- optional parameters
lampColorSf30	(140),	-- optional parameters
lampColorSf31	(141),	-- optional parameters
lampColorSf32	(142),	-- optional parameters
lampColorSf33	(143),	-- optional parameters
lampColorSf34	(144),	-- optional parameters
lampColorSf35	(145),	-- optional parameters
lampColorSf36	(146),	-- optional parameters
lampColorSf37	(147),	-- optional parameters
lampColorSf38	(148),	-- optional parameters
lampColorSf39	(149),	-- optional parameters
lampColorSf40	(150),	-- optional parameters
lampColorSf41	(151),	-- optional parameters
lampColorSf42	(152),	-- optional parameters
lampColorSf43	(153),	-- optional parameters
lampColorSf44	(154),	-- optional parameters
lampColorSf45	(155),	-- optional parameters
lampColorSf46	(156),	-- optional parameters
lampColorSf47	(157),	-- optional parameters
lampColorSf48	(158),	-- optional parameters
lampColorSf49	(159),	-- optional parameters
lampColorSf50	(160),	-- optional parameters
lampColorSf51	(161),	-- optional parameters
lampColorSf52	(162),	-- optional parameters
lampColorSf53	(163),	-- optional parameters
lampColorSf54	(164),	-- optional parameters
lampColorSf55	(165),	-- optional parameters
lampColorSf56	(166),	-- optional parameters
lampColorSf57	(167),	-- optional parameters
lampColorSf58	(168),	-- optional parameters
lampColorSf59	(169),	-- optional parameters
lampColorSf60	(170),	-- optional parameters
lampColorSf61	(171),	-- optional parameters
lampColorSf62	(172),	-- optional parameters
lampColorSf63	(173),	-- optional parameters
lampColorSf64	(174),	-- optional parameters
lampColorSf65	(175),	-- optional parameters
lampColorSf66	(176),	-- optional parameters
lampColorSf67	(177),	-- optional parameters
lampColorSf68	(178),	-- optional parameters
lampColorSf69	(179),	-- optional parameters
lampColorSf70	(180),	-- optional parameters
lampColorSf71	(181),	-- optional parameters
lampColorSf72	(182),	-- optional parameters
lampColorSf73	(183),	-- optional parameters
lampColorSf74	(184),	-- optional parameters
lampColorSf75	(185),	-- optional parameters
lampColorSf76	(186),	-- optional parameters
lampColorSf77	(187),	-- optional parameters
lampColorSf78	(188),	-- optional parameters
lampColorSf79	(189),	-- optional parameters
lampColorSf80	(190),	-- optional parameters
lampColorSf81	(191),	-- optional parameters
lampColorSf82	(192),	-- optional parameters
lampColorSf83	(193),	-- optional parameters
lampColorSf84	(194),	-- optional parameters
lampColorSf85	(195),	-- optional parameters
lampColorSf86	(196),	-- optional parameters
lampColorSf87	(197),	-- optional parameters
lampColorSf88	(198),	-- optional parameters
lampColorSf89	(199),	-- optional parameters
lampColorSf90	(200),	-- optional parameters
lampColorSf91	(201),	-- optional parameters
lampColorSf92	(202),	-- optional parameters
lampColorSf93	(203),	-- optional parameters
lampColorSf94	(204),	-- optional parameters

```
privateData (205)} -- optional parameters

MessageWaiting ::= BIT STRING
{
    deviceForMsg ( 0), -- optional parameters
    privateData ( 1)} -- optional parameters

MicrophoneGain ::= BIT STRING
{
    microphoneGainAbs ( 0), -- optional parameters
    microphoneGainInc ( 1), -- optional parameters
    privateData ( 2)} -- optional parameters

MicrophoneMute ::= BIT STRING
{
    privateData ( 0)} -- optional parameters

RingerStatus ::= BIT STRING
{
    ringerModeRinging ( 0), -- optional parameters
    ringerModeNotRinging ( 1), -- optional parameters
    ringCount ( 2), -- optional parameters
    ringPattern ( 3), -- optional parameters
    ringVolumeAbs ( 4), -- optional parameters
    ringVolumeInc ( 5), -- optional parameters
    privateData ( 6)} -- optional parameters

SpeakerMute ::= BIT STRING
{
    privateData ( 0)} -- optional parameters

SpeakerVolume ::= BIT STRING
{
    speakerVolumeAbs ( 0), -- optional parameters
    speakerVolumeInc ( 1), -- optional parameters
    privateData ( 2)} -- optional parameters

LogicalServList ::= SEQUENCE
{
    callBackNonCallRel [ 0] IMPLICIT CallBackNonCallRel OPTIONAL,
    callBackMsgNonCallRel [ 1] IMPLICIT CallBackMsgNonCallRel OPTIONAL,
    cancelCallBack [ 2] IMPLICIT CancelCallBack OPTIONAL,
    cancelCallBackMsg [ 3] IMPLICIT CancelCallBackMsg OPTIONAL,
    getAgentState [ 4] IMPLICIT GetAgentState OPTIONAL,
    getAutoAnswer [ 5] IMPLICIT GetAutoAnswer OPTIONAL,
    getAutoWorkMode [ 6] IMPLICIT GetAutoWorkMode OPTIONAL,
    getCallerIDStatus [ 7] IMPLICIT GetCallerIDStatus OPTIONAL,
    getDoNotDisturb [ 8] IMPLICIT GetDoNotDisturb OPTIONAL,
    getForwarding [ 9] IMPLICIT GetForwarding OPTIONAL,
    getLastNumberDialed [10] IMPLICIT GetLastNumberDialed OPTIONAL,
    getRouteingMode [11] IMPLICIT GetRouteingMode OPTIONAL,
    setAgentState [12] IMPLICIT SetAgentState OPTIONAL,
    setAutoAnswer [13] IMPLICIT SetAutoAnswer OPTIONAL,
    setAutoWorkMode [14] IMPLICIT SetAutoWorkMode OPTIONAL,
    setCallerIDStatus [15] IMPLICIT SetCallerIDStatus OPTIONAL,
    setDoNotDisturb [16] IMPLICIT SetDoNotDisturb OPTIONAL,
    setForwarding [17] IMPLICIT SetForwarding OPTIONAL,
    setRouteingMode [18] IMPLICIT SetRouteingMode OPTIONAL}

CallBackNonCallRel ::= BIT STRING
{
    privateData ( 0), -- optional parameters
    privateDataInAck ( 1), -- optional parameters
    additionalReqForbidden ( 2), -- optional parameters
    ackModelMultiStep ( 3)} -- misc characteristics

CallBackMsgNonCallRel ::= BIT STRING
{
    privateData ( 0), -- optional parameters
    privateDataInAck ( 1), -- optional parameters
    additionalReqForbidden ( 2), -- optional parameters
    ackModelMultiStep ( 3)} -- misc characteristics

CancelCallBack ::= BIT STRING
{
    privateData ( 0), -- optional parameters
    privateDataInAck ( 1), -- optional parameters
    ackModelMultiStep ( 2), -- misc characteristics
```

```
        supportsClearing                ( 3)} -- misc characteristics

CancelCallBackMsg ::= BIT STRING
{
    privateData                ( 0), -- optional parameters
    privateDataInAck           ( 1), -- optional parameters
    ackModelMultiStep          ( 2), -- misc characteristics
    supportsClearing           ( 3)} -- misc characteristics

GetAgentState ::= BIT STRING
{
    acdGroup                    ( 0), -- optional parameters
    privateData                ( 1), -- optional parameters
    agentStateListAgentIDInAck ( 2), -- optional parameters
    agentGroupInAck            ( 3), -- optional parameters
    pendingAgentStateInAck      ( 4), -- optional parameters
    agentStateConditionForcedPauseInAck ( 5), -- optional parameters
    agentStateConditionPauseInAck ( 6), -- optional parameters
    privateDataInAck           ( 7)} -- optional parameters

GetAutoAnswer ::= BIT STRING
{
    privateData                ( 0), -- optional parameters
    numberOfRingsInAck         ( 1), -- optional parameters
    privateDataInAck           ( 2)} -- optional parameters

GetAutoWorkMode ::= BIT STRING
{
    privateData                ( 0), -- optional parameters
    autoWorkIntervalInAck      ( 1), -- optional parameters
    privateDataInAck           ( 2)} -- optional parameters

GetCallerIDStatus ::= BIT STRING
{
    privateData                ( 0), -- optional parameters
    privateDataInAck           ( 1)} -- optional parameters

GetDoNotDisturb ::= BIT STRING
{
    privateData                ( 0), -- optional parameters
    callOriginParameterInAck   ( 1), -- optional parameters
    callOriginInternInAck      ( 2), -- optional parameters
    callOriginExternInAck      ( 3), -- optional parameters
    callingDeviceListInAck     ( 4), -- optional parameters
    privateDataInAck           ( 5)} -- optional parameters

GetForwarding ::= BIT STRING
{
    privateData                ( 0), -- optional parameters
    forwardListInAck           ( 1), -- optional parameters
    forwardListImmediateInAck   ( 2), -- optional parameters
    forwardListBusyInAck       ( 3), -- optional parameters
    forwardListDNDInAck        ( 4), -- optional parameters
    forwardListNoAnsInAck      ( 5), -- optional parameters
    forwardListBusyIntInAck     ( 6), -- optional parameters
    forwardListBusyExtInAck     ( 7), -- optional parameters
    forwardListDNDIntInAck     ( 8), -- optional parameters
    forwardListDNDExtInAck     ( 9), -- optional parameters
    forwardListNoAnsIntInAck    (10), -- optional parameters
    forwardListNoAnsExtInAck    (11), -- optional parameters
    forwardListImmIntInAck      (12), -- optional parameters
    forwardListImmExtInAck      (13), -- optional parameters
    forwardDNInAck             (14), -- optional parameters
    forwardDefaultInAck         (15), -- optional parameters
    forwardDefaultTypeAndDNInAck (16), -- optional parameters
    forwardDefaultTypeInAck     (17), -- optional parameters
    forwardDefaultDNInAck       (18), -- optional parameters
    ringCountInAck             (19), -- optional parameters
    privateDataInAck           (20)} -- optional parameters

GetLastNumberDialed ::= BIT STRING
{
    privateData                ( 0), -- optional parameters
    privateDataInAck           ( 1)} -- optional parameters

GetRouteingMode ::= BIT STRING
```



```
{      privateData      ( 0),  -- optional parameters
      privateDataInAck  ( 1)}  -- optional parameters

SetAgentState ::= BIT STRING
{      requestedAgentStateLoggedOn      ( 0),  -- optional parameters
      requestedAgentStateLoggedOff      ( 1),  -- optional parameters
      requestedAgentStateNotReady      ( 2),  -- optional parameters
      requestedAgentStateReady      ( 3),  -- optional parameters
      requestedAgentStateWorkingAfterCall ( 4),  -- optional parameters
      agentID      ( 5),  -- optional parameters
      password      ( 6),  -- optional parameters
      group      ( 7),  -- optional parameters
      privateData      ( 8),  -- optional parameters
      pendingAgentStateWorkingAfterCallInAck ( 9),  -- optional parameters
      pendingAgentStateNotReadyInAck (10),  -- optional parameters
      pendingAgentStateNullInAck      (11),  -- optional parameters
      privateDataInAck      (12),  -- optional parameters
      ackModelMultiStep      (13),  -- misc characteristics
      groupDeviceAllowedInReq      (14),  -- misc characteristics
      aCDDDeviceAllowedInReq      (15),  -- misc characteristics
      delayTransitionIfBusy      (16),  -- misc characteristics
      delayTransitionIfWorkingAfterCall (17)}  -- misc characteristics

SetAutoAnswer ::= BIT STRING
{      numberOfRings      ( 0),  -- optional parameters
      privateData      ( 1),  -- optional parameters
      privateDataInAck      ( 2),  -- optional parameters
      ackModelMultiStep      ( 3)}  -- misc characteristics

SetAutoWorkMode ::= BIT STRING
{      autoWorkInterval      ( 0),  -- optional parameters
      privateData      ( 1),  -- optional parameters
      privateDataInAck      ( 2),  -- optional parameters
      ackModelMultiStep      ( 3),  -- misc characteristics
      groupDeviceAllowedInReq      ( 4),  -- misc characteristics
      aCDDDeviceAllowedInReq      ( 5)}  -- misc characteristics

SetCallerIDStatus ::= BIT STRING
{      privateData      ( 0),  -- optional parameters
      privateDataInAck      ( 1),  -- optional parameters
      ackModelMultiStep      ( 2)}  -- misc characteristics

SetDoNotDisturb ::= BIT STRING
{      callOriginationInternal      ( 0),  -- optional parameters
      callOriginationExternal      ( 1),  -- optional parameters
      callingDeviceList      ( 2),  -- optional parameters
      privateData      ( 3),  -- optional parameters
      privateDataInAck      ( 4),  -- optional parameters
      ackModelMultiStep      ( 5)}  -- misc characteristics

SetForwarding ::= BIT STRING
{      forwardingTypeBusy      ( 0),  -- optional parameters
      forwardingTypeBusyInt      ( 1),  -- optional parameters
      forwardingTypeBusyExt      ( 2),  -- optional parameters
      forwardingTypeDND      ( 3),  -- optional parameters
      forwardingTypeDNDInt      ( 4),  -- optional parameters
      forwardingTypeDNDExt      ( 5),  -- optional parameters
      forwardingTypeNoAns      ( 6),  -- optional parameters
      forwardingTypeNoAnsInt      ( 7),  -- optional parameters
      forwardingTypeNoAnsExt      ( 8),  -- optional parameters
      forwardingTypeImmediate      ( 9),  -- optional parameters
      forwardingTypeImmInt      (10),  -- optional parameters
      forwardingTypeImmExt      (11),  -- optional parameters
      forwardDN      (12),  -- optional parameters
      ringCount      (13),  -- optional parameters
      privateData      (14),  -- optional parameters
      privateDataInAck      (15),  -- optional parameters
      ackModelMultiStep      (16)}  -- misc characteristics
```

```
SetRouteingMode ::= BIT STRING
{
    privateData                ( 0),  -- optional parameters
    privateDataInAck           ( 1),  -- optional parameters
    ackModelMultiStep          ( 2)}  -- misc characteristics

LogicalEvtsList ::= SEQUENCE
{
    agentBusy                  [0] IMPLICIT AgentBusy          OPTIONAL,
    agentLoggedOff             [1] IMPLICIT AgentLoggedOff      OPTIONAL,
    agentLoggedOn              [2] IMPLICIT AgentLoggedOn       OPTIONAL,
    agentNotReady              [3] IMPLICIT AgentNotReady       OPTIONAL,
    agentReady                 [4] IMPLICIT AgentReady          OPTIONAL,
    agentWorkingAfterCall      [5] IMPLICIT AgentWorkingAfterCall OPTIONAL,
    autoAnswer                 [6] IMPLICIT AutoAnswer         OPTIONAL,
    autoWorkMode               [7] IMPLICIT AutoWorkMode       OPTIONAL,
    callBack                   [8] IMPLICIT CallBackEvent      OPTIONAL,
    callBackMessage            [9] IMPLICIT CallBackMessageEvent OPTIONAL,
    callerIDStatus             [10] IMPLICIT CallerIDStatus     OPTIONAL,
    doNotDisturb               [11] IMPLICIT DoNotDisturb       OPTIONAL,
    forwarding                  [12] IMPLICIT Forwarding        OPTIONAL,
    routeingMode               [13] IMPLICIT RouteingMode      OPTIONAL}

AgentBusy ::= BIT STRING
{
    agentID                    ( 0),  -- optional parameters
    acdGroup                   ( 1),  -- optional parameters
    pendingAgentStateWorkingAfterCall ( 2),  -- optional parameters
    pendingAgentStateNotReady   ( 3),  -- optional parameters
    pendingAgentStateReady      ( 4),  -- optional parameters
    pendingAgentStateNull       ( 5),  -- optional parameters
    cause                      ( 6),  -- optional parameters
    privateData                 ( 7)}  -- optional parameters

AgentLoggedOff ::= BIT STRING
{
    agentID                    ( 0),  -- optional parameters
    acdGroup                   ( 1),  -- optional parameters
    agentPassword              ( 2),  -- optional parameters
    cause                      ( 3),  -- optional parameters
    privateData                 ( 4)}  -- optional parameters

AgentLoggedOn ::= BIT STRING
{
    agentID                    ( 0),  -- optional parameters
    acdGroup                   ( 1),  -- optional parameters
    agentPassword              ( 2),  -- optional parameters
    cause                      ( 3),  -- optional parameters
    privateData                 ( 4)}  -- optional parameters

AgentNotReady ::= BIT STRING
{
    agentID                    ( 0),  -- optional parameters
    acdGroup                   ( 1),  -- optional parameters
    cause                      ( 2),  -- optional parameters
    privateData                 ( 3)}  -- optional parameters

AgentReady ::= BIT STRING
{
    agentID                    ( 0),  -- optional parameters
    acdGroup                   ( 1),  -- optional parameters
    cause                      ( 2),  -- optional parameters
    privateData                 ( 3)}  -- optional parameters

AgentWorkingAfterCall ::= BIT STRING
{
    agentID                    ( 0),  -- optional parameters
    acdGroup                   ( 1),  -- optional parameters
    pendingAgentStateNotReady   ( 2),  -- optional parameters
    pendingAgentStateReady      ( 3),  -- optional parameters
    pendingAgentStateNull       ( 4),  -- optional parameters
    cause                      ( 5),  -- optional parameters
    privateData                 ( 6)}  -- optional parameters
```

```
AutoAnswer ::= BIT STRING
{
    numberOfRings          ( 0),  -- optional parameters
    privateData            ( 1)}  -- optional parameters

AutoWorkMode ::= BIT STRING
{
    privateData            ( 0)}  -- optional parameters

CallBackEvent ::= BIT STRING
{
    privateData            ( 0)}  -- optional parameters

CallBackMessageEvent ::= BIT STRING
{
    privateData            ( 0)}  -- optional parameters

CallerIDStatus ::= BIT STRING
{
    privateData            ( 0)}  -- optional parameters

DoNotDisturb ::= BIT STRING
{
    callOriginationParameter ( 0),  -- optional parameters
    callOriginationInternal  ( 1),  -- optional parameters
    callOriginationExternal  ( 2),  -- optional parameters
    callingDeviceList        ( 3),  -- optional parameters
    privateData              ( 4)}  -- optional parameters

Forwarding ::= BIT STRING
{
    forwardingTypeBusy      ( 0),
    forwardingTypeBusyInt   ( 1),
    forwardingTypeBusyExt   ( 2),
    forwardingTypeDND       ( 3),
    forwardingTypeDNDInt    ( 4),
    forwardingTypeDNDExt    ( 5),
    forwardingTypeNoAns      ( 6),
    forwardingTypeNoAnsInt   ( 7),
    forwardingTypeNoAnsExt   ( 8),
    forwardingTypeImmediate ( 9),
    forwardingTypeImmInt     (10),
    forwardingTypeImmExt     (11),
    forwardTo                (12),
    forwardDefaultTypeAndDN  (13),
    forwardDefaultType       (14),
    forwardDefaultDN         (15),
    ringCount                (16),
    privateData              (17)}

RouteingMode ::= BIT STRING
{
    privateData            ( 0)}  -- optional parameters

DeviceMaintEvsList ::= SEQUENCE
{
    backInService          [0] IMPLICIT BackInService      OPTIONAL,
    deviceCapsChanged      [1] IMPLICIT DeviceCapsChanged  OPTIONAL,
    outOfService           [2] IMPLICIT OutOfService       OPTIONAL}

BackInService ::= BIT STRING
{
    cause                  ( 0),  -- optional parameters
    privateData            ( 1)}  -- optional parameters

DeviceCapsChanged ::= BIT STRING
{
    cause                  ( 0),  -- optional parameters
    privateData            ( 1)}  -- optional parameters

OutOfService ::= BIT STRING
{
    cause                  ( 0),  -- optional parameters
    privateData            ( 1)}  -- optional parameters

IOServicesServList ::= SEQUENCE
{
    ioRegister             [ 0] IMPLICIT IoRegister        OPTIONAL,
    ioRegisterAbort        [ 1] IMPLICIT IoRegisterAbort    OPTIONAL,
    ioRegisterCancel       [ 2] IMPLICIT IoRegisterCancel    OPTIONAL,
    dataPathResumed        [ 3] IMPLICIT DataPathResumed     OPTIONAL,
```

```
dataPathSuspended      [ 4] IMPLICIT DataPathSuspended OPTIONAL,
fastData                [ 5] IMPLICIT FastData             OPTIONAL,
resumeDataPath          [ 6] IMPLICIT ResumeDataPath       OPTIONAL,
sendBroadcastData       [ 7] IMPLICIT SendBroadcastData    OPTIONAL,
sendData                [ 8] IMPLICIT SendData             OPTIONAL,
sendMulticastData       [ 9] IMPLICIT SendMulticastData    OPTIONAL,
startDataPath           [10] IMPLICIT StartDataPath        OPTIONAL,
stopDataPath            [11] IMPLICIT StopDataPath         OPTIONAL,
suspendDataPath         [12] IMPLICIT SuspendDataPath      OPTIONAL}

IoRegister ::= BIT STRING
{
    ioDevice              ( 0),  -- optional parameters
    privateData           ( 1),  -- optional parameters
    privateDataInAck      ( 2),  -- optional parameters
    allIODevices          ( 3)}  -- misc characteristics

IoRegisterAbort ::= BIT STRING
{
    privateData           ( 0)}  -- optional parameters

IoRegisterCancel ::= BIT STRING
{
    privateData           ( 0),  -- optional parameters
    privateDataInAck      ( 1)}  -- optional parameters

DataPathResumed ::= BIT STRING
{
    privateData           ( 0),  -- optional parameters
    privateDataInAck      ( 1)}  -- optional parameters

DataPathSuspended ::= BIT STRING
{
    privateData           ( 0),  -- optional parameters
    privateDataInAck      ( 1)}  -- optional parameters

FastData ::= BIT STRING
{
    objectDevice          ( 0),  -- optional parameters
    objectCall            ( 1),  -- optional parameters
    dataPathTypeText      ( 2),  -- optional parameters
    dataPathTypeVoice     ( 3),  -- optional parameters
    displayAttribPhyBaseRowNumber ( 4), -- optional parameters
    displayAttribPhyBaseColumnNumber ( 5), -- optional parameters
    displayAttribOffset   ( 6),  -- optional parameters
    privateData           ( 7),  -- optional parameters
    privateDataInAck      ( 8),  -- optional parameters
    supportsModifyingPosition ( 9)} -- misc characteristics

ResumeDataPath ::= BIT STRING
{
    privateData           ( 0),  -- optional parameters
    privateDataInAck      ( 1),  -- optional parameters
    sendsDataPathResumed ( 2)}  -- misc characteristics

SendBroadcastData ::= BIT STRING
{
    privateData           ( 0),  -- optional parameters
    dataPathTypeText      ( 1),  -- optional parameters
    dataPathTypeVoice     ( 2),  -- optional parameters
    displayAttribPhyBaseRowNumber ( 3), -- optional parameters
    displayAttribPhyBaseColumnNumber ( 4), -- optional parameters
    displayAttribOffset   ( 5),  -- optional parameters
    privateDataInAck      ( 6),  -- optional parameters
    supportsModifyingPosition ( 7)} -- misc characteristics

SendData ::= BIT STRING
{
    displayAttribPhyBaseRowNumber ( 0), -- optional parameters
    displayAttribPhyBaseColumnNumber ( 1), -- optional parameters
    displayAttribOffset   ( 2),  -- optional parameters
    ioCauseTerminationCharReceived ( 3), -- optional parameters
    ioCauseCharCountReached ( 4),  -- optional parameters
    ioCauseTimeout        ( 5),  -- optional parameters
    ioCauseSfTerminated   ( 6),  -- optional parameters
    privateData           ( 7),  -- optional parameters
    privateDataInAck      ( 8),  -- optional parameters
```

```
        supportsModifyingPosition          ( 9)}  -- misc characteristics

SendMulticastData ::= BIT STRING
{
    ioData                                ( 0),  -- optional parameters
    displayAttribPhyBaseRowNumber         ( 1),  -- optional parameters
    displayAttribPhyBaseColumnNumber      ( 2),  -- optional parameters
    displayAttribOffset                   ( 3),  -- optional parameters
    privateData                           ( 4),  -- optional parameters
    privateDataInAck                      ( 5),  -- optional parameters
    supportsModifyingPosition              ( 6)}  -- misc characteristics

StartDataPath ::= BIT STRING
{
    objectDevice                          ( 0),  -- optional parameters
    objectCall                            ( 1),  -- optional parameters
    dataPathDirectionCfToObject           ( 2),  -- optional parameters
    dataPathDirectionObjectToCf           ( 3),  -- optional parameters
    dataPathDirectionBidirectional        ( 4),  -- optional parameters
    dataPathTypeText                      ( 5),  -- optional parameters
    dataPathTypeVoice                    ( 6),  -- optional parameters
    numberOfCharsToCollect                ( 7),  -- optional parameters
    terminationChar                       ( 8),  -- optional parameters
    timeout                               ( 9),  -- optional parameters
    privateData                           (10),  -- optional parameters
    numberOfCharsToCollectInAck           (11),  -- optional parameters
    terminationCharInAck                  (12),  -- optional parameters
    timeoutInAck                          (13),  -- optional parameters
    privateDataInAck                      (14)}  -- optional parameters

StopDataPath ::= BIT STRING
{
    privateData                          ( 0),  -- optional parameters
    privateDataInAck                     ( 1)}  -- optional parameters

SuspendDataPath ::= BIT STRING
{
    privateData                          ( 0),  -- optional parameters
    privateDataInAck                     ( 1)}  -- optional parameters

DataCollectionServList ::= SEQUENCE
{
    dataCollected                       [ 0] IMPLICIT DataCollected      OPTIONAL,
    dataCollectionResumed                 [ 1] IMPLICIT DataCollectionResumed  OPTIONAL,
    dataCollectionSuspended               [ 2] IMPLICIT DataCollectionSuspended  OPTIONAL,
    resumeDataCollection                  [ 3] IMPLICIT ResumeDataCollection    OPTIONAL,
    startDataCollection                   [ 4] IMPLICIT StartDataCollection     OPTIONAL,
    stopDataCollection                    [ 5] IMPLICIT StopDataCollection      OPTIONAL,
    suspendDataCollection                 [ 6] IMPLICIT SuspendDataCollection   OPTIONAL}

DataCollected ::= BIT STRING
{
    digitsDuration                       ( 0),  -- optional parameters
    digitsPauseDuration                  ( 1),  -- optional parameters
    toneDetectedBeep                     ( 2),  -- optional parameters
    toneDetectedBilling                   ( 3),  -- optional parameters
    toneDetectedBusy                      ( 4),  -- optional parameters
    toneDetectedCarrier                   ( 5),  -- optional parameters
    toneDetectedConfirmation              ( 6),  -- optional parameters
    toneDetectedDial                      ( 7),  -- optional parameters
    toneDetectedFaxCNG                    ( 8),  -- optional parameters
    toneDetectedHold                      ( 9),  -- optional parameters
    toneDetectedHowler                    (10),  -- optional parameters
    toneDetectedIntrusion                 (11),  -- optional parameters
    toneDetectedModemCNG                  (12),  -- optional parameters
    toneDetectedPark                      (13),  -- optional parameters
    toneDetectedRecordWarning              (14),  -- optional parameters
    toneDetectedReorder                   (15),  -- optional parameters
    toneDetectedRingback                  (16),  -- optional parameters
    toneDetectedSilence                   (17),  -- optional parameters
    toneDetectedSitVC                     (18),  -- optional parameters
    toneDetectedSitIC                     (19),  -- optional parameters
    toneDetectedSitRO                     (20),  -- optional parameters
    toneDetectedSitNC                     (21),  -- optional parameters
```

```
toneDetectedSf0          (22),  -- optional parameters
toneDetectedSf1          (23),  -- optional parameters
toneDetectedSf2          (24),  -- optional parameters
toneDetectedSf3          (25),  -- optional parameters
toneDetectedSf4          (26),  -- optional parameters
toneDetectedSf5          (27),  -- optional parameters
toneDetectedSf6          (28),  -- optional parameters
toneDetectedSf7          (29),  -- optional parameters
toneDetectedSf8          (30),  -- optional parameters
toneDetectedSf9          (31),  -- optional parameters
toneDetectedSf10         (32),  -- optional parameters
toneDetectedOther        (33),  -- optional parameters
toneFrequency            (34),  -- optional parameters
toneDuration             (35),  -- optional parameters
tonePauseDuration        (36),
connectionInfo           (37),  -- optional parameters
dcollCauseFushCharReceived (38),  -- optional parameters
dcollCauseCharCountReached (39),  -- optional parameters
dcollCauseTimeout        (40),  -- optional parameters
dcollCauseSFTerminated   (41),  -- optional parameters
privateData              (42),  -- optional parameters
privateDataInAck         (43)}  -- optional parameters

DataCollectionResumed ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck     ( 1)}  -- optional parameters

DataCollectionSuspended ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck     ( 1)}  -- optional parameters

ResumeDataCollection ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck     ( 1)}  -- optional parameters

StartDataCollection ::= BIT STRING
{
    objectDevice          ( 0),  -- optional parameters
    objectCall            ( 1),  -- optional parameters
    dataCollectionTypeDigits ( 2),  -- optional parameters
    dataCollectionTypeTones ( 3),  -- optional parameters
    digitsReportingCriteriaNumChars ( 4),  -- optional parameters
    digitsReportingCriteriaFlushChar ( 5),  -- optional parameters
    digitsReportingCriteriaTimeout ( 6),  -- optional parameters
    privateData          ( 7),  -- optional parameters
    privateDataInAck     ( 8)}  -- optional parameters

StopDataCollection ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck     ( 1)}  -- optional parameters

SuspendDataCollection ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck     ( 1)}  -- optional parameters

VoiceUnitServList ::= SEQUENCE
{
    concatenateMsg        [ 0] IMPLICIT ConcatenateMsg    OPTIONAL,
    deleteMsg            [ 1] IMPLICIT DeleteMsg          OPTIONAL,
    playMsg               [ 2] IMPLICIT PlayMsg            OPTIONAL,
    queryVoiceAttrib      [ 3] IMPLICIT QueryVoiceAttrib   OPTIONAL,
    recordMsg             [ 4] IMPLICIT RecordMsg          OPTIONAL,
    reposition            [ 5] IMPLICIT Reposition         OPTIONAL,
    resume                [ 6] IMPLICIT Resume             OPTIONAL,
    review                [ 7] IMPLICIT Review             OPTIONAL,
    setVoiceAttrib        [ 8] IMPLICIT SetVoiceAttrib     OPTIONAL,
    stop                  [ 9] IMPLICIT Stop               OPTIONAL,
    suspend               [10] IMPLICIT Suspend            OPTIONAL,
    synthesizeMsg         [11] IMPLICIT SynthesizeMsg     OPTIONAL}
```

```
ConcatenateMsg ::= BIT STRING
{
    privateData          ( 0),    -- optional parameters
    privateDataInAck      ( 1)}   -- optional parameters

DeleteMsg ::= BIT STRING
{
    privateData          ( 0),    -- optional parameters
    privateDataInAck      ( 1)}   -- optional parameters

PlayMsg ::= BIT STRING
{
    duration              ( 0),    -- optional parameters
    terminationParameter  ( 1),    -- optional parameters
    terminationDurationExceeded ( 2), -- optional parameters
    terminationDTMFDigitDetected ( 3), -- optional parameters
    terminationEndOfSpeechDetected ( 4), -- optional parameters
    terminationSpeech     ( 5),    -- optional parameters
    privateData           ( 6),    -- optional parameters
    privateDataInAck      ( 7),    -- optional parameters
    multipleMsgsSimultaneously ( 8)} -- miscellaneous characteristics

QueryVoiceAttrib ::= BIT STRING
{
    attribToQueryEncodingAlgorithm ( 0), -- optional parameters
    attribToQuerySamplingRate      ( 1), -- optional parameters
    attribToQueryDuration          ( 2), -- optional parameters
    attribToQueryFilename          ( 3), -- optional parameters
    attribToQueryCurrentPosition   ( 4), -- optional parameters
    attribToQueryCurrentSpeed      ( 5), -- optional parameters
    attribToQueryCurrentVolume     ( 6), -- optional parameters
    attribToQueryCurrentLevel      ( 7), -- optional parameters
    attribToQueryCurrentState      ( 8), -- optional parameters
    connection                    ( 9), -- optional parameters
    duration                      (10), -- optional parameters
    terminationParameter          (11), -- optional parameters
    terminationDurationExceeded   (12), -- optional parameters
    terminationDTMFDigitDetected  (13), -- optional parameters
    terminationEndOfSpeechDetected (14), -- optional parameters
    terminationSpeech             (15), -- optional parameters
    privateData                   (16), -- optional parameters
    attribInAckEncodingAlgorithmADPCM6K (17), -- optional parameters
    attribInAckEncodingAlgorithmADPCM8K (18), -- optional parameters
    attribInAckEncodingAlgorithmMuLawPCM6K (19), -- optional parameters
    attribInAckEncodingAlgorithmALawPCM6K (20), -- optional parameters
    attribInAckSamplingRate       (21), -- optional parameters
    attribInAckDuration           (22), -- optional parameters
    attribInAckFilename           (23), -- optional parameters
    attribInAckCurrentPosition    (24), -- optional parameters
    attribInAckCurrentSpeed       (25), -- optional parameters
    attribInAckCurrentVolumeAbs   (26), -- optional parameters
    attribInAckCurrentGain        (27), -- optional parameters
    attribInAckCurrentState       (28), -- optional parameters
    privateDataInAck              (29)} -- optional parameters

RecordMsg ::= BIT STRING
{
    samplingRate          ( 0),    -- optional parameters
    encodingAlgorithmADPCM6K ( 1), -- optional parameters
    encodingAlgorithmADPCM8K ( 2), -- optional parameters
    encodingAlgorithmMuLawPCM6K ( 3), -- optional parameters
    encodingAlgorithmALawPCM6K ( 4), -- optional parameters
    maxDuration           ( 5),    -- optional parameters
    terminationParameter  ( 6),    -- optional parameters
    terminationDurationExceeded ( 7), -- optional parameters
    terminationDTMFDigitDetected ( 8), -- optional parameters
    terminationEndOfDataDetected ( 9), -- optional parameters
    terminationSpeechDetected (10), -- optional parameters
    privateData           (11),    -- optional parameters
    privateDataInAck      (12)}   -- optional parameters

Reposition ::= BIT STRING
{
    periodOfRepositionStartOfMsg ( 0), -- optional parameters
```

```
periodOfRepositionEndOfMsg          ( 1),  -- optional parameters
periodOfRepositionRelativePointer   ( 2),  -- optional parameters
msgToReposition                     ( 3),  -- optional parameters
privateData                         ( 4),  -- optional parameters
privateDataInAck                    ( 5)}  -- optional parameters

Resume ::= BIT STRING
{
    msgToResume          ( 0),  -- optional parameters
    duration             ( 1),  -- optional parameters
    privateData          ( 2),  -- optional parameters
    privateDataInAck     ( 3)}  -- optional parameters

Review ::= BIT STRING
{
    periodToResumeStartOfMsg      ( 0),  -- optional parameters
    periodToResumeLengthOfReview ( 1),  -- optional parameters
    privateData                  ( 2),  -- optional parameters
    privateDataInAck             ( 3)}  -- optional parameters

SetVoiceAttrib ::= BIT STRING
{
    currentSpeed          ( 0),  -- optional parameters
    currentVolumeAbs      ( 1),  -- optional parameters
    currentVolumeInc      ( 2),  -- optional parameters
    periodToResumeStartOfMsg ( 3),  -- optional parameters
    periodToResumeLengthOfReview ( 4),  -- optional parameters
    currentGain           ( 5),  -- optional parameters
    message               ( 6),  -- optional parameters
    privateData           ( 7),  -- optional parameters
    privateDataInAck      ( 8)}  -- optional parameters

Stop ::= BIT STRING
{
    privateData          ( 0),  -- optional parameters
    privateDataInAck     ( 1)}  -- optional parameters

Suspend ::= BIT STRING
{
    message              ( 0),  -- optional parameters
    privateData          ( 1),  -- optional parameters
    privateDataInAck     ( 2)}  -- optional parameters

SynthesizeMsg ::= BIT STRING
{
    genderMale           ( 0),  -- optional parameters
    genderFemale         ( 1),  -- optional parameters
    privateData          ( 2),  -- optional parameters
    privateDataInAck     ( 3)}  -- optional parameters

VoiceUnitEvtsList ::= SEQUENCE
{
    play                [ 0] IMPLICIT Play          OPTIONAL,
    record              [ 1] IMPLICIT Record        OPTIONAL,
    review              [ 2] IMPLICIT ReviewEvent    OPTIONAL,
    stop               [ 3] IMPLICIT StopEvent       OPTIONAL,
    suspendPlay        [ 4] IMPLICIT SuspendPlay     OPTIONAL,
    suspendRecord      [ 5] IMPLICIT SuspendRecord   OPTIONAL,
    voiceAttribChanged [ 6] IMPLICIT VoiceAttribChanged OPTIONAL}

Play ::= BIT STRING
{
    length              ( 0),  -- optional parameters
    currentPosition    ( 1),  -- optional parameters
    speed              ( 2),  -- optional parameters
    cause              ( 3),  -- optional parameters
    servicesPermitted  ( 4),  -- optional parameters
    privateData        ( 5)}  -- optional parameters

Record ::= BIT STRING
{
    length              ( 0),  -- optional parameters
    currentPosition    ( 1),  -- optional parameters
    speed              ( 2),  -- optional parameters
    cause              ( 3),  -- optional parameters
    servicesPermitted  ( 4),  -- optional parameters
    privateData        ( 5)}  -- optional parameters
```



```
ReviewEvent ::= BIT STRING
{
    length                ( 0),  -- optional parameters
    currentPosition       ( 1),  -- optional parameters
    cause                 ( 2),  -- optional parameters
    servicesPermitted     ( 3),  -- optional parameters
    privateData           ( 4)}  -- optional parameters

StopEvent ::= BIT STRING
{
    length                ( 0),  -- optional parameters
    currentPosition       ( 1),  -- optional parameters
    speed                 ( 2),  -- optional parameters
    cause                 ( 3),  -- optional parameters
    servicesPermitted     ( 4),  -- optional parameters
    privateData           ( 5)}  -- optional parameters

SuspendPlay ::= BIT STRING
{
    length                ( 0),  -- optional parameters
    currentPosition       ( 1),  -- optional parameters
    cause                 ( 2),  -- optional parameters
    servicesPermitted     ( 3),  -- optional parameters
    privateData           ( 4)}  -- optional parameters

SuspendRecord ::= BIT STRING
{
    length                ( 0),  -- optional parameters
    currentPosition       ( 1),  -- optional parameters
    cause                 ( 2),  -- optional parameters
    servicesPermitted     ( 3),  -- optional parameters
    privateData           ( 4)}  -- optional parameters

VoiceAttribChanged ::= BIT STRING
{
    playVolumeAbs         ( 0),  -- optional parameters
    playVolumeInc         ( 1),  -- optional parameters
    recordGain            ( 2),  -- optional parameters
    speed                 ( 3),  -- optional parameters
    currentPosition       ( 4),  -- optional parameters
    cause                 ( 5),  -- optional parameters
    privateData           ( 6)}  -- optional parameters

CDRServList ::= SEQUENCE
{
    cdrNotification       [ 0] IMPLICIT CdrNotification      OPTIONAL,
    cdrReport             [ 1] IMPLICIT CdrReport            OPTIONAL,
    sendStoredCDRs        [ 2] IMPLICIT SendStoredCDRs        OPTIONAL,
    startCDRTransmission [ 3] IMPLICIT StartCDRTransmission  OPTIONAL,
    stopCDRTransmission  [ 4] IMPLICIT StopCDRTransmission   OPTIONAL }

CdrNotification ::= BIT STRING
{
    cdrReasonTimeout      ( 0),  -- optional parameters
    cdrReasonThresholdReached ( 1), -- optional parameters
    cdrReasonOther        ( 2),  -- optional parameters
    privateData           ( 3),  -- optional parameters
    privateDataInAck      ( 4)}  -- optional parameters

CdrReport ::= BIT STRING
{
    cdrReasonTimeout      ( 0),  -- optional parameters
    cdrReasonThresholdReached ( 1), -- optional parameters
    cdrReasonOther        ( 2),  -- optional parameters
    recordNumber          ( 3),  -- optional parameter
    recordCreationTime     ( 4),  -- optional parameter
    callingDevice          ( 5),  -- optional parameter
    calledDevice           ( 6),  -- optional parameter
    assocCallingDevice     ( 7),  -- optional parameter
    assocCalledDevice      ( 8),  -- optional parameter
    netwCallingDevice      ( 9),  -- optional parameter
    netwCalledDevice       (10),  -- optional parameter
    callCharacteristics    (11),  -- optional parameter
    mediaCallCharacteristics (12), -- optional parameter
    chargedDeviceOperator  (13),  -- optional parameter
```

```
chargedDeviceNonOperator      (14),  -- optional parameters
recordedCall                  (15),  -- optional parameters
nodeNumberArea0               (16),  -- optional parameters
nodeNumberArea1               (17),  -- optional parameters
nodeNumberArea2               (18),  -- optional parameters
tarifTable                    (19),  -- optional parameters
connectionStart                (20),  -- optional parameters
connectionEnd                  (21),  -- optional parameters
connectionDuration             (22),  -- optional parameters
accessCode                     (23),  -- optional parameters
carrier                        (24),  -- optional parameters
selectedRoute                  (25),  -- optional parameters
billingIndicatorNormalCharging (26),  -- optional parameters
billingIndicatorReverseCharging (27), -- optional parameters
billingIndicatorCreditCardCharging (28), -- optional parameters
billingIndicatorCallForwarding (29),  -- optional parameters
billingIndicatorCallDeflection (30),  -- optional parameters
billingIndicatorCallTransfer   (31),  -- optional parameters
billingIndicatorOther           (32),  -- optional parameters
chargingInfo                   (33),  -- optional parameters
suppServiceInfoNormalCall      (34),  -- optional parameters
suppServiceInfoConsultationCall (35), -- optional parameters
suppServiceInfoTransferCall    (36),  -- optional parameters
suppServiceInfoCallCompletion  (37),  -- optional parameters
suppServiceInfoCallForwarding  (38),  -- optional parameters
suppServiceInfoCallDiversion   (39),  -- optional parameters
suppServiceInfoConferencing    (40),  -- optional parameters
suppServiceInfoIntrusion       (41),  -- optional parameters
suppServiceInfoUserUserInfo    (42),  -- optional parameters
suppServiceInfoOther           (43),  -- optional parameters
reasonForTermNormalClearing    (44),  -- optional parameters
reasonForTermUnsuccessfulCallAttempt (45), -- optional parameters
reasonForTermAbnormalTermination (46), -- optional parameters
reasonForTermCallTransferred   (47),  -- optional parameters
reasonForTermOther             (48),  -- optional parameters
authCode                       (49),  -- optional parameters
accountInfo                    (50),  -- optional parameters
deviceCategory                 (51),  -- optional parameters
namedDeviceTypes               (52),  -- optional parameters
operatorDevice                  (53),  -- optional parameters
lastStoredCDRReportSent        (54),  -- optional parameters
privateData                     (55),  -- optional parameters
privateDataInAck                (56)} -- optional parameters

SendStoredCDRs ::= BIT STRING
{
    timePeriod      ( 0),  -- optional parameters
    privateData     ( 1),  -- optional parameters
    privateDataInAck ( 2)} -- optional parameters

StartCDRTransmission ::= BIT STRING
{
    transferModeTransferAtEndOfCall      ( 0),  -- optional parameters
    transferModeTransferOnRequest         ( 1),  -- optional parameters
    transferModeTransferOnThresholdReached ( 2),  -- optional parameters
    privateData                           ( 3),  -- optional parameters
    privateDataInAck                       ( 4)} -- optional parameters

StopCDRTransmission ::= BIT STRING
{
    cdrTermReasonEndOfData      ( 0),  -- optional parameters
    cdrTermReasonError           ( 1),  -- optional parameters
    cdrTermReasonThresholdReached ( 2),  -- optional parameters
    cdrTermReasonOther           ( 3),  -- optional parameter
    privateData                   ( 4),  -- optional parameter
    privateDataInAck              ( 5),  -- optional parameter
    swFunctionSupportsSending      ( 6),  -- miscellaneous characteristics
    swFunctionSupportsReceiving    ( 7)} -- miscellaneous characteristics

VendorSpecificServList ::= SEQUENCE
{
    escapeRegister [ 0] IMPLICIT EscapeRegister OPTIONAL,
```

```

        escapeRegisterCancel      [ 1] IMPLICIT EscapeRegisterCancel      OPTIONAL,
        escapeRegisterAbort       [ 2] IMPLICIT EscapeRegisterAbort       OPTIONAL,
        escape                    [ 3] IMPLICIT Escape                    OPTIONAL,
        privateDataVersionSelection [ 4] IMPLICIT PrivateDataVersionSelection OPTIONAL }

EscapeRegister ::= BIT STRING
{
    privateData      (0),    -- optional parameters
    privateDataInAck (1)}    -- optional parameters

EscapeRegisterCancel ::= BIT STRING
{
    privateData      (0),    -- optional parameters
    privateDataInAck (1)}    -- optional parameters

EscapeRegisterAbort ::= BIT STRING
{
    privateData      (0),    -- optional parameters
    privateDataInAck (1)}    -- optional parameters

Escape ::= BIT STRING
{
    privateDataInAck      ( 0),    -- optional parameters
    swFunctionSupportsSending ( 1),    -- misc characteristics
    swFunctionSupportsReceiving ( 2)}    -- misc characteristics

PrivateDataVersionSelection ::= BIT STRING
{
    privateDataInAck      ( 0)}    -- optional parameters

VendorSpecificEvtsList ::= SEQUENCE
{
    privateEvent [0] IMPLICIT PrivateEvent OPTIONAL}

PrivateEvent ::= BIT STRING

-- other Types

DeviceIDFormat ::= BIT STRING
{
    dialableDigitsAsterix      ( 0),
    dialableDigitsHash         ( 1),
    dialableDigitsABCD         ( 2),
    dialableDigitsExclamation  ( 3),
    dialableDigitsP            ( 4),
    dialableDigitsT            ( 5),
    dialableDigitsComma        ( 6),
    dialableDigitsW            ( 7),
    dialableDigitsAt           ( 8),
    dialableDigitsDollar       ( 9),
    dialableDigitsSemicolon    (10),
    sFReprExclamation          (11),
    sFReprEt                   (12),
    sFReprSlash                (13),
    sFReprPercent              (14),
    sFReprNM                   (15),
    sFReprGeneric              (16),
    sFReprImplicitTON          (17),
    sFReprPubTONUnkown         (18),
    sFReprPubTONInternal       (19),
    sFReprPubTONNational       (20),
    sFReprPubTONSubscriber     (21),
    sFReprPubTONAbbreviated    (22),
    sFReprPriTONUnknown        (23),
    sFReprPriTONLevel3         (24),
    sFReprPriTONLevel2         (25),
    sFReprPriTONLevel1         (26),
    sFReprPriTONLocal          (27),
    sFReprPriTONAbbreviated    (28),
    sFReprOther                (29),
    deviceNumber               (30)}

SwDomainFeatures ::= BIT STRING
```

```
{      isForwardingBefore      ( 0),
      isForwardingAfter        ( 1),
      swFunctionDefaultSettings ( 2),
      userSpecific              ( 3),
      userSpecificDefaultFowardingType ( 4),
      userSpecificDefaultForwardDestination ( 5),
      negativeAcknowledgment    ( 6),
      supportFailedWithAssConn   ( 7),
      supportFailedWithoutAssConn ( 8),
      supportFailedWithAssConnNotReportet ( 9),
      recall                     (10),
      callBack                   (11),
      extCallsIncoming           (12),
      extCallsOutgoing           (13),
      prompting                  (14)}
```

SwAppearanceAddressability ::= BIT STRING

```
{      nonAddressable (0),
      addressable     (1)}
```

SwAppearanceTypes ::= BIT STRING

```
{      selectedStandard      (0),
      basicStandard          (1),
      basicBridged           (2),
      exclusiveBridged       (3),
      independentSharedBridged (4),
      interDependentSharedBridged (5)}
```

IgnoreUnsupportedParameters ::= ENUMERATED

```
{      ignoreParameters (0),
      rejectMessage      (1)}
```

PauseTime ::= INTEGER (1..2000)

TimeStampMode ::= BIT STRING

```
{      allEvents      (0),
      allAcks          (1),
      allServReqs      (2)}
```

MiscMonitorCaps ::= BIT STRING

```
{      groupInclusivModel (0),
      groupExclusiveModel (1),
      monitorPhysicalElement (2),
      acdDeviceInclusiv (3),
      acdDeviceExclusiv (4)
}
```

MaxLengthParameters ::= SEQUENCE

```
{      accountInfo      INTEGER (0..32),
      authCode           INTEGER (0..32),
      agentID            INTEGER (0..32),
      agentPassword      INTEGER (0..32),
      callIDInConnectionID INTEGER (0..8),
      correlatorData     INTEGER (0..32),
      privateData        INTEGER,
      deviceIdentifiers  INTEGER (0..128),
      userData           INTEGER (0..256),
      buttonLabel        INTEGER (0..64),
      lampLabel          INTEGER (0..64),
      charactersToSend   INTEGER (0..64)}
```

FilterThreshold ::= SEQUENCE

```
{      getLogicalDeviceInformation  INTEGER,
      getPhysicalDeviceInformation  INTEGER,
      getSwitchingFunctionCaps     INTEGER,
      getSwitchingFunctionDevices  INTEGER,
      switchingFunctionDevices     INTEGER,
      changeSystemStatusFilter     INTEGER,
```

systemStatusRegister	INTEGER,
systemStatusRegisterAbort	INTEGER,
systemStatusRegisterCancel	INTEGER,
requestSystemStatus	INTEGER,
systemStatus	INTEGER,
switchingFunctionCapsChanged	INTEGER,
switchingFunctionDevsChanged	INTEGER,
changeMonitorFilter	INTEGER,
monitorStart	INTEGER,
monitorStop	INTEGER,
snapshotCall	INTEGER,
snapshotDevice	INTEGER,
snapshotCallData	INTEGER,
snapshotDeviceData	INTEGER,
acceptCall	INTEGER,
alternateCall	INTEGER,
answerCall	INTEGER,
callBackCallRelated	INTEGER,
callBackMessageCallRelated	INTEGER,
campOnCall	INTEGER,
clearCall	INTEGER,
clearConnection	INTEGER,
conferenceCall	INTEGER,
consultationCall	INTEGER,
deflectCall	INTEGER,
dialDigits	INTEGER,
directedPickupCall	INTEGER,
groupPickupCall	INTEGER,
holdCall	INTEGER,
intrudeCall	INTEGER,
joinCall	INTEGER,
makeCall	INTEGER,
makePredictiveCall	INTEGER,
parkCall	INTEGER,
reconnectCall	INTEGER,
retrieveCall	INTEGER,
singleStepConferenceCall	INTEGER,
singleStepTransferCall	INTEGER,
transferCall	INTEGER,
associateData	INTEGER,
cancelTelephonyTone	INTEGER,
generateDigits	INTEGER,
generateTelephonyTone	INTEGER,
sendUserInformation	INTEGER,
startDTMFDigitsCollection	INTEGER,
startTelephonyTonesCollection	INTEGER,
stopDTMFDigitsCollection	INTEGER,
stopTelephonyTonesCollection	INTEGER,
attachMediaService	INTEGER,
detachMediaService	INTEGER,
routeRegister	INTEGER,
routeRegisterAbort	INTEGER,
routeRegisterCancel	INTEGER,
reRoute	INTEGER,
routeEnd	INTEGER,
routeReject	INTEGER,
routeRequest	INTEGER,
routeSelect	INTEGER,
routeUsed	INTEGER,
buttonPress	INTEGER,
getAuditoryApparatusInfo	INTEGER,
getButtonInformation	INTEGER,
getDisplay	INTEGER,
getHookswitchStatus	INTEGER,
getLampInformation	INTEGER,
getLampMode	INTEGER,
getMicrophoneGain	INTEGER,
getMicrophoneMute	INTEGER,

getMessageWaitingIndicator	INTEGER,
getRingerStatus	INTEGER,
getSpeakerMute	INTEGER,
getSpeakerVolume	INTEGER,
setButtonInformation	INTEGER,
setDisplay	INTEGER,
setHookswitchStatus	INTEGER,
setLampMode	INTEGER,
setMsgWaitingIndicator	INTEGER,
setMicrophoneGain	INTEGER,
setMicrophoneMute	INTEGER,
setRingerStatus	INTEGER,
setSpeakerMute	INTEGER,
setSpeakerVolume	INTEGER,
callBackMessageNonCallRelated	INTEGER,
callBackNonCallRelated	INTEGER,
cancelCallBack	INTEGER,
cancelCallBackMessage	INTEGER,
getAgentState	INTEGER,
getAutoAnswer	INTEGER,
getAutoWorkMode	INTEGER,
getCallerIDStatus	INTEGER,
getDoNotDisturb	INTEGER,
getForwarding	INTEGER,
getLastNumberDialed	INTEGER,
getRouteingMode	INTEGER,
setAgentState	INTEGER,
setAutoAnswer	INTEGER,
setAutoWorkMode	INTEGER,
setCallerIDStatus	INTEGER,
setDoNotDisturb	INTEGER,
setForwarding	INTEGER,
setRouteingMode	INTEGER,
backInService	INTEGER,
deviceCaosChanged	INTEGER,
outOfService	INTEGER,
ioRegister	INTEGER,
ioRegisterAbort	INTEGER,
ioRegisterCancel	INTEGER,
dataPathResumed	INTEGER,
dataPathSuspended	INTEGER,
fastData	INTEGER,
resumeDataPath	INTEGER,
sendBroadcastData	INTEGER,
sendData	INTEGER,
sendMulticastData	INTEGER,
startDataPath	INTEGER,
stopDataPath	INTEGER,
suspendDataPath	INTEGER,
concatenateMsg	INTEGER,
deleteMsg	INTEGER,
playMsg	INTEGER,
queryVoiceAttribute	INTEGER,
recordMsg	INTEGER,
reposition	INTEGER,
resume	INTEGER,
review	INTEGER,
setVoiceAttribute	INTEGER,
stop	INTEGER,
suspend	INTEGER,
synthesizeMsg	INTEGER,
cDRNotification	INTEGER,
cDRReport	INTEGER,
sendStoredCDRs	INTEGER,
startCDRTransmission	INTEGER,
stopCDRTransmission	INTEGER,
escapeRegister	INTEGER,
escapeRegisterAbort	INTEGER,

```

        escapeRegisterCancel      INTEGER,
        escape                    INTEGER,
        privateDataVersion        INTEGER}

MediaServiceCapsList ::= SEQUENCE OF SEQUENCE
{
    mediaServiceType      MediaServiceType,
    mediaServiceVersion   INTEGER
    mediaServiceInstance  MediaServiceInstanceID OPTIONAL,
    connectionMode        ConnectionModeBMap    OPTIONAL,
    mediaStreamIDSupported BOOLEAN}

DeviceCategory ::= ENUMERATED
{
    acd                ( 0 ),
    group              ( 1 ),
    networkInterface   ( 2 ),
    park               ( 3 ),
    routeingDevice     ( 4 ),
    station            ( 5 ),
    voiceUnit          ( 6 ),
    other              ( 7 )}

GroupDeviceAttributes ::= BIT STRING
{
    acd      ( 0 ),
    hunt     ( 1 ),
    pick     ( 2 ),
    other    ( 3 )}

NamedDeviceTypes ::= ENUMERATED
{
    acd                ( 0 ),
    acdGroup           ( 1 ),
    button             ( 2 ),
    buttonGroup        ( 3 ),
    conferenceBridge   ( 4 ),
    line               ( 5 ),
    lineGroup          ( 6 ),
    operator           ( 7 ),
    operatorGroup      ( 8 ),
    parkingDevice      ( 9 ),
    station            (10),
    stationGroup       (11),
    trunk              (12),
    trunkGroup         (13),
    other              (14),
    otherGroup         (15)}

ACDModels ::= BIT STRING
{
    visibleACDRelatedDevices      (0),
    nonVisibleACDRelatedDevices   (1)}

AgentLogOnModels ::= BIT STRING
{
    logOnToACDDevice              ( 0 ),
    logOnToACDGroupExplOneStep    ( 1 ),
    logOnToACDGroupExplTwoSteps   ( 2 ),
    logOnToACDImplOneStep         ( 3 )}

AppearanceType ::= ENUMERATED
{
    selectedStandard      ( 0 ),
    basicStandard         ( 1 ),
    basicBridged          ( 2 ),
    exclusiveBridged      ( 3 ),
    independentSharedBridged ( 4 ),
    interdependentSharedBridged ( 5 )}

TransAndConfSetup ::= BIT STRING
{
    consultationCall      ( 0 ),
    holdCallMakeCall      ( 1 ),
    alternateCall          ( 2 ),
    twoCallsInHold        ( 3 ),
```

```
twoCallsInConnected      ( 4)}
```

```
END  -- of CSTA-capability-exchange
```



## 9.11 Call Detail Record

```
CSTA-call-detail-record
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-detail-record( 132) }

DEFINITIONS ::=
BEGIN

EXPORTS
CDRCrossRefID, CDRInfo, CDRReason, CDRTermReason, CDRTIMEPERIOD,
CDRTransferMode;

IMPORTS
DeviceID, CalledDeviceID, CallingDeviceID, AssociatedCalledDeviceID,
  AssociatedCallingDeviceID, NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
TimeInfo FROM CSTA-security
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) security( 128) }
CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
DeviceCategory, NamedDeviceTypes FROM CSTA-capability-exchange
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) capability-exchange( 131) }
ChargingInfo FROM CSTA-charge-info
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charge-info( 133) }
MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) }
;

CDRCrossRefID ::= OCTET STRING (SIZE(0..4))

CDRReason ::= ENUMERATED
{
  timeout                (0),
  thresholdReached       (1),
  other                   (2)}

CDRInfo ::= SEQUENCE OF CDRInformationItem

CDRInformationItem ::= SEQUENCE
{
  recordNumber            INTEGER (1..128)                OPTIONAL,
  recordCreationTime      TimeInfo,                      OPTIONAL,
  callingDevice           CallingDeviceID                 OPTIONAL,
  calledDevice            CalledDeviceID                  OPTIONAL,
  associatedCallingDevice AssociatedCallingDeviceID        OPTIONAL,
  associatedCalledDevice  AssociatedCalledDeviceID         OPTIONAL,
  networkCallingDevice    NetworkCallingDeviceID          OPTIONAL,
  networkCalledDevice     NetworkCalledDeviceID           OPTIONAL,
  callCharacteristics     [0] IMPLICIT CallCharacteristics OPTIONAL,
  mediaCallCharacteristics [1] IMPLICIT MediaCallCharacteristics OPTIONAL,
  chargedDevice           [2] ChargedDevice               OPTIONAL,
  recordedCall            ConnectionID                     OPTIONAL,
  nodeNumber              [3] IMPLICIT NodeNumber         OPTIONAL,
  tariffTable             [4] IMPLICIT INTEGER            OPTIONAL,
  connectionStart         [5] IMPLICIT TimeInfo           OPTIONAL,
  connectionEnd           [6] IMPLICIT TimeInfo           OPTIONAL,
```

```

        connectionDuration      [7] IMPLICIT INTEGER          OPTIONAL,
        accessCode               [8] IMPLICIT OCTET STRING    OPTIONAL,
        carrier                   [9] IMPLICIT INTEGER         OPTIONAL,
        selectedRoute             [10] IMPLICIT INTEGER        OPTIONAL,
        billingID                 [11] IMPLICIT BillingID       OPTIONAL,
        chargingInfo              [12] IMPLICIT ChargingInfo   OPTIONAL,
        supplServiceInfo          [13] IMPLICIT SupplServiceInfo OPTIONAL,
        reasonForTerm             [14] IMPLICIT ReasonForTerm  OPTIONAL,
        authCode                  [15] IMPLICIT AuthCode       OPTIONAL,
        accountInfo               [16] IMPLICIT AccountInfo    OPTIONAL,
        deviceCategory            [17] IMPLICIT DeviceCategory  OPTIONAL,
        namedDeviceTypes          [18] IMPLICIT NamedDeviceTypes OPTIONAL,
        operatorDevice            [19] DeviceID                OPTIONAL}

ChargedDevice ::= CHOICE
{
    operator          [0] IMPLICIT DeviceID,
    nonOperator       [1] IMPLICIT DeviceID}

NodeNumber ::= SEQUENCE
{
    area0    [0] IMPLICIT INTEGER OPTIONAL,
    area1    [1] IMPLICIT INTEGER OPTIONAL,
    area2    [2] IMPLICIT INTEGER OPTIONAL}

BillingID ::= ENUMERATED
{
    normalCharging          (0),
    reverseCharging         (1),
    creditCardCharging      (2),
    callForwarding          (3),
    callDeflection          (4),
    callTransfer            (5),
    other                   (6)}

SupplServiceInfo ::= BIT STRING
{
    normalCall              (0),
    consultationCall        (1),
    transferCall            (2),
    callCompletion          (3),
    callForwarding          (4),
    callDiversion           (5),
    conferencing            (6),
    intrusion               (7),
    userUserInfo            (8),
    other                   (9)}

ReasonForTerm ::= ENUMERATED
{
    normalClearing          (0),
    unsuccessfulCallAttempt (1),
    abnormalTermination     (2),
    callTransferred         (3),
    other                   (4)}

CDRTimePeriod ::= SEQUENCE
{
    beginningOfCDR  TimeInfo,
    endOfCDR        TimeInfo}

CDRTransferMode ::= ENUMERATED
{
    transferAtEndOfCall      (0),
    transferOnRequest        (1),
    transferOnThresholdReached (2)}

CDRTermReason ::= ENUMERATED
{
    endOfDataDetected       (0),
    errorDetected           (1),
    thresholdReached        (2),
    other                   (3)}

END -- of CSTA-call-detail-record
```

## 9.12 Charge information

```
CSTA-charge-info
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charge-info( 133) }

DEFINITIONS ::=
BEGIN

EXPORTS
ChargingInfo;

ChargingInfo ::= SEQUENCE
{
    numberUnits          NumberUnits,
    typeOfChargingInfo   ENUMERATED
    {
        subTotal        (0),
        total            (1)
    }
}

NumberUnits ::= CHOICE
{
    numberOfChargeUnits   [0] IMPLICIT NumberOfChargingUnits,
    numberOfCurrencyUnits [1] IMPLICIT NumberOfCurrencyUnits}

NumberOfChargingUnits ::= SEQUENCE OF SEQUENCE
{
    chargingUnits   INTEGER,
    typeOfUnits     OCTET STRING OPTIONAL }

NumberOfCurrencyUnits ::= SEQUENCE
{
    currencyType      OCTET STRING,          -- size 0 indicates default currency
    currencyAmount     INTEGER,
    currencyMultiplier ENUMERATED
    {
        oneThousandth      (0),
        oneHundredth        (1),
        oneTenth            (2),
        one                  (3),
        ten                  (4),
        hundred              (5),
        thousand             (6)
    }
}

END -- of CSTA-charge-info
```

### 9.13 Data call types

```
CSTA-data-call-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-call-types( 134) }

DEFINITIONS ::=
BEGIN

EXPORTS
  NumberOfChannels, MaxChannelBind, ConnectionRateList, DelayToleranceList;

NumberOfChannels          ::= INTEGER

MaxChannelBind            ::= INTEGER

ConnectionRateList ::= SEQUENCE OF INTEGER

DelayToleranceList ::= SEQUENCE OF INTEGER

END      -- of CSTA-data-call-types
```

## 9.14 Escape types

```
CSTA-escape-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-types( 135) }

DEFINITIONS ::=
BEGIN
EXPORTS
EscapeRegisterID;

EscapeRegisterID ::= [0] OCTET STRING (SIZE(0..4))

END -- of CSTA-escape-types
```

## 9.15 Media services

```
CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) }

DEFINITIONS ::=
BEGIN

EXPORTS
ConnectionInformation, ConnectionMode, ConnectionModeBMap, MediaCallCharacteristics,
MediaServiceInstanceID, MediaServiceType, MediaStreamID, MediaClass;

MediaServiceType ::= ENUMERATED
{
  cstaVoiceUnit                                ( 0),
  dataModem                                    ( 1),
  digitalDataIsochronousIeee1394              ( 2),
  digitalDataIsochronousGeoport               ( 3),
  digitalDataIsochronousIeeeAtm               ( 4),
  digitalDataIsochronousIeeeIsdn              ( 5),
  digitalDataApi                              ( 6),
  ectfS100MediaServicesDefault                ( 7),
  ectfS100MediaServicesAppServices           ( 8),
  cstaIVRScript1                             ( 9),
  cstaIVRScript2                             (10),
  cstaIVRScript3                             (11),
  cstaIVRScript4                             (12),
  cstaIVRScript5                             (13),
  cstaIVRScript6                             (14),
  cstaIVRScript7                             (15),
  cstaIVRScript8                             (16),
  cstaIVRScript9                             (17),
  cstaIVRScript10                            (18),
  liveSoundCaptureAnalog                     (19),
  liveSoundTransmitAnalog                    (20),
  liveSoundCaptureIeee1394                   (21),
  liveSoundTransmitIeee1394                  (22),
  liveSoundCaptureTransmitGeoport            (23),
  liveSoundCaptureTransmitAtm                (24),
  liveSoundCaptureTransmitISDN               (25),
  soundCaptureTransmitADPCM                  (26),
  soundCaptureTransmitApi                    (27),
  usb                                         (28),
  sfSpecific1                                (29),
  sfSpecific2                                (30),
  sfSpecific3                                (31),
  sfSpecific4                                (32),
  sfSpecific5                                (33),
  sfSpecific6                                (34),
  sfSpecific7                                (35),
  sfSpecific8                                (36),
  sfSpecific9                                (37),
  sfSpecific10                               (38)}

MediaStreamID ::= OCTET STRING
MediaServiceInstanceID ::= OCTET STRING (SIZE(0..64))

ConnectionInformation ::= SEQUENCE
{
  flowDirection          ENUMERATED
  {
    transmit              (0),
    receive               (1),
    transmitAndReceive    (2)
  } OPTIONAL,
  numberOfChannels       INTEGER    DEFAULT 1 }

ConnectionMode ::= ENUMERATED
{
  consultationConference      (0),
  consultationConferenceHold  (1),
```

```
deflect                (2),
directedPickup          (3),
join                    (4),
singleStepConference    (5),
singleStepConferenceHold (6),
singleStepTransfer      (7),
transfer                (8),
direct                  (9)}

ConnectionModeBMap ::= BIT STRING
{
    consultationConference    (0),
    consultationConferenceHold (1),
    deflect                  (2),
    directedPickup            (3),
    join                      (4),
    singleStepConference      (5),
    singleStepConferenceHold  (6),
    singleStepTransfer        (7),
    transfer                  (8),
    direct                    (9)}

MediaCallCharacteristics ::= SEQUENCE
{
    mediaClass             MediaClass,
    connectionRate         [0] IMPLICIT INTEGER OPTIONAL,
                                -- value 0 indicates that
                                -- the connection rate is
                                -- unknown
    bitrate                [1] IMPLICIT ENUMERATED
                                {
                                    constant (0),
                                    variable (1)} DEFAULT constant,
    delayTolerance         [2] IMPLICIT INTEGER OPTIONAL,
    switchingSubDomainCCIEType [3] IMPLICIT ENUMERATED {
                                                isdn      (0),
                                                atm        (1),
                                                isoEthernet (2),
                                                rsvp        (3),
                                                other       (4)
                                            } OPTIONAL,
    switchingSubDomainInformationElements OCTET STRING OPTIONAL
    -- is mandatory, if the switchingSubDomainCCIEType is present,
    -- should be ignored otherwise
}

MediaClass ::= BIT STRING
{
    voice      (0),
    data       (1),
    image      (2),
    audio      (4),
    other      (3),
    notKnown   (5)}

END      -- of CSTA-media-services
```

## 9.16 Physical device features

```
CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) }

DEFINITIONS ::=
BEGIN

EXPORTS
AuditoryApparatusID, AuditoryApparatusList, ButtonID, CharacterSet, DisplayID, LampBrightness,
LampColor, LampID, LampMode, MicGainAbs, MicrophoneGain, RingerID, RingMode,
VolAbs, Volume, HookswitchID;

AuditoryApparatusList ::= SEQUENCE OF
    SEQUENCE {
        auditoryApparatus AuditoryApparatusID,
        auditoryApparatusType ENUMERATED {
            speakerphone (0),
            handset (1),
            headset (2),
            speakerOnlyPhone (3),
            other (4)
        },
        speaker BIT STRING {
            present (0),
            volumeSettable (1),
            volumeReadable (2),
            muteSettable (3),
            muteReadable (4)
        },
        microphone BIT STRING {
            present (0),
            gainSettable (1),
            gainReadable (2),
            muteSettable (3),
            muteReadable (4)
        },
        hookswitch BIT STRING {
            hookswitchSettable (0),
            hookswitchOnHook (1)
        },
        hookswitchID HookswitchID
    }

AuditoryApparatusID ::= OCTET STRING (SIZE(0..4))

ButtonID ::= OCTET STRING (SIZE(0..4))

CharacterSet ::= ENUMERATED
{
    ascii (0),
    unicode (1),
    proprietary (2)
}

DisplayID ::= OCTET STRING (SIZE(0..4))

HookswitchID ::= OCTET STRING (SIZE(0..4))

LampBrightness ::= ENUMERATED
{
    unspecified (0),
    dim (1),
    bright (2)
}
```



```
LampColor ::= INTEGER
{
    noColor (0),
    red      (1),
    yellow   (2),
    green     (3),
    blue      (4),
    unknown   (5)} (0..100)

LampID ::= OCTET STRING (SIZE(0..4))

LampMode ::= INTEGER
{
    brokenFlutter (0),
    flutter       (1),
    off           (2),
    steady        (3),
    wink          (4),
    unknown       (5)} (0..100)

MicrophoneGain ::= CHOICE
{
    micGainAbs      MicGainAbs,
    micGainInc      MicGainInc}

MicGainInc ::= ENUMERATED
{
    increment (0),
    decrement (1)}

MicGainAbs ::= INTEGER (0..100)

RingerID ::= OCTET STRING (SIZE(0..4))

RingMode ::= ENUMERATED
{
    ringing      (0),
    notRinging   (1)}

Volume ::= CHOICE
{
    volAbs  VolAbs,
    volInc  VolInc}

VolInc ::= ENUMERATED
{
    increment (0),
    decrement (1)}

VolAbs ::= INTEGER (0..100)

END -- of CSTA-physical-device-feature
```

## 9.17 Data Collection

```
CSTA-data-collection
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) data-collection( 138) }

DEFINITIONS ::=
BEGIN

EXPORTS
DcollCrossRefID;

DcollCrossRefID ::= OCTET STRING (SIZE(0..4))

END -- of CSTA-data-collection
```

### 9.18 Event Cause

```
CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }

DEFINITIONS ::=
BEGIN

EXPORTS
EventCause;

EventCause ::= ENUMERATED
-- a general list of cause codes
--
--
--
{
    acDBusy
    acDForward
    acDSaturated
    activeParticipation
    alertTimeExpired
    alternate
    autoWork
    blocked
    busy
    callBack
    callCancelled
    callForward
    callForwardImmediate
    callForwardBusy
    callForwardNoAnswer
    callNotAnswered
    callPickup
    campOn
    campOnTrunks
    characterCountReached
    conference
    consultation
    destDetected
    destNotObtainable
    destOutOfOrder
    distributed
    distributionDelay
    doNotDisturb
    dTMFDigitDetected
    durationExceeded
    endOfMessageDetected
    enteringDistribution
    forcedPause
    forcedTransition
    incompatibleDestination
    intrude
    invalidAccountCode
    invalidNumberFormat
    joinCall
    keyOperation
    keyOperationInUse
    lockout
    maintenance
    makeCall
    makePredictiveCall
    messageDurationExceeded
    messageSizeExceeded
    multipleAlerting
    multipleQueuing
    networkCongestion
    networkDialling
    networkNotObtainable
    networkOutOfOrder
```

```
networkSignal                (46),
newCall                      (22),
nextMessage                  (47),
noAvailableAgents           (23),
normal                      (78),
normalClearing               (48),
noSpeechDetected             (49),
notAvaliableBearerService    (79),
notSupportedBearerService    (80),
numberChanged                (50),
numberUnallocated            (81),
overflow                     (26),
override                     (24),
park                         (25),
queueCleared                 (82),
recall                      (27),
redirected                   (28),
remainsInQueue               (83),
reorderTone                  (29),
reserved                     (84),
resourcesNotAvailable        (30),
selectedTrunkBusy            (85),
silentParticipation          (31),
singleStepConference          (51),
singleStepTransfer           (52),
speechDetected               (53),
suspend                      (86),
switchingFunctionTerminated  (54),
terminationCharacterReceived (55),
timeout                      (56),
transfer                     (32),
trunksBusy                   (33),
unauthorisedBearerService    (87)}
-- voiceUnitInitiator        (34) }
-- *** note that the voiceUnitOriginator (34) is no longer used (commented out) ***

END -- of event-cause-definitions
```

## 9.19 Error Value

```

CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }

DEFINITIONS ::=
BEGIN

EXPORTS
UniversalFailure, universalFailure, ErrorValue;

IMPORTS

ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)};

universalFailure ERROR ::=
{
  PARAMETER      UniversalFailure
  CODE           local:1
}

ErrorValue ::= UniversalFailure

UniversalFailure ::= CHOICE
{
  operation                [0] OperationErrors,
  security                  [1] SecurityErrors,
  stateIncompatibility      [2] StateIncompatibilityErrors,
  systemResourceAvailability [3] SystemResourceAvailabilityErrors,
  subscribedResourceAvailability [4] SubscribedResourceAvailabilityErrors,
  performanceManagement     [5] PerformanceManagementErrors,
  privateData               [6] PrivateDataInfoErrors,
  unspecified                [7] UnspecifiedErrors}

OperationErrors ::= ENUMERATED -- in CSTA2 added in CSTA3
{
  generic ( 1),
  atLeastOneConditionalParameterNotProvided (29),
  featureAlreadySet (30),
  invalidMsgID (25),
  invalidParameterValue (31),
  invalidAccountCode (21),
  invalidAgentGroup (32),
  invalidAgentIdentifier (33),
  invalidAgentPassword (34),
  invalidAgentState (35),
  invalidAlertTime (36),
  invalidAllocationState (16),
  invalidAuthCode (22),
  invalidAutoAnswer (37),
  invalidBitRate (38),
  invalidButtonIdentifier (39),
  invalidCallType (42),
  invalidConnectionRate (43),
  invalidConsultPurpose (44),
  invalidCorrelatorData (20),
  invalidCrossRefID (17),
  invalidDelayTolerance (45),
  invalidDestination (14),
  invalidDestinationDetect (46),
  invalidDoNotDisturb (47),
  invalidEscapeCrossRefID (48),
  invalidFeature (15),
  invalidFile (28),
  invalidFlowDirection (49),
  invalidForwardingDestination ( 7),
  invalidForwardingFlag (51),
  invalidForwardingType (52),

```

invalidHookswitchType		(53),
invalidHookswitchComponent		(54),
invalidLampMode		(55),
invalidLampID		(56),
invalidMessageWaitingSetting		(57),
invalidMicrophoneGain		(58),
invalidMicrophoneMute		(59),
invalidMonitorCrossRefID		(60),
invalidMonitorFilter		(61),
invalidMonitorObject		(62),
invalidMonitorType		(63),
invalidNumberOfChannels		(64),
invalidParticipationType		(65),
invalidRemainRetry		(66),
invalidRingCount		(67),
invalidRingPattern		(68),
invalidRingVolume		(69),
invalidRouteingAlgorithm		(70),
invalidRouteingCrossRefID		(71),
invalidRouteRegistrationCrossRefID		(72),
invalidSpeakerVolume		(73),
invalidSpeakerMute		(74),
invalidSwitchingSubdomainCharsType		(75),
invalidObjectType	(18),	
invalidActiveCallObject		(76),
invalidCalledDeviceObjectType		(77),
invalidCallingDeviceObjectType		(78),
invalidCallToBePickedUpObjectType		(79),
invalidCallToDivertObjectType		(80),
invalidCallToParkObjectType		(81),
invalidDestinationDeviceObject		(195),
invalidHeldCallObject		(82),
invalidMonitorObjectType		(83),
invalidParkToObjectType		(84),
messageIDRequired	(26),	
notDifferentDevices		(85),
notSameDevice		(86),
objectNotKnown	( 4),	
invalidCallID	(11),	
invalidActiveCallID		(87),
invalidHeldCallID		(88),
invalidConnectionID	(13),	
invalidActiveConnectionID		(89),
invalidHeldConnectionID		(90),
invalidDeviceID	(12),	
invalidActiveDeviceID		(91),
invalidCalledDeviceID	( 6),	
invalidCallingDeviceID	( 5),	
invalidCallToParkDeviceID		(92),
invalidDestinationDeviceID		(93),
invalidDivertingDeviceID		(94),
invalidHeldDeviceID		(95),
invalidParkToDeviceID		(96),
invalidPickUpDeviceID		(97),
parameterNotSupported		(98),
accountCodeNotSupported		(99),
agentGroupNotSupported		(100),
agentPasswordNotSupported		(101),
agentStateNotSupported		(102),
alertTimeNotSupported		(103),
allocationNotSupported		(104),
authorisationCodeNotSupported		(105),
autoAnswerNotSupported		(106),
bitRateNotSupported		(107),
buttonNotSupported		(108),
callTypeNotSupported		(109),
charactersToSendNotSupported		(110),
connectionRateNotSupported		(111),

connectionReservationNotSupported	(112),
consultPurposeNotSupported	(113),
correlatorDataNotSupported	(114),
delayToleranceNotSupported	(115),
destinationDetectNotSupported	(116),
digitModeNotSupported	(117),
errorValueNotSupported	(118),
flowDirectionNotSupported	(119),
forwardingDestinationNotSupported	(120),
lampNotSupported	(121),
monitorTypeNotSupported	(122),
numberOfChannelsNotSupported	(123),
parameterTypeNotSupported	(124),
priorityNotSupported	(125),
privateDataNotSupported	(126),
pulseDurationNotSupported	(127),
pulseRateNotSupported	(128),
remainRetryNotSupported	(129),
ringCountNotSupported	(130),
routeUsedNotSupported	(131),
securityNotSupported	(132),
swSubdomainCCIETypeNotSupported	(133),
toneDurationNotSupported	(134),
sysStatRegIDNotSupported	(135),
userDataNotSupported	(136),
privilegeViolationSpecifiedDevice( 8),	
privilegeViolationActiveDevice	(137),
privilegeViolationCalledDevice( 9),	
privilegeViolationCallingDevice(10),	
privilegeViolationCallToParkDevice	(138),
privilegeViolationDestinationDevice	(139),
privilegeViolationOnDivertingDevice	(140),
privilegeViolationHeldDevice	(141),
privilegeViolationOnParkToDevice	(142),
privilegeViolationPickUpDevice	(143),
routeingTimerExpired	(144),
requestIncompatibleWithObject	( 2),
requestIncompatibleWithConnection	(145),
requestIncompatibleWithActiveConnection	(146),
requestIncompatibleWithHeldConnection	(147),
requestIncompatibleWithDevice	(148),
requestIncompatibleWithCalledDevice	(24),
requestIncompatibleWithCallingDevice	(23),
requestIncompatibleWithSubjectDevice	(149),
requestIncompatibleWithActiveDevice	(150),
requestIncompatibleWithCallToParkDevice	(151),
requestIncompatibleWithDestinationDevice	(152),
requestIncompatibleWithDivertingDevice	(153),
requestIncompatibleWithHeldDevice	(154),
requestIncompatibleWithMedia	(27),
requestIncompatibleWithParkToDevice	(155),
requestIncompatibleWithPickupDevice	(156),
serviceNotSupported	(50),
securityViolation	(19),
valueOutOfRange	( 3),
agentStateOutOfRange	(157),
alertTimeOutOfRange	(158),
allocationOutOfRange	(159),
autoAnswerOutOfRange	(160),
bitRateOutOfRange	(161),
callTypeOutOfRange	(162),
connectionRateOutOfRange	(163),
connectionReservoationOutOfRange	(164),
consultPurposeOutOfRange	(165),
correlatorDataOutOfRange	(166),
delayToleranceOutOfRange	(167),
destinationDetectOutOfRange	(168),
digitModeOutOfRange	(169),

```
doNotDisturbOutOfRange (170),
flowDirectionOutOfRange (171),
forwardingFlagOutOfRange (172),
forwardingTypeOutOfRange (173),
hookswitchComponentOutOfRange (174),
hookswitchTypeOutOfRange (175),
lampModeOutOfRange (176),
messageWaitingSettingOutOfRange (177),
micGainOutOfRange (178),
micMuteOutOfRange (179),
monitorTypeOutOfRange (180),
numberOfChannelsOutOfRange (181),
participationTypeOutOfRange (182),
pulseDurationOutOfRange (183),
pulseRateOutOfRange (184),
ringCountOutOfRange (185),
ringPatternOutOfRange (186),
ringVolumnOutOfRange (187),
routeingAlgorithmOutOfRange (188),
speakerMuteOutOfRange (189),
speakerVolumeOutOfRange (190),
switchingCcittTypeOutOfRange (191),
systemStatusOutOfRange (192),
toneCharacterOutOfRange (193),
toneDurationOutOfRange (194)}

SecurityErrors ::= ENUMERATED
{
    generic ( 0),
    sequenceNumberViolated ( 1),
    timeStampViolated ( 2),
    securityInfoViolated ( 4)}

StateIncompatibilityErrors ::= ENUMERATED
{
    generic ( 1),
    invalidObjectState ( 2),
    invalidDeviceState (15),
    connectedCallExists (16),
    invalidActiveDeviceState (17),
    invalidCalledDeviceState (18),
    invalidCallingDeviceState (19),
    invalidCallToParkDeviceState (20),
    invalidDestinationDeviceState (21),
    invalidDivertingDeviceState (22),
    invalidHeldDeviceState (23),
    invalidParkToDeviceState (24),
    invalidConnectionState (25),
    invalidActiveConnectionState (26),
    invalidConnectionIDForActiveCall ( 3),
    invalidHeldConnectionState (27),
    noActiveCall ( 4),
    noCallToAnswer ( 8),
    noCallToClear ( 6),
    noCallToComplete ( 9),
    noConnectionToClear ( 7),
    noHeldCall ( 5),
    incorrectMsgState (28),
    beginningOfMsg (13),
    endOfMsg (12),
    msgSuspended (14),
    notAbleToPlay (10),
    notAbleToResume (11)}

SystemResourceAvailabilityErrors ::= ENUMERATED
{
    generic ( 1),
    resourceBusy ( 2),
    internalResourceBusy ( 3),
    classifierBusy ( 9),
    noMediaChannelsAvailable (10),
```



```
channelsInUseForBridgedDevices      (11),
channelsInUseForData                 (12),
toneDetectorBusy                     (13),
toneGeneratorBusy                    (14),
networkBusy                          ( 5),
resourceOutOfService                 ( 4),
deviceOutOfService                   (15),
activeDeviceOutOfService              (16),
calledDeviceOutOfService              (17),
callingDeviceOutOfService             (18),
callToParkDeviceOutOfService         (19),
destinationDeviceOutOfService        (20),
divertingDeviceOutOfService          (21),
heldDeviceOutOfService               (22),
parkToDeviceOutOfService              (23),
pickupDeviceOutOfService              (24),
networkOutOfService                   ( 6),
otherResourceOutOfService             (25),
resourceLimitExceeded                (26),
overallMonitorLimitExceeded          ( 7),
conferenceMemberLimitExceeded        ( 8),
registrationLimitExceeded             (27)}

SubscribedResourceAvailabilityErrors ::= ENUMERATED
{
    generic                          ( 1),
    objectMonitorLimitExceeded      ( 2),
    trunkLimitExceeded              ( 3),
    outstandingReqLimitExceeded     ( 4),
    objectRegistrationLimitExceeded  ( 5)}

PerformanceManagementErrors ::= ENUMERATED
{
    generic                          (1),
    performanceLimitExceeded         (2)}

PrivateDataInfoErrors ::= ENUMERATED
{
    CSTAPrivateDataInfoError(1)}

UnspecifiedErrors ::= NULL

END -- of CSTA-error-definition
```

## 10 Event Report Service

```
CSTA-event-report-definitions
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-report-definitions( 21) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION FROM Remote-Operations-Information-Objects
    { joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
CallClearedEvent FROM CSTA-call-cleared-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-cleared-event( 22) }
ConferencedEvent FROM CSTA-conferenced-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) conferenced-event( 23) }
ConnectionClearedEvent FROM CSTA-connection-cleared-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) connection-cleared-event( 24) }
DeliveredEvent FROM CSTA-delivered-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) delivered-event( 25) }
DivertedEvent FROM CSTA-diverted-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) diverted-event( 26) }
EstablishedEvent FROM CSTA-established-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) established-event( 27) }
FailedEvent FROM CSTA-failed-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) failed-event( 28) }
HeldEvent FROM CSTA-held-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) held-event( 29) }
NetworkReachedEvent FROM CSTA-network-reached-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) network-reached-event( 30) }
OriginatedEvent FROM CSTA-originated-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) originated-event( 31) }
QueuedEvent FROM CSTA-queued-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) queued-event( 32) }
RetrievedEvent FROM CSTA-retrieved-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) retrieved-event( 33) }
ServiceInitiatedEvent FROM CSTA-service-initiated-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) service-initiated-event( 34) }
TransferredEvent FROM CSTA-transferred-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) transferred-event( 35) }
AutoAnswerEvent FROM CSTA-auto-answer-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) auto-answer-event( 40) }
CallInformationEvent FROM CSTA-call-information-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-information-event( 41) }
DoNotDisturbEvent FROM CSTA-do-not-disturb-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) do-not-disturb-event( 42) }
ForwardingEvent FROM CSTA-forwarding-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) forwarding-event( 43) }
MessageWaitingEvent FROM CSTA-message-waiting-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) message-waiting-event( 44) }
```

```
MicrophoneMuteEvent FROM CSTA-microphone-mute-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) microphone-mute-event( 45) }
SpeakerMuteEvent FROM CSTA-speaker-mute-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) speaker-mute-event( 46) }
SpeakerVolumeEvent FROM CSTA-speaker-volume-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) speaker-volume-event( 47) }
AgentBusyEvent FROM CSTA-agent-busy-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) agent-busy-event( 319) }
AgentLoggedInEvent FROM CSTA-agent-logged-on-event
    { iso( 1) identified-organization( 3) icd-ecma( 321)
      standard( 0) csta3( 285) agent-logged-on-event( 321) }
AgentLoggedOffEvent FROM CSTA-agent-logged-off-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) agent-logged-off-event( 320) }
AgentNotReadyEvent FROM CSTA-agent-not-ready-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) agent-not-ready-event( 322) }
AgentReadyEvent FROM CSTA-agent-ready-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) agent-ready-event( 323) }
AgentWorkingAfterCallEvent FROM CSTA-agent-working-after-call-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) agent-working-after-call-event( 324) }
BackInServiceEvent FROM CSTA-back-in-service-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) back-in-service-event( 333) }
OutOfServiceEvent FROM CSTA-out-of-service-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) out-of-service-event( 335) }
PrivateEvent FROM CSTA-private-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) private-event( 71) }
PlayEvent FROM CSTA-play-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) play( 75) }
RecordEvent FROM CSTA-record-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) record( 76) }
ReviewEvent FROM CSTA-review-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) review( 77) }
StopEvent FROM CSTA-stop-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) stop( 78) }
SuspendPlayEvent FROM CSTA-suspend-play-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) suspend-play( 79) }
SuspendRecordEvent FROM CSTA-suspend-record-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) suspend-record( 80) }
VoiceAttributesChangeEvent FROM CSTA-voice-attributes-change-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) voice-attributes-change-event( 74) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
BridgedEvent FROM CSTA-bridged-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) bridged-event( 224) }
DigitsDialedEvent FROM CSTA-digits-dialed-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) digits-dialed-event( 225) }
NetworkCapabilitiesChangedEvent FROM CSTA-network-capabilities-changed-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
```

```
        standard( 0) csta3( 285) network-capabilities-changed-event( 226) }
OfferedEvent FROM CSTA-offered-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) offered-event( 227) }
ChargingEvent FROM CSTA-charging-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) charging-event( 240) }
DigitsGeneratedEvent FROM CSTA-digits-generated-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) digits-generated-event( 241) }
TelephonyTonesGeneratedEvent FROM CSTA-telephony-tones-generated-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) telephony-tones-generated-event( 242) }
ServiceCompletionFailureEvent FROM CSTA-service-completion-failure-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) service-completion-failure-event( 243) }
MediaAttachedEvent FROM CSTA-media-attached-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-attached-event( 246) }
MediaDetachedEvent FROM CSTA-media-detached-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-detached-event( 247) }
ButtonInformationEvent FROM CSTA-button-information-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) button-information-event( 283) }
ButtonPressEvent FROM CSTA-button-press-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) button-press-event( 284) }
DisplayUpdatedEvent FROM CSTA-display-updated-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) display-updated-event( 285) }
HookswitchEvent FROM CSTA-hookswitch-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) hookswitch-event( 286) }
LampModeEvent FROM CSTA-lamp-mode-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) lamp-mode-event( 287) }
MicrophoneGainEvent FROM CSTA-microphone-gain-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) microphone-gain-event( 288) }
RingerStatusEvent FROM CSTA-ringer-status-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) ringer-status-event( 289) }
AutoWorkModeEvent FROM CSTA-auto-work-mode-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) auto-work-mode-event( 326) }
CallBackEvent FROM CSTA-call-back-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-back-event( 327) }
CallBackMessageEvent FROM CSTA-call-back-message-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-back-message-event( 328) }
CallerIDStatusEvent FROM CSTA-caller-id-status-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) caller-id-status-event( 329) }
RouteingModeEvent FROM CSTA-routeing-mode-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) routeing-mode-event( 332) }
DeviceCapsChangedEvent FROM CSTA-device-capabilities-changed-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-capabilities-changed-event( 334) }
;

cSTAEventReport      OPERATION ::=
{
    ARGUMENT      CSTAEventReportArgument
    ALWAYS RESPONDS      FALSE
    CODE              local:21
}
}
```

```
CSTAEventReportArgument ::= SEQUENCE
{
    crossRefIdentifier      MonitorCrossRefID,
    eventSpecificInfo       EventSpecificInfo}

EventSpecificInfo ::= CHOICE
{
    callControlEvents      [0] CallControlEvents,
    callAssociatedEvents    [1] CallAssociatedEvents,
    mediaAttachmentEvents  [2] MediaAttachmentEvents,
    physicalDeviceFeatureEvents [3] PhysicalDeviceFeatureEvents,
    logicalDeviceFeatureEvents [4] LogicalDeviceFeatureEvents,
    deviceMaintenanceEvents [5] DeviceMaintenanceEvents,
    voiceUnitEvents        [6] VoiceUnitEvents,
    vendorSpecEvents       [7] VendorSpecEvents}

CallControlEvents ::= CHOICE
{
    bridged                [ 0] IMPLICIT BridgedEvent,
    callCleared            [ 1] IMPLICIT CallClearedEvent,
    conferenced            [ 2] IMPLICIT ConferencedEvent,
    connectionCleared      [ 3] IMPLICIT ConnectionClearedEvent,
    delivered              [ 4] IMPLICIT DeliveredEvent,
    digitsDialed           [ 5] IMPLICIT DigitsDialedEvent,
    diverted               [ 6] IMPLICIT DivertedEvent,
    established            [ 7] IMPLICIT EstablishedEvent,
    failed                 [ 8] IMPLICIT FailedEvent,
    held                   [ 9] IMPLICIT HeldEvent,
    networkCapabilitiesChanged [10] IMPLICIT NetworkCapabilitiesChangedEvent,
    networkReached         [11] IMPLICIT NetworkReachedEvent,
    offered                [12] IMPLICIT OfferedEvent,
    originated             [13] IMPLICIT OriginatedEvent,
    queued                 [14] IMPLICIT QueuedEvent,
    retrieved              [15] IMPLICIT RetrievedEvent,
    serviceInitiated       [16] IMPLICIT ServiceInitiatedEvent,
    transferred            [17] IMPLICIT TransferredEvent}

CallAssociatedEvents ::= CHOICE
{
    callInformation        [ 0] IMPLICIT CallInformationEvent,
    charging               [ 1] IMPLICIT ChargingEvent,
    digitsGeneratedEvent   [ 2] IMPLICIT DigitsGeneratedEvent,
    telephonyTonesGeneratedEvent [ 3] IMPLICIT TelephonyTonesGeneratedEvent,
    serviceCompletionFailure [ 4] IMPLICIT ServiceCompletionFailureEvent}

MediaAttachmentEvents ::= CHOICE
{
    mediaAttached          [ 0] IMPLICIT MediaAttachedEvent,
    mediaDetached          [ 1] IMPLICIT MediaDetachedEvent}

PhysicalDeviceFeatureEvents ::= CHOICE
{
    buttonInformation      [ 0] IMPLICIT ButtonInformationEvent,
    buttonPress            [ 1] IMPLICIT ButtonPressEvent,
    displayUpdated         [ 2] IMPLICIT DisplayUpdatedEvent,
    hookswitch             [ 3] IMPLICIT HookswitchEvent,
    lampMode               [ 4] IMPLICIT LampModeEvent,
    messageWaiting         [ 5] IMPLICIT MessageWaitingEvent,
    microphoneGain         [ 6] IMPLICIT MicrophoneGainEvent,
    microphoneMute         [ 7] IMPLICIT MicrophoneMuteEvent,
    ringerStatus           [ 8] IMPLICIT RingerStatusEvent,
    speakerMute            [ 9] IMPLICIT SpeakerMuteEvent,
    speakerVolume          [10] IMPLICIT SpeakerVolumeEvent}

LogicalDeviceFeatureEvents ::= CHOICE
{
    agentBusy              [ 0] IMPLICIT AgentBusyEvent,
    agentLoggedOn          [ 1] IMPLICIT AgentLoggedOnEvent,
    agentLoggedOff         [ 2] IMPLICIT AgentLoggedOffEvent,
    agentNotReady          [ 3] IMPLICIT AgentNotReadyEvent,
    agentReady             [ 4] IMPLICIT AgentReadyEvent,
    agentWorkingAfterCall  [ 5] IMPLICIT AgentWorkingAfterCallEvent,
    autoAnswer             [ 6] IMPLICIT AutoAnswerEvent,
```

```
autoWorkMode          [ 7] IMPLICIT AutoWorkModeEvent,
callBack              [ 8] IMPLICIT CallBackEvent,
callBackMessage       [ 9] IMPLICIT CallBackMessageEvent,
callerIDStatus        [10] IMPLICIT CallerIDStatusEvent,
doNotDisturb          [11] IMPLICIT DoNotDisturbEvent,
forwarding            [12] IMPLICIT ForwardingEvent,
routeingMode          [13] IMPLICIT RouteingModeEvent}

DeviceMaintenanceEvents ::= CHOICE
{
    backInService      [ 0] IMPLICIT BackInServiceEvent,
    deviceCapabilityChanged [ 1] IMPLICIT DeviceCapsChangedEvent,
    outOfService       [ 2] IMPLICIT OutOfServiceEvent}

VoiceUnitEvents ::= CHOICE
{
    play               [ 0] IMPLICIT PlayEvent,
    record             [ 1] IMPLICIT RecordEvent,
    review             [ 2] IMPLICIT ReviewEvent,
    stop              [ 3] IMPLICIT StopEvent,
    suspendPlay       [ 4] IMPLICIT SuspendPlayEvent,
    suspendRecord     [ 5] IMPLICIT SuspendRecordEvent,
    voiceAttributesChange [ 6] IMPLICIT VoiceAttributesChangeEvent}

VendorSpecEvents ::= CHOICE
{
    privateEvent       [ 0] IMPLICIT PrivateEvent}

END -- of CSTA-event-report-definitions
```

## 11 Capability exchange services

### 11.1 Services

#### 11.1.1 Get logical device information

```
CSTA-get-logical-device-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-logical-device-information( 201) }

DEFINITIONS ::=
BEGIN

IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  { joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
MonitorFilter, MonitorMediaClass FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DeviceCategory, GroupDeviceAttributes, NamedDeviceTypes, ACDModels, AgentLogOnModels,
  AppearanceType, MiscMonitorCaps, TransAndConfSetup, MediaServiceCapsList,
  RouteingServList, LogDevServList, LogDevEvtsList
FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) }
NumberOfChannels, MaxChannelBind, ConnectionRateList, DelayToleranceList
FROM CSTA-data-call-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-call-types( 134) };

getLogicalDeviceInformation OPERATION ::=
{
  ARGUMENT    GetLogicalDeviceInformationArgument
  RESULT      GetLogicalDeviceInformationResult
  ERRORS      {universalFailure}
  CODE        local:201
}

GetLogicalDeviceInformationArgument ::= SEQUENCE
{
  device          DeviceID,
  extensions      CSTACommonArgumentsOPTIONAL}

GetLogicalDeviceInformationResult ::= SEQUENCE
{
  deviceCategory          [ 0] IMPLICIT DeviceCategory          DEFAULT station,
  groupDeviceAttributes   [ 1] IMPLICIT GroupDeviceAttributes OPTIONAL,
  namedDeviceTypes        [ 2] IMPLICIT NamedDeviceTypes        OPTIONAL,
  shortFormDeviceID       [ 3] DeviceID                          OPTIONAL,
  hasPhysicalElement      BOOLEAN,
  acdModels               ACDModels,
  agentLogOnModels        [ 4] IMPLICIT AgentLogOnModels        OPTIONAL,
  appearanceAddressable   BOOLEAN,
  appearanceType          AppearanceType,
  appearanceList          [ 5] IMPLICIT SEQUENCE OF IA5String OPTIONAL,
  otherPhysicalDeviceList [ 6] IMPLICIT SEQUENCE OF DeviceID OPTIONAL,
  miscMonitorCaps         [ 7] IMPLICIT MiscMonitorCaps         OPTIONAL,
  associatedGroupList      [ 8] IMPLICIT SEQUENCE OF DeviceID OPTIONAL,
  maxCallbacks            [ 9] IMPLICIT INTEGER                  OPTIONAL,
  maxAutoAnswerRings      [10] IMPLICIT INTEGER                  OPTIONAL,
  maxActiveCalls          [11] IMPLICIT INTEGER                  OPTIONAL,
```

maxHeldCalls	[12]	IMPLICIT	INTEGER	OPTIONAL,
maxFwdSettings	[13]	IMPLICIT	INTEGER	OPTIONAL,
maxDevicesInConf	[14]	IMPLICIT	INTEGER	OPTIONAL,
transAndConfSetup	[15]	IMPLICIT	TransAndConfSetup	OPTIONAL,
deviceOnDeviceMonitorFilter	[16]	IMPLICIT	MonitorFilter	OPTIONAL,
deviceOnConnectionMonitorFilter	[17]	IMPLICIT	MonitorFilter	OPTIONAL,
callOnDeviceMonitorFilter	[18]	IMPLICIT	MonitorFilter	OPTIONAL,
callOnConnectionMonitorFilter	[19]	IMPLICIT	MonitorFilter	OPTIONAL,
mediaClassSupport	[20]	IMPLICIT	MonitorMediaClass	OPTIONAL,
mediaServiceCapsList	[21]	IMPLICIT	MediaServiceCapsList	OPTIONAL,
connectionRateList	[22]	IMPLICIT	ConnectionRateList	OPTIONAL,
delayToleranceList	[23]	IMPLICIT	DelayToleranceList	OPTIONAL,
numberOfChannels	[24]	IMPLICIT	NumberOfChannels	OPTIONAL,
maxChannelBind	[25]	IMPLICIT	MaxChannelBind	OPTIONAL,
routeingServList	[26]	IMPLICIT	RouteingServList	OPTIONAL,
logDevServList	[27]	IMPLICIT	LogDevServList	OPTIONAL,
logDevEvtsList	[28]	IMPLICIT	LogDevEvtsList	OPTIONAL,
extensions			CSTACommonArguments	OPTIONAL}

END -- of CSTA-get-logical-device-information



### 11.1.2 Get physical device information

```
CSTA-get-physical-device-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-physical-device-information( 202) }

DEFINITIONS ::=
BEGIN

IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
MonitorFilter FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
DeviceCategory, GroupDeviceAttributes, NamedDeviceTypes, PhysDevServList, PhysDevEvtsList
FROM CSTA-capability-exchange
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) capability-exchange( 131) };

getPhysicalDeviceInformation OPERATION ::=
{
    ARGUMENT    GetPhysicalDeviceInformationArgument
    RESULT      GetPhysicalDeviceInformationResult
    ERRORS      {universalFailure}
    CODE        local:202
}

GetPhysicalDeviceInformationArgument ::= SEQUENCE
{
    device      DeviceID,
    extensions  CSTACommonArguments    OPTIONAL}

GetPhysicalDeviceInformationResult ::= SEQUENCE
{
    deviceCategory          [ 0] IMPLICIT DeviceCategory          DEFAULT sta-
tion,
    groupDeviceAttributes   [ 1] IMPLICIT GroupDeviceAttributes   OPTIONAL,
    namedDeviceTypes        [ 2] IMPLICIT NamedDeviceTypes        OPTIONAL,
    hasLogicalElement        BOOLEAN,
    otherLogicalDeviceList  [ 3] IMPLICIT SEQUENCE OF DeviceID    OPTIONAL,
    deviceModelName         [ 4] IMPLICIT IA5String (SIZE(0..64)) OPTIONAL,
    deviceOnDeviceMonitorFilter [ 5] IMPLICIT MonitorFilter        OPTIONAL,
    deviceOnConnectionMonitorFilter [ 6] IMPLICIT MonitorFilter    OPTIONAL,
    callOnDeviceMonitorFilter [ 7] IMPLICIT MonitorFilter          OPTIONAL,
    callOnConnectionMonitorFilter [ 8] IMPLICIT MonitorFilter      OPTIONAL,
    maxDisplays             [ 9] IMPLICIT INTEGER                  OPTIONAL,
    maxButtons              [10] IMPLICIT INTEGER                  OPTIONAL,
    maxLamps                [11] IMPLICIT INTEGER                  OPTIONAL,
    maxRingPatterns         [12] IMPLICIT INTEGER                  OPTIONAL,
    physDevServList         [13] IMPLICIT PhysDevServList          OPTIONAL,
    physDevEvtsList         [14] IMPLICIT PhysDevEvtsList          OPTIONAL,
    extensions              CSTACommonArguments                    OPTIONAL}

END -- of CSTA-get-physical-device-information
```

### 11.1.3 Get switching function capabilities

```
CSTA-get-switching-function-capabilities
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-switching-function-capabilities( 203) }

DEFINITIONS ::=
BEGIN

IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
MonitorMediaClass, MonitorFilter FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
TimeInfo FROM CSTA-security
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) security( 128) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ACDModels, CapExchangeServList, DeviceIDFormat, FilterThreshold,
IgnoreUnsupportedParameters, CallControlServList, CallControlEvtsList,
CallAssociatedServList, CallAssociatedEvtsList, MediaServList, MediaEvtsList,
RouteingServList, PhysDevEvtsList, PhysDevServList, LogicalEvtsList, LogicalServList,
DeviceMaintEvtsList, IOServicesServList, DataCollectionServList, VoiceUnitServList,
VoiceUnitEvtsList, CDRServList, VendorSpecificServList, VendorSpecificEvtsList,
MaxLengthParameters, TransAndConfSetup, MediaServiceCapsList, MiscMonitorCaps,
MonitoringServList, PauseTime, SnapshotServList, SwAppearanceAddressability,
SwAppearanceTypes, SwDomainFeatures, SystemStatusServList, TimeStampMode
FROM CSTA-capability-exchange
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) capability-exchange( 131) }
NumberOfChannels, MaxChannelBind, ConnectionRateList, DelayToleranceList
FROM CSTA-data-call-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-call-types( 134) };

getSwitchingFunctionCapabilities OPERATION ::=
{
  ARGUMENT    GetSwitchingFunctionCapsArgument
  RESULT      GetSwitchingFunctionCapsResult
  ERRORS      {universalFailure}
  CODE        local:203
}

GetSwitchingFunctionCapsArgument ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

GetSwitchingFunctionCapsResult ::= SEQUENCE
{
  switchingSubDomainName      IA5String (SIZE(0..64)),
  manufacturerName            IA5String (SIZE(0..64)),
  profiles                     Profiles,
  deviceIDFormat               DeviceIDFormat,
  swDomainFeatures             SwDomainFeatures,
  swAppearanceAddressability   SwAppearanceAddressability,
  swAppearanceTypes            SwAppearanceTypes,
  ignoreUnsupportedParameters  IgnoreUnsupportedParameters,
  callCharacteristicsSupported [0] IMPLICIT CallCharacteristics      OPTIONAL,
  mediaClassSupport            [1] IMPLICIT MonitorMediaClass        OPTIONAL,
  numberOfChannels              [2] IMPLICIT NumberOfChannels        OPTIONAL,
```

```
maxChannelBind [3] IMPLICIT MaxChannelBind OPTIONAL,
miscMediaCallCharacteristics [4] IMPLICIT MiscMediaCallCharacteristics OPTIONAL,
connectionRateList [5] IMPLICIT ConnectionRateList OPTIONAL,
delayToleranceList [6] IMPLICIT DelayToleranceList OPTIONAL,
pauseTime [7] IMPLICIT PauseTime OPTIONAL,
currentTime [8] IMPLICIT TimeInfo OPTIONAL,
messageSeqNumbers [9] IMPLICIT MessageSeqNumbers OPTIONAL,
timeStampMode [10] IMPLICIT TimeStampMode OPTIONAL,
securityMode [11] IMPLICIT SecurityMode OPTIONAL,
securityFormat [12] IMPLICIT SecurityFormat OPTIONAL,
privateDataFormat [13] IMPLICIT SecurityFormat OPTIONAL,
transAndConfSetup [14] IMPLICIT TransAndConfSetup OPTIONAL,
monitorFilterItems [15] IMPLICIT MonitorFilterItems OPTIONAL,
miscMonitorCaps [16] IMPLICIT MiscMonitorCaps OPTIONAL,
correlatorDataSupported [17] IMPLICIT BOOLEAN OPTIONAL,
dynamicFeatureSupported [18] IMPLICIT DynamicFeatureSupported OPTIONAL,
callLinkageOptions [28] IMPLICIT CallLinkageOptions OPTIONAL,
aCDModels [19] IMPLICIT ACDModels OPTIONAL,
agentLogOnModels [20] IMPLICIT AgentLogOnModels OPTIONAL,
agentStateModels [21] IMPLICIT AgentStateModels OPTIONAL,
connectionView ConnectionView,
maxLengthParameters MaxLengthParameters,
servEvtsList [22] IMPLICIT ServEvtsList OPTIONAL,
privateDataVersionList [23] IMPLICIT PrivateDataVersionList OPTIONAL,
systemStatusTimer [24] IMPLICIT INTEGER (0..180) OPTIONAL,
simpleThreshold [25] IMPLICIT INTEGER OPTIONAL,
filterThreshold [26] IMPLICIT FilterThreshold OPTIONAL,
mediaServiceCapsList [27] IMPLICIT MediaServiceCapsList OPTIONAL,
extensions CSTACCommonArguments OPTIONAL}

MonitorFilterItems ::= SEQUENCE
{
    deviceOnDeviceMonitorFilter [0] IMPLICIT MonitorFilter OPTIONAL,
    deviceOnConnectionMonitorFilter [1] IMPLICIT MonitorFilter OPTIONAL,
    callOnDeviceMonitorFilter [2] IMPLICIT MonitorFilter OPTIONAL,
    callOnConnectionMonitorFilter [3] IMPLICIT MonitorFilter OPTIONAL}

MessageSeqNumbers ::= BIT STRING
{
    allEvents (0),
    allAcks (1),
    allServReqs (2)}

SecurityMode ::= ENUMERATED
{
    allEvents (0),
    allAcks (1),
    allServReqs (2)}

SecurityFormat ::= BIT STRING
{
    octetStringFromSF (0),
    otherTypeFromSF (1),
    octetStringToSF (2),
    otherTypeToSF (3)}

Profiles ::= BIT STRING
{
    basicTelephonyProfile (0),
    routeingProfile (1)}

DynamicFeatureSupported ::= ENUMERATED
{
    none (0),
    all (1),
    some (2)}

CallLinkageOptions ::= BIT STRING
{
    callLinkageFeatureSupported (0),
    threadLinkageFeatureSupported (1) }

AgentLogOnModels ::= BIT STRING
{
    logOnACDDevice (0),
```

```
logOnACDGroupExplOneStep      (1),
logOnACDGroupExplTwoSteps     (2),
logOnACDGroupImplOneStep      (3)}

AgentStateModels ::= BIT STRING
{
    multiState                (0),
    multiStateSemiIndependentLinked (1),
    agentOriented              (2)}

ConnectionView ::= ENUMERATED
{
    fixed      (0),
    local      (1)}

ServEvsList ::= SEQUENCE
{
    capExchangeServList    [ 0] IMPLICIT CapExchangeServList    OPTIONAL,
    systemServList         [ 1] IMPLICIT SystemStatusServList   OPTIONAL,
    monitoringServList     [ 2] IMPLICIT MonitoringServList     OPTIONAL,
    snapshotServList       [ 3] IMPLICIT SnapshotServList       OPTIONAL,
    callControlServList    [ 4] IMPLICIT CallControlServList    OPTIONAL,
    callControlEvsList     [ 5] IMPLICIT CallControlEvsList     OPTIONAL,
    callAssociatedServList  [ 6] IMPLICIT CallAssociatedServList  OPTIONAL,
    callAssociatedEvsList   [ 7] IMPLICIT CallAssociatedEvsList   OPTIONAL,
    mediaServList          [ 8] IMPLICIT MediaServList          OPTIONAL,
    mediaEvsList           [ 9] IMPLICIT MediaEvsList           OPTIONAL,
    routeingServList       [10] IMPLICIT RouteingServList       OPTIONAL,
    physDevServList        [11] IMPLICIT PhysDevServList        OPTIONAL,
    physDevEvsList         [12] IMPLICIT PhysDevEvsList         OPTIONAL,
    logicalServList        [13] IMPLICIT LogicalServList        OPTIONAL,
    logicalEvsList         [14] IMPLICIT LogicalEvsList         OPTIONAL,
    deviceMaintEvsList     [15] IMPLICIT DeviceMaintEvsList     OPTIONAL,
    iOServicesServList     [16] IMPLICIT IOServicesServList     OPTIONAL,
    dataCollectionServList [17] IMPLICIT DataCollectionServList  OPTIONAL,
    voiceUnitServList      [18] IMPLICIT VoiceUnitServList      OPTIONAL,
    voiceUnitEvsList       [19] IMPLICIT VoiceUnitEvsList       OPTIONAL,
    cdrServList            [20] IMPLICIT CDRServList            OPTIONAL,
    vendorSpecificServList [21] IMPLICIT VendorSpecificServList  OPTIONAL,
    vendorSpecificEvsList  [22] IMPLICIT VendorSpecificEvsList  OPTIONAL,
    statusReportingServList [23] IMPLICIT StatusReportingServList OPTIONAL}

StatusReportingServList ::= SEQUENCE
{
    monitoringServices    [ 0] IMPLICIT MonitoringServList    OPTIONAL,
    snapshotServices      [ 1] IMPLICIT SnapshotServList      OPTIONAL,
    systemServices        [ 2] IMPLICIT SystemStatusServList  OPTIONAL}

MiscMediaCallCharacteristics ::= BIT STRING
{
    supportAdjustment      (0) }

PrivateDataVersionList ::= SEQUENCE OF INTEGER

END -- of CSTA-get-switching-function-capabilities
```

#### 11.1.4 Get switching function devices

```
CSTA-get-switching-function-devices
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-switching-function-devices( 204) }

DEFINITIONS ::=
BEGIN

IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ServiceCrossRefID FROM CSTA-capability-exchange
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) capability-exchange( 131) };

getSwitchingFunctionDevices OPERATION ::=
{
    ARGUMENT    GetSwitchingFunctionDevicesArgument
    RESULT      GetSwitchingFunctionDevicesResult
    ERRORS      {universalFailure}
    CODE        local:204
}

GetSwitchingFunctionDevicesArgument ::= SEQUENCE
{
    requestedDeviceID          DeviceID          OPTIONAL,
    requestedDeviceCategory    ReqDeviceCategory OPTIONAL,
    extensions                  CSTACCommonArguments OPTIONAL}

GetSwitchingFunctionDevicesResult ::= SEQUENCE
{
    serviceCrossRefID          ServiceCrossRefID,
    extensions                  CSTACCommonArguments OPTIONAL}

ReqDeviceCategory ::= ENUMERATED
{
    acd                        ( 0),
    groupACD                   ( 1),
    groupHunt                   ( 2),
    groupPick                   ( 3),
    groupOther                  ( 4),
    networkInterface            ( 5),
    park                        ( 6),
    routeingDevice              ( 7),
    station                     ( 8),
    voiceUnit                   ( 9),
    other                       (10)}

END -- of CSTA-get-switching-function-devices
```

### 11.1.5 Switching function devices

```
CSTA-switching-function-devices
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) switching-function-devices( 205) }

DEFINITIONS ::=
BEGIN

IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{ joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ServiceCrossRefID, DeviceCategory, NamedDeviceTypes FROM CSTA-capability-exchange
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) capability-exchange( 131) };

switchingFunctionDevices OPERATION ::=
{
  ARGUMENT      SwitchingFunctionDevicesArgument
  ERRORS        {universalFailure}
  CODE          local:205
}

SwitchingFunctionDevicesArgument ::= SEQUENCE
{
  serviceCrossRefID      ServiceCrossRefID,
  segmentID              INTEGER                OPTIONAL,
  lastSegment            BOOLEAN,
  deviceList             DeviceList,
  extensions             CSTACommonArguments   OPTIONAL}

DeviceList ::= SEQUENCE OF SEQUENCE
{
  deviceID             DeviceID,
  deviceCategory       [0] IMPLICIT DeviceCategory      DEFAULT station,
  namedDeviceTypes     [1] IMPLICIT NamedDeviceTypes    OPTIONAL,
  deviceAttributes     DeviceAttributes                  OPTIONAL,
  deviceModelName      IA5String (SIZE(0..64))          OPTIONAL}

DeviceAttributes ::= BIT STRING
{
  mediaAccessDevice    ( 0),
  routeingDevice       ( 1),
  groupACD             ( 2),
  groupHunt            ( 3),
  groupPick            ( 4)}

END -- of CSTA-switching-function-devices
```

## 12 System services

### 12.1 Registration services

#### 12.1.1 Change system status filter

```
CSTA-change-system-status-filter
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) change-system-status-filter( 206) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    { joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID, SystemStatus FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

changeSysStatFilter OPERATION ::=
{
    ARGUMENT      ChangeSysStatFilterArg
    RESULT        ChangeSysStatFilterRes
    ERRORS        {universalFailure}
    CODE          local: 206
}

ChangeSysStatFilterArg ::= SEQUENCE
{
    sysStatRegisterID      SysStatRegisterID,
    requestedStatusFilter  SystemStatus,
    extensions              CSTACommonArguments      OPTIONAL}

ChangeSysStatFilterRes ::= SEQUENCE
{
    actualStatusFilter      SystemStatus,
    extensions              CSTACommonArguments      OPTIONAL}

END -- of CSTA-change-system-status-filter
```

## 12.1.2 System register

```
CSTA-system-register
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) system-register( 207) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

systemRegister OPERATION ::=
{
  ARGUMENT      SystemRegisterArgument
  RESULT        SystemRegisterResult
  ERRORS        {universalFailure}
  CODE          local: 207
}

SystemRegisterArgument ::= SEQUENCE
{
  requestTypes      RequestTypes,
  requestedStatusFilter StatusFilter      OPTIONAL,
  extensions        CSTACommonArguments OPTIONAL}

SystemRegisterResult ::= SEQUENCE
{
  sysStatRegisterID SysStatRegisterID,
  actualStatusFilter StatusFilter      OPTIONAL,
  extensions        CSTACommonArguments OPTIONAL}

StatusFilter ::= BIT STRING
{
  initializing      ( 0),
  enabled           ( 1),
  normal            ( 2),
  messageLost       ( 3),
  disabled          ( 4),
  partiallyDisabled ( 5),
  overloadImminent  ( 6),
  overloadReached   ( 7),
  overloadRelieved  ( 8)}

RequestTypes ::= BIT STRING
{
  systemStatus      (0),
  requestSystemStatus (1),
  switchingFunctionCapsChanged (2),
  switchingFunctionDevicesChanged (3)}

END -- of CSTA-system-register
```



### 12.1.3 System register abort

```
CSTA-system-register-abort
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) system-register-abort( 208) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

systemRegisterAbort OPERATION ::=
{
    ARGUMENT          SystemRegisterAbortArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS   FALSE
    CODE              local: 208
}

SystemRegisterAbortArgument ::= SEQUENCE
{
    sysStatRegisterID   SysStatRegisterID,
    extensions           CSTACommonArguments    OPTIONAL}

END -- of CSTA-system-register-abort
```

## 12.1.4 System register cancel

```
CSTA-system-register-cancel
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) system-register-cancel( 209) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
;

systemRegisterCancel OPERATION ::=
{
    ARGUMENT    SystemRegisterCancelArgument
    RESULT      SystemRegisterCancelResult
    ERRORS      {universalFailure}
    CODE        local: 209
}

SystemRegisterCancelArgument ::= SEQUENCE
{
    sysStatRegisterID      SysStatRegisterID,
    extensions              CSTACommonArguments    OPTIONAL}

SystemRegisterCancelResult ::= CHOICE
{
    extensions      CSTACommonArguments,
    noData          NULL}

END -- of CSTA-system-register-cancel
```

## 12.2 Services

### 12.2.1 Request system status

```
CSTA-request-system-status
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) request-system-status( 210) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID, SystemStatus FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

requestSysStat OPERATION ::=
{
    ARGUMENT      RequestSysStatArg
    RESULT        RequestSysStatRes
    ERRORS        {universalFailure}
    CODE          local: 210
}

RequestSysStatArg ::= SEQUENCE
{
    sysStatRegisterID      SysStatRegisterID      OPTIONAL,
    extensions              CSTACommonArguments    OPTIONAL}

RequestSysStatRes ::= SEQUENCE
{
    systemStatus            SystemStatus,
    extensions              CSTACommonArguments    OPTIONAL}

END -- of CSTA-request-system-status
```

## 12.2.2 System status

```
CSTA-system-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) system-status( 211) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID, SystemStatus FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

systemStatus OPERATION ::=
{
  ARGUMENT      SystemStatusArg
  RESULT        SystemStatusRes
  ERRORS        {universalFailure}
  CODE          local: 211
}

SystemStatusArg ::= SEQUENCE
{
  sysStatRegisterID      SysStatRegisterID      OPTIONAL,
  systemStatus           SystemStatus,
  extensions             CSTACommonArguments     OPTIONAL}

SystemStatusRes ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

END -- of CSTA-system-status
```

### 12.2.3 Switching function capabilities changed

```
CSTA-switching-function-capabilities-changed
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) switching-function-capabilities-changed( 212) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

swFunctionCapsChanged OPERATION ::=
{
    ARGUMENT    SwFunctionCapsChangedArg
    RESULT      SwFunctionCapsChangedRes
    ERRORS      {universalFailure}
    CODE        local: 212
}

SwFunctionCapsChangedArg ::= SEQUENCE
{
    sysStatRegisterID    SysStatRegisterID    OPTIONAL,
    extensions            CSTACommonArguments  OPTIONAL}

SwFunctionCapsChangedRes ::= CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

END -- of CSTA-switching-function-capabilities-changed
```

## 12.2.4 Switching function devices changed

```
CSTA-switching-function-devices-changed
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) switching-function-devices-changed( 213) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    { joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
SysStatRegisterID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

swFunctionDevicesChanged OPERATION ::=
{
    ARGUMENT      SwFunctionDevicesChangedArg
    RESULT        SwFunctionDevicesChangedRes
    ERRORS        { universalFailure }
    CODE          local: 213
}

SwFunctionDevicesChangedArg ::= SEQUENCE
{
    sysStatRegisterID      SysStatRegisterID      OPTIONAL,
    extensions              CSTACommonArguments    OPTIONAL}

SwFunctionDevicesChangedRes ::= CHOICE
{
    extensions  CSTACommonArguments,
    noData      NULL}

END -- of CSTA-switching-function-devices-changed
```

## 13 Monitoring services

### 13.1 Services

#### 13.1.1 Change monitor filter

```
CSTA-change-monitor-filter
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) change-monitor-filter( 102) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    { joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
MonitorFilter, MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

changeMonitorFilter      OPERATION ::=
{
    ARGUMENT      ChangeMonitorFilterArgument
    RESULT        ChangeMonitorFilterResult
    ERRORS        {universalFailure}
    CODE          local: 72
}

ChangeMonitorFilterArgument ::=
SEQUENCE
{crossRefIdentifier      MonitorCrossRefID,
 requestedFilterList      MonitorFilter,
 extensions              CSTACCommonArguments      OPTIONAL}

ChangeMonitorFilterResult ::=
SEQUENCE
{actualFilterList        MonitorFilter      OPTIONAL,
 extensions              CSTACCommonArguments      OPTIONAL}

END -- of CSTA-change-monitor-filter
```

### 13.1.2 Monitor start

```
CSTA-monitor-start
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) monitor-start( 101) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
MonitorObject, MonitorFilter, MonitorType, MonitorMediaClass,
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

monitorStart      OPERATION ::=
{
    ARGUMENT      MonitorStartArgument
    RESULT        MonitorStartResult
    ERRORS        {universalFailure}
    CODE          local: 71
}

MonitorStartArgument ::= SEQUENCE
{
    monitorObject          MonitorObject,
    requestedMonitorFilter [0] IMPLICIT MonitorFilter      OPTIONAL,
    monitorType            MonitorType                      OPTIONAL,
    requestedMonitorMediaClass [1] IMPLICIT MonitorMediaClass OPTIONAL,
    extensions             CSTACommonArguments             OPTIONAL}

MonitorStartResult ::= SEQUENCE
{
    crossRefIdentifier      MonitorCrossRefID,
    actualmonitorFilter      [0] IMPLICIT MonitorFilter      OPTIONAL,
    actualMonitorMediaClass [1] IMPLICIT MonitorMediaClass   OPTIONAL,
    monitorExistingCalls    BOOLEAN                        OPTIONAL,
    extensions              CSTACommonArguments             OPTIONAL}

END -- of CSTA-monitor-start
```



### 13.1.3 Monitor stop

```
CSTA-monitor-stop
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) monitor-stop( 103) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
MonitorCrossRefID FROM CSTA-status-reporting
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

monitorStop      OPERATION ::=
{
    ARGUMENT      MonitorStopArgument
    RESULT        MonitorStopResult
    ERRORS        {universalFailure}
    CODE          local: 73
}

MonitorStopArgument ::=
    SEQUENCE
    {crossRefIdentifier      MonitorCrossRefID,
     extensions              CSTACommonArguments      OPTIONAL}

MonitorStopResult ::=
    CHOICE
    {extensions              CSTACommonArguments,
     noData                  NULL}

END -- of CSTA-monitor-stop
```

## 14 Snapshot services

### 14.1 Services

#### 14.1.1 Snapshot call

```
CSTA-snapshot-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) snapshot-call( 105) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
CallingDeviceID, CalledDeviceID, AssociatedCallingDeviceID,
AssociatedCalledDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
SnapshotCallData FROM CSTA-status-reporting
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) status-reporting( 126) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ServiceCrossRefID FROM CSTA-capability-exchange
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) capability-exchange( 131) }
MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

snapshotCall      OPERATION ::=
{
  ARGUMENT      SnapshotCallArgument
  RESULT        SnapshotCallResult
  ERRORS        {universalFailure}
  CODE          local: 75
}

SnapshotCallArgument ::=
SEQUENCE
{snapshotObject      ConnectionID,
 extensions          CSTACommonArguments    OPTIONAL}

SnapshotCallResult ::=
SEQUENCE
{crossRefIDorSnapshotData
  CHOICE
    {serviceCrossRefID [0] IMPLICIT ServiceCrossRefID,
      snapshotData      SnapshotCallData},
  mediaCallCharacteristics MediaCallCharacteristics    OPTIONAL,
  callCharacteristics      CallCharacteristics          OPTIONAL,
  callingDevice            CallingDeviceID              OPTIONAL,
  calledDevice             CalledDeviceID               OPTIONAL,
  associatedCallingDeviceID AssociatedCallingDeviceID    OPTIONAL,
  associatedCalledDeviceID AssociatedCalledDeviceID      OPTIONAL,
  correlatorData           [1] IMPLICIT CorrelatorData  OPTIONAL,
```

callLinkageData	[2] IMPLICIT CallLinkageData	OPTIONAL,
extensions	CSTACommonArguments	OPTIONAL}
END -- of CSTA-snapshot-call		

## 14.1.2 Snapshot device

```
CSTA-snapshot-device
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) snapshot-device( 104) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
SnapshotDeviceData FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ServiceCrossRefID FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) };

snapshotDevice OPERATION ::=
{
  ARGUMENT    SnapshotDeviceArgument
  RESULT      SnapshotDeviceResult
  ERRORS      {universalFailure}
  CODE        local: 74
}

SnapshotDeviceArgument ::=
SEQUENCE
{snapshotObject DeviceID,
 extensions      CSTACCommonArguments      OPTIONAL}

SnapshotDeviceResult ::=
SEQUENCE
{crossRefIDorSnapshotData
  CHOICE
    {serviceCrossRefID      ServiceCrossRefID,
     snapshotData           SnapshotDeviceData},
 extensions CSTACCommonArguments      OPTIONAL}

END -- of CSTA-snapshot-device
```

### 14.1.3 Snapshot calldata

```
CSTA-snapshot-call-data
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) snapshot-call-data(106) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
SnapshotCallData FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ServiceCrossRefID FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) };

snapshotCallData      OPERATION ::=
{
  ARGUMENT      SnapshotCallDataArgument
  ERRORS        {universalFailure}
  ALWAYS RESPONDS FALSE
  CODE          local: 76
}

SnapshotCallDataArgument ::=
SEQUENCE
{serviceCrossRefID  ServiceCrossRefID,
 segmentID         INTEGER,                OPTIONAL,
 lastSegment       BOOLEAN,
 snapshotData      SnapshotCallData,
 extensions        CSTACommonArguments     OPTIONAL}
```

END -- of CSTA-snapshot-call-data

#### 14.1.4 Snapshot devicedata

```
CSTA-snapshot-device-data
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) snapshot-device-data(107) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
SnapshotDeviceData FROM CSTA-status-reporting
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) status-reporting( 126) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ServiceCrossRefID FROM CSTA-capability-exchange
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) capability-exchange( 131) };

snapshotDeviceData      OPERATION ::=
{
  ARGUMENT      SnapshotDeviceDataArgument
  ERRORS        {universalFailure}
  ALWAYS RESPONDS FALSE
  CODE          local: 77
}

SnapshotDeviceDataArgument ::=
SEQUENCE
{serviceCrossRefID      ServiceCrossRefID,
 segmentID              INTEGER              OPTIONAL,
 lastSegment            BOOLEAN,
 snapshotData           SnapshotDeviceData,
 extensions             CSTACommonArguments  OPTIONAL}
```

END -- of CSTA-snapshot-device-data

## 15 Call control services and events

### 15.1 Services

#### 15.1.1 Accept call

```
CSTA-accept-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) accept-call( 214) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{ joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

acceptCall OPERATION ::=
{
  ARGUMENT    AcceptCallArgument
  RESULT      AcceptCallResult
  ERRORS      {universalFailure}
  CODE        local: 214
}

AcceptCallArgument ::= SEQUENCE
{
  callToBeAccepted      ConnectionID,
  correlatorData         CorrelatorData OPTIONAL,
  userData               UserData OPTIONAL,
  extensions              CSTACCommonArguments OPTIONAL}

AcceptCallResult ::= CHOICE
{
  extensions      CSTACCommonArguments,
  noData          NULL}

END -- of CSTA-accept-call
```

## 15.1.2 Alternate call

```
CSTA-alternate-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) alternate-call( 1) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ConsultOptions FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) }
;

alternateCall      OPERATION ::=
{
    ARGUMENT      AlternateCallArgument
    RESULT        AlternateCallResult
    ERRORS        {universalFailure}
    CODE          local: 1
}

AlternateCallArgument ::= SEQUENCE
{
    heldCall      ConnectionID,
    activeCall    ConnectionID,
    connectionReservation  BOOLEAN          OPTIONAL,
    consultOptions    ConsultOptions        DEFAULT unrestricted,
    extensions        CSTACommonArguments  OPTIONAL}

AlternateCallResult ::=CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

END -- of CSTA-alternate-call
```



### 15.1.3 Answer call

```
CSTA-answer-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) answer-call( 2) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

answerCall OPERATION ::=
{
    ARGUMENT    AnswerCallArgument
    RESULT      AnswerCallResult
    ERRORS      {universalFailure}
    CODE        local: 2
}

AnswerCallArgument ::=
SEQUENCE
{
    callToBeAnswered      ConnectionID,
    correlatorData         CorrelatorData
    userData               UserData
    extensions              CSTACommonArguments
}

AnswerCallResult ::=
CHOICE
{extensions      CSTACommonArguments,
 noData          NULL}

END -- of CSTA-answer-call
```

### 15.1.4 Call back call-related

```
CSTA-call-back-call-related
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-back-call-related( 215) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) };

callBack OPERATION ::=
{
    ARGUMENT    CallBackArgument
    RESULT      CallBackResult
    ERRORS      {universalFailure}
    CODE        local: 215
}

CallBackArgument ::=
    SEQUENCE
    {
        callbackConnection      ConnectionID,
        callCharacteristics      CallCharacteristics      OPTIONAL,
        extensions               CSTACommonArguments      OPTIONAL}

CallBackResult ::=
    SEQUENCE
    {
        targetDevice      DeviceID      OPTIONAL,
        extensions        CSTACommonArguments      OPTIONAL}

END -- of CSTA-call-back-call-related
```

### 15.1.5 Call back message call-related

```
CSTA-call-back-message-call-related
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-back-message-call-related( 216) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

callBackMessage OPERATION ::=
{
  ARGUMENT    CallBackMessageArgument
  RESULT      CallBackMessageResult
  ERRORS      {universalFailure}
  CODE        local: 216
}

CallBackMessageArgument ::=
SEQUENCE
{
  callbackMessageConnection      ConnectionID,
  extensions                     CSTACommonArguments OPTIONAL}

CallBackMessageResult ::=
SEQUENCE
{
  targetDevice      DeviceID      OPTIONAL,
  extensions        CSTACommonArguments OPTIONAL}

END -- of CSTA-call-back-message-call-related
```

### 15.1.6 Camp on call

```

CSTA-camp-on-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) camp-on-call( 217) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

camponCall OPERATION ::=
{
    ARGUMENT      CamponCallArgument
    RESULT        CamponCallResult
    ERRORS        {universalFailure}
    CODE          local: 217
}

CamponCallArgument ::=
    SEQUENCE
    {
        camponConnection      ConnectionID,
        extensions             CSTACommonArguments      OPTIONAL}

CamponCallResult ::=
    CHOICE
    {
        extensions             CSTACommonArguments,
        noData                 NULL      }

END -- of CSTA-camp-on-call

```

### 15.1.7 Clear call

```
CSTA-clear-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) clear-call( 4) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

clearCall          OPERATION ::=
{
    ARGUMENT      ClearCallArgument
    RESULT        ClearCallResult
    ERRORS        {universalFailure}
    CODE          local: 4
}

ClearCallArgument ::=
SEQUENCE
{
    callToBeCleared ConnectionID,
    userData         UserData         OPTIONAL,
    extensions       CSTACommonArguments OPTIONAL}

ClearCallResult ::=
CHOICE
{extensions      CSTACommonArguments,
 noData          NULL}

END -- of CSTA-clear-call
```

### 15.1.8 Clear Connection

```

CSTA-clear-connection
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) clear-connection( 5) }

DEFINITIONS ::=
BEGIN
IMPORTS

OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --

universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }

ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }

CorrelatorData, UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }

CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

clearConnection OPERATION ::=
{
    ARGUMENT      ClearConnectionArgument
    RESULT        ClearConnectionResult
    ERRORS        {universalFailure}
    CODE          local: 5
}

ClearConnectionArgument ::=
SEQUENCE
{connectionToBeCleared  ConnectionID,
 correlatorData         CorrelatorData          OPTIONAL,
 userData              UserData                OPTIONAL,
 extensions             CSTACCommonArguments    OPTIONAL}

ClearConnectionResult ::=
CHOICE
{extensions             CSTACCommonArguments,
 noData                 NULL}

END -- of CSTA-clear-connection

```

### 15.1.9 Conference call

```
CSTA-conference-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) conference-call( 6) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
ConnectionList FROM CSTA-connection-states
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) connection-states( 125) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

conferenceCall OPERATION ::=
{
    ARGUMENT      ConferenceCallArgument
    RESULT        ConferenceCallResult
    ERRORS        {universalFailure}
    CODE          local: 6
}

ConferenceCallArgument ::=
SEQUENCE
{
    heldCall      ConnectionID,
    activeCall    ConnectionID,
    extensions    CSTACommonArguments OPTIONAL}

ConferenceCallResult ::=
SEQUENCE
{
    conferenceCall      ConnectionID,
    connections         [0] IMPLICIT ConnectionList OPTIONAL,
    conferenceCallInfo  [1] IMPLICIT ConnectionInformation OPTIONAL,
    extensions          CSTACommonArguments OPTIONAL}

END -- of CSTA-conference-call
```

### 15.1.10 Consultation call

```
CSTA-consultation-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) consultation-call( 7) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, ConsultOptions FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

consultationCall OPERATION ::=
{
  ARGUMENT ConsultationCallArgument
  RESULT ConsultationCallResult
  ERRORS {universalFailure}
  CODE local: 7
}

ConsultationCallArgument ::= SEQUENCE
{
  existingCall [0] IMPLICIT ConnectionID,
  consultedDevice [1] DeviceID,
  connectionReservation [2] IMPLICIT BOOLEAN OPTIONAL,
  accountCode [3] IMPLICIT AccountInfo OPTIONAL,
  authCode [4] IMPLICIT AuthCode OPTIONAL,
  correlatorData [5] IMPLICIT CorrelatorData OPTIONAL,
  userData [6] IMPLICIT UserData OPTIONAL,
  callCharacteristics [7] IMPLICIT CallCharacteristics OPTIONAL,
  mediaCallCharacteristics [8] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callingConnectionInfo [9] IMPLICIT ConnectionInformation OPTIONAL,
  consultOptions [10] IMPLICIT ConsultOptions DEFAULT unrestricted,
  extensions CSTACommonArguments OPTIONAL
}

ConsultationCallResult ::= SEQUENCE
{
  initiatedCall ConnectionID,
  mediaCallCharacteristics [0] IMPLICIT MediaCallCharacteristics OPTIONAL,
  initiatedCallInfo [1] IMPLICIT ConnectionInformation OPTIONAL,
  extensions CSTACommonArguments OPTIONAL
}

END -- of CSTA-consultation-call
```



### 15.1.11 Deflect call

```
CSTA-deflect-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) deflect-call( 218) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

deflectCall      OPERATION ::=
{
    ARGUMENT      DeflectCallArgument
    RESULT        DeflectCallResult
    ERRORS        {universalFailure}
    CODE          local: 218
}

DeflectCallArgument ::=
SEQUENCE
{
    callToBeDiverted      ConnectionID,
    newDestination        DeviceID,
    correlatorData        CorrelatorData      OPTIONAL,
    userData              UserData            OPTIONAL,
    extensions            CSTACommonArguments OPTIONAL}

DeflectCallResult ::=
CHOICE
{extensions      CSTACommonArguments,
 noData          NULL}

END -- of CSTA-deflect-call
```

### 15.1.12 Dial digits

```
CSTA-dial-digits
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) dial-digits( 219) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

dialDigits      OPERATION ::=
{
    ARGUMENT      DialDigitsArgument
    RESULT        DialDigitsResult
    ERRORS        {universalFailure}
    CODE          local: 219
}

DialDigitsArgument ::=
    SEQUENCE
    {
        diallingConnection          ConnectionID,
        diallingSequence             DeviceID,
        correlatorData               CorrelatorData      OPTIONAL,
        extensions                   CSTACommonArguments OPTIONAL}

DialDigitsResult ::=
    CHOICE
    {extensions      CSTACommonArguments,
     noData          NULL}

END -- of CSTA-dial-digits
```

### 15.1.13 Directed pickup call

```
CSTA-directed-pickup-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) directed-pickup-call( 220) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

directedPickupCall      OPERATION ::=
{
    ARGUMENT    DirectedPickupCallArgument
    RESULT      DirectedPickupCallResult
    ERRORS      {universalFailure}
    CODE        local: 220
}

DirectedPickupCallArgument ::=
SEQUENCE
{
    callToBePickedUp      ConnectionID,
    requestingDevice      DeviceID,
    correlatorData        CorrelatorData      OPTIONAL,
    userData              UserData            OPTIONAL,
    extensions            CSTACommonArguments OPTIONAL}

DirectedPickupCallResult ::=
SEQUENCE
{
    pickedCall      ConnectionID      OPTIONAL,
    pickedCallInfo  ConnectionInformation OPTIONAL,
    extensions      CSTACommonArguments OPTIONAL}

END -- of CSTA-directed-pickup-call
```

### 15.1.14 Group pickup call

```
CSTA-group-pickup-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) group-pickup-call( 221) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

groupPickupCall OPERATION ::=
{
  ARGUMENT    GroupPickupCallArgument
  RESULT      GroupPickupCallResult
  ERRORS      {universalFailure}
  CODE        local: 221
}

GroupPickupCallArgument ::=
SEQUENCE
{
  newDestination DeviceID,
  pickGroup       DeviceID                OPTIONAL,
  correlatorData  CorrelatorData          OPTIONAL,
  userData        UserData                OPTIONAL,
  extensions      CSTACommonArguments     OPTIONAL}

GroupPickupCallResult ::=
SEQUENCE
{
  pickedCall      ConnectionID            OPTIONAL,
  pickedCallInfo  ConnectionInformation    OPTIONAL,
  extensions      CSTACommonArguments     OPTIONAL}

END -- of CSTA-group-pickup-call
```

### 15.1.15 Hold call

```
CSTA-hold-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) hold-call( 9) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

holdCall      OPERATION ::=
{
  ARGUMENT      HoldCallArgument
  RESULT        HoldCallResult
  ERRORS        {universalFailure}
  CODE          local: 9
}

HoldCallArgument ::=
SEQUENCE
{callToBeHeld      ConnectionID,
 connectionReservation  BOOLEAN          OPTIONAL,
 extensions          CSTACommonArguments OPTIONAL}

HoldCallResult ::=
CHOICE
{extensions      CSTACommonArguments,
 noData          NULL}

END -- of CSTA-hold-call
```

### 15.1.16 Intrude call

```
CSTA-intrude-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) intrude-call( 222) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    { joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
ParticipationType, UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

intrudeCall OPERATION ::=
{
    ARGUMENT    IntrudeCallArgument
    RESULT      IntrudeCallResult
    ERRORS      {universalFailure}
    CODE        local: 222
}

IntrudeCallArgument ::= SEQUENCE
{
    intrude          ConnectionID,
    participationType ParticipationType    DEFAULT active,
    userData         UserData              OPTIONAL,
    extensions       CSTACCommonArguments OPTIONAL}

IntrudeCallResult ::= SEQUENCE
{
    conferencedCall    ConnectionID        OPTIONAL,
    conferencedCallInfo ConnectionInformation OPTIONAL,
    extensions         CSTACCommonArguments OPTIONAL}

END -- of CSTA-intrude-call
```

### 15.1.17 Join call

```
CSTA-join-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) join-call( 223) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData, ParticipationType, UserData
  FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) }
AutoOriginate FROM CSTA-call-control
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-control( 130) };

joinCall OPERATION ::=
{
  ARGUMENT      JoinCallArgument
  RESULT        JoinCallResult
  ERRORS        {universalFailure}
  CODE          local: 223
}

JoinCallArgument ::= SEQUENCE
{
  activeCall          ConnectionID,
  joiningDevice        DeviceID,
  autoOriginate        [0] IMPLICIT AutoOriginate          DEFAULT prompt,
  participationType    [1] IMPLICIT ParticipationType       DEFAULT active,
  accountCode          [2] IMPLICIT AccountInfo             OPTIONAL,
  authCode             [3] IMPLICIT AuthCode                OPTIONAL,
  correlatorData       [4] IMPLICIT CorrelatorData           OPTIONAL,
  userData             UserData                              OPTIONAL,
  extensions           CSTACommonArguments                  OPTIONAL}

JoinCallResult ::= SEQUENCE
{
  conferencedCall      ConnectionID,
  conferencedCallInfo  ConnectionInformation OPTIONAL,
  extensions           CSTACommonArguments  OPTIONAL}

END -- of CSTA-join-call
```

### 15.1.18 Make call

```
CSTA-make-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) make-call( 10) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
AutoOriginate, CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) }
;

makeCall      OPERATION ::=
{
  ARGUMENT    MakeCallArgument
  RESULT      MakeCallResult
  ERRORS      {universalFailure}
  CODE        local: 10
}

MakeCallArgument ::= SEQUENCE
{
  callingDevice          DeviceID,
  calledDirectoryNumber  DeviceID,
  accountCode            [0] IMPLICIT AccountInfo          OPTIONAL,
  authCode               [1] IMPLICIT AuthCode              OPTIONAL,
  autoOriginate          [3] IMPLICIT AutoOriginate         DEFAULT prompt,
  correlatorData         [2] IMPLICIT CorrelatorData        OPTIONAL,
  userData               UserData                          OPTIONAL,
  callCharacteristics    CallCharacteristics                OPTIONAL,
  mediaCallCharacteristics [4] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callingConnectionInfo  [5] IMPLICIT ConnectionInformation OPTIONAL,
  extensions             CSTACommonArguments                OPTIONAL}

MakeCallResult ::= SEQUENCE
{
  callingDevice          ConnectionID,
  mediaCallCharacteristics [0] IMPLICIT MediaCallCharacteristics OPTIONAL,
  initiatedCallInfo      [1] IMPLICIT ConnectionInformation  OPTIONAL,
  extensions             CSTACommonArguments                OPTIONAL}

END -- of CSTA-make-call
```



### 15.1.19 Make predictive call

```
CSTA-make-predictive-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) make-predictive-call( 11) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData, UserData FROM
    CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
AutoOriginate, CallCharacteristics FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

makePredictiveCall          OPERATION ::=
{
    ARGUMENT    MakePredictiveCallArgument
    RESULT      MakePredictiveCallResult
    ERRORS      {universalFailure}
    CODE        local: 11
}

MakePredictiveCallArgument ::= SEQUENCE
{
    callingDevice          DeviceID,
    calledDirectoryNumber  DeviceID,
    signallingDetection     [0] IMPLICIT SignallingDetection    OPTIONAL,
    destinationDetection   [1] IMPLICIT DestinationDetection   OPTIONAL,
    defaultAction          [2] IMPLICIT DefaultAction          OPTIONAL,
    accountCode            [3] IMPLICIT AccountInfo            OPTIONAL,
    authCode               [4] IMPLICIT AuthCode               OPTIONAL,
    autoOriginate          [5] IMPLICIT AutoOriginate          DEFAULT prompt,
    alertTime              [6] IMPLICIT INTEGER                OPTIONAL,
    correlatorData         [7] IMPLICIT CorrelatorData         OPTIONAL,
    callCharacteristics     [8] IMPLICIT CallCharacteristics    OPTIONAL,
    userData               UserData                            OPTIONAL,
    extensions             CSTACCommonArguments                OPTIONAL}

MakePredictiveCallResult ::= SEQUENCE
{
    initiatedCall          ConnectionID,
    initiatedCallInfo      ConnectionInformation                OPTIONAL,
    extensions             CSTACCommonArguments                OPTIONAL}

SignallingDetection ::= SEQUENCE
{
    signallingCondition     SignallingCondition,
    signallingConditionsAction SignallingConditionsAction}

SignallingCondition ::= ENUMERATED
{
    callDelivered           (0),
```

```
        callEstablished      (1)}

SignallingConditionsAction ::= ENUMERATED
{
    destinationDetection      (0),
    remainConnected           (1)}

DestinationDetection ::= SEQUENCE OF SEQUENCE
{
    destinationCondition      DestinationCondition,
    detectionAction           DetectionAction}

DestinationCondition ::= ENUMERATED
{
    humanVoice                (0),
    answeringMachine          (1),
    facsimileMachine          (2)}

DefaultAction ::= DetectionAction

DetectionAction ::= ENUMERATED
{
    clearCalledConnection     (0),
    remainConnected           (1)}

END -- of CSTA-make-predictive-call
```

### 15.1.20 Park call

```
CSTA-park-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) park-call( 18) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

parkCall OPERATION ::=
{
  ARGUMENT      ParkCallArgument
  RESULT        ParkCallResult
  ERRORS        {universalFailure}
  CODE          local: 18
}

ParkCallArgument ::=
SEQUENCE
{
  parking          ConnectionID,
  parkTo           DeviceID,
  correlatorData   CorrelatorData OPTIONAL,
  extensions       CSTACommonArguments OPTIONAL}

ParkCallResult ::=
SEQUENCE
{
  parkedTo         ConnectionID OPTIONAL,
  extensions       CSTACommonArguments OPTIONAL}

END -- of CSTA-park-call
```

### 15.1.21 Reconnect call

```
CSTA-reconnect-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) reconnect-call( 13) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

reconnectCall      OPERATION ::=
{
    ARGUMENT      ReconnectCallArgument
    RESULT         ReconnectCallResult
    ERRORS         {universalFailure}
    CODE           local: 13
}

ReconnectCallArgument ::= SEQUENCE
{
    activeCall      ConnectionID,
    heldCall        ConnectionID,
    extensions      CSTACommonArguments OPTIONAL}

ReconnectCallResult ::=
CHOICE
{extensions          CSTACommonArguments,
 noData              NULL}

END -- of CSTA-reconnect-call
```

### 15.1.22 Retrieve call

```
CSTA-retrieve-call
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) retrieve-call( 14) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

retrieveCall          OPERATION ::=
{
    ARGUMENT          RetrieveCallArgument
    RESULT             RetrieveCallResult
    ERRORS             {universalFailure}
    CODE               local: 14
}

RetrieveCallArgument ::=
    SEQUENCE
    {
        callToBeRetrieved          ConnectionID,
        extensions                  CSTACommonArguments OPTIONAL}

RetrieveCallResult ::=
    CHOICE
    {extensions          CSTACommonArguments,
     noData              NULL}

END -- of CSTA-retrieve-call
```

### 15.1.23 Single step conference call

```
CSTA-single-step-conference
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) single-step-conference( 20) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData, ParticipationType, UserData
FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

singleStepConf OPERATION ::=
{
  ARGUMENT      SingleStepConfArgument
  RESULT        SingleStepConfResult
  ERRORS        {universalFailure}
  CODE          local: 20
}

SingleStepConfArgument ::=
SEQUENCE
{activeCall      ConnectionID,
 deviceToJoin    DeviceID,
 participationType ParticipationType          DEFAULT active,
 accountCode     [0] IMPLICIT AccountInfo     OPTIONAL,
 authCode        [1] IMPLICIT AuthCode        OPTIONAL,
 correlatorData  [2] IMPLICIT CorrelatorData   OPTIONAL,
 userData        UserData                      OPTIONAL,
 extensions      CSTACCommonArguments         OPTIONAL}

SingleStepConfResult ::=
SEQUENCE
{
  conferencedCall ConnectionID,
  conferencedCallInfo ConnectionInformation  OPTIONAL,
  extensions      CSTACCommonArguments      OPTIONAL}

END -- of CSTA-single-step-conference
```

### 15.1.24 Single step transfer call

```
CSTA-single-step-transfer
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) single-step-conference( 50) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
ConnectionList FROM CSTA-connection-states
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) connection-states( 125) }
AccountInfo, AuthCode, CorrelatorData, UserData
  FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) };

singleStepTrans OPERATION ::=
{
  ARGUMENT      SingleStepTransArgument
  RESULT        SingleStepTransResult
  ERRORS        {universalFailure}
  CODE          local: 50
}

SingleStepTransArgument ::=
SEQUENCE
{activeCall      ConnectionID,
 tranferredTo    DeviceID,
 accountCode     [0] IMPLICIT AccountInfo      OPTIONAL,
 authCode        [1] IMPLICIT AuthCode          OPTIONAL,
 correlatorData  [2] IMPLICIT CorrelatorData     OPTIONAL,
 userData        UserData                       OPTIONAL,
 extensions      CSTACCommonArguments           OPTIONAL}

SingleStepTransResult ::= SEQUENCE
{transferredCall ConnectionID,
 connections     [0] IMPLICIT ConnectionList    OPTIONAL,
 transferredCallInfo [1] IMPLICIT ConnectionInformation OPTIONAL,
 extensions      CSTACCommonArguments           OPTIONAL}

END -- of CSTA-single-step-transfer
```

### 15.1.25 Transfer call

```
CSTA-transfer-call
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) transfer-call( 16) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
ConnectionList FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) }
;

transferCall      OPERATION ::=
{
  ARGUMENT      TransferCallArgument
  RESULT        TransferCallResult
  ERRORS        {universalFailure}
  CODE          local: 16
}

TransferCallArgument ::= SEQUENCE
{
  heldCall      ConnectionID,
  activeCall    ConnectionID,
  extensions    CSTACommonArguments OPTIONAL}

TransferCallResult ::= SEQUENCE
{
  transferredCall      ConnectionID,
  connections          [0] IMPLICIT ConnectionList      OPTIONAL,
  transferredCallInfo  [1] IMPLICIT ConnectionInformation OPTIONAL,
  extensions           CSTACommonArguments                OPTIONAL}

END -- of CSTA-transfer-call
```



## 15.2 Events

### 15.2.1 Bridged

```
CSTA-bridged-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) bridged-event( 224) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

BridgedEvent ::= SEQUENCE
{
    bridgedConnection      ConnectionID,
    bridgedAppearance      SubjectDeviceID,
    localConnectionInfo    LocalConnectionState          OPTIONAL,
    correlatorData          [0] IMPLICIT CorrelatorData    OPTIONAL,
    userData                UserData                      OPTIONAL,
    cause                   EventCause,
    servicesPermitted       [1] IMPLICIT ServicesPermitted OPTIONAL,
    mediaCallCharacteristics[2] IMPLICIT MediaCallCharacteristics OPTIONAL,
    callCharacteristics     [3] IMPLICIT CallCharacteristics OPTIONAL,
    bridgedConnectionInfo  [4] IMPLICIT ConnectionInformation OPTIONAL,
    callLinkageData         [5] IMPLICIT CallLinkageData    OPTIONAL,
    extensions              CSTACommonArguments           OPTIONAL}

END -- of CSTA-bridged-event
```

## 15.2.2 Call cleared

```
CSTA-call-cleared-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-cleared-event( 22) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) }
;

CallClearedEvent ::=
SEQUENCE
{
  clearedCall          ConnectionID,
  correlatorData        [1] IMPLICIT CorrelatorData          OPTIONAL,
  userData              UserData                                OPTIONAL,
  cause                 EventCause,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics    [3] IMPLICIT CallCharacteristics      OPTIONAL,
  callLinkageData        [4] IMPLICIT CallLinkageData          OPTIONAL,
  extensions             CSTACommonArguments                  OPTIONAL}

END -- of CSTA-call-cleared-event
```

### 15.2.3 Conferenced

```
CSTA-conferenced-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) conferenced-event( 23) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState, ConnectionList FROM CSTA-connection-states
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageDataList, ServicesPermitted FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) }
MediaCallCharacteristics FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

ConferencedEvent ::= SEQUENCE
{
    primaryOldCall          ConnectionID,
    secondaryOldCall        ConnectionID                OPTIONAL,
    conferencingDevice      SubjectDeviceID,
    addedParty              SubjectDeviceID,
    conferenceConnections   ConnectionList,
    localConnectionInfo     LocalConnectionState        OPTIONAL,
    correlatorData          [1] IMPLICIT CorrelatorData  OPTIONAL,
    userData                UserData                    OPTIONAL,
    cause                   EventCause,
    servicesPermitted       [2] IMPLICIT ServicesPermitted OPTIONAL,
    mediaCallCharacteristics [3] IMPLICIT MediaCallCharacteristics OPTIONAL,
    callCharacteristics      [4] IMPLICIT CallCharacteristics  OPTIONAL,
    callLinkageDataList     [6] IMPLICIT CallLinkageDataList   OPTIONAL,
    extensions              [5] IMPLICIT CSTACommonArguments  OPTIONAL}

END -- of CSTA-conferenced-event
```

## 15.2.4 Connection cleared

```
CSTA-connection-cleared-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-cleared-event( 24) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ChargingInfo FROM CSTA-charge-info
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charge-info( 133) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

ConnectionClearedEvent ::=
SEQUENCE
{
  droppedConnection          ConnectionID,
  releasingDevice            SubjectDeviceID,
  localConnectionInfo        LocalConnectionState          OPTIONAL,
  correlatorData              [0] IMPLICIT CorrelatorData    OPTIONAL,
  userData                    UserData                        OPTIONAL,
  chargingInfo                [1] IMPLICIT ChargingInfo       OPTIONAL,
  cause                       EventCause,
  servicesPermitted           [2] IMPLICIT ServicesPermitted  OPTIONAL,
  mediaCallCharacteristics    [3] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics          [4] IMPLICIT CallCharacteristics OPTIONAL,
  droppedConnectionInfo        [5] IMPLICIT ConnectionInformation OPTIONAL,
  callLinkageData              [6] IMPLICIT CallLinkageData    OPTIONAL,
  extensions                  CSTACommonArguments            OPTIONAL}

END -- of CSTA-connection-cleared-event
```

## 15.2.5 Delivered

```
CSTA-delivered-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) delivered-event( 25) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CallingDeviceID, CalledDeviceID, RedirectionDeviceID,
AssociatedCalledDeviceID, AssociatedCallingDeviceID,
NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

DeliveredEvent ::=
SEQUENCE
{
  connection                ConnectionID,
  alertingDevice             SubjectDeviceID,
  callingDevice              CallingDeviceID,
  calledDevice               CalledDeviceID,
  lastRedirectionDevice      RedirectionDeviceID,
  originatingNIDConnection  ConnectionID                OPTIONAL,
  localConnectionInfo        LocalConnectionState        OPTIONAL,
  correlatorData              [0] IMPLICIT CorrelatorData  OPTIONAL,
  userData                   UserData                     OPTIONAL,
  cause                      EventCause,
  servicesPermitted           [1] IMPLICIT ServicesPermitted OPTIONAL,
  networkCallingDevice        NetworkCallingDeviceID      OPTIONAL,
  networkCalledDevice         NetworkCalledDeviceID        OPTIONAL,
  associatedCallingDevice      AssociatedCallingDeviceID    OPTIONAL,
  associatedCalledDevice       AssociatedCalledDeviceID     OPTIONAL,
  mediaCallCharacteristics     [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics          [3] IMPLICIT CallCharacteristics  OPTIONAL,
  connectionInfo              [4] IMPLICIT ConnectionInformation OPTIONAL,
  callLinkageData              [5] IMPLICIT CallLinkageData      OPTIONAL,
  extensions                  CSTACommonArguments          OPTIONAL}

END -- of CSTA-delivered-event
```

## 15.2.6 Digits dialed

```
CSTA-digits-dialed-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) digits-dialed-event( 225) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, DeviceID, AssociatedCalledDeviceID, AssociatedCallingDeviceID,
NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

DigitsDialedEvent ::= SEQUENCE
{
    dialingConnection      ConnectionID,
    dialingDevice          SubjectDeviceID,
    dialingSequence        DeviceID,
    localConnectionInfo    LocalConnectionState      OPTIONAL,
    correlatorData         [0] IMPLICIT CorrelatorData OPTIONAL,
    cause                  EventCause,
    servicesPermitted      [1] IMPLICIT ServicesPermitted OPTIONAL,
    networkCallingDevice   NetworkCallingDeviceID    OPTIONAL,
    networkCalledDevice    NetworkCalledDeviceID     OPTIONAL,
    associatedCallingDevice AssociatedCallingDeviceID OPTIONAL,
    associatedCalledDevice AssociatedCalledDeviceID   OPTIONAL,
    dialingConnectionInfo  [2] IMPLICIT ConnectionInformation OPTIONAL,
    callCharacteristics     [3] IMPLICIT CallCharacteristics    OPTIONAL,
    callLinkageData        [4] IMPLICIT CallLinkageData         OPTIONAL,
    extensions              CSTACommonArguments      OPTIONAL}

END -- of CSTA-digits-dialed-event
```

## 15.2.7 Diverted

```
CSTA-diverted-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) diverted-event( 26) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID , CallingDeviceID, CalledDeviceID, RedirectionDeviceID,
  AssociatedCalledDeviceID, AssociatedCallingDeviceID,
  NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

DivertedEvent ::= SEQUENCE
{
  connection          ConnectionID,
  divertingDevice      SubjectDeviceID,
  newDestination       SubjectDeviceID,
  callingDevice        CallingDeviceID,
  calledDevice         CalledDeviceID,
  lastRedirectionDevice RedirectionDeviceID,
  localConnectionInfo  LocalConnectionState,
  correlatorData       [0] IMPLICIT CorrelatorData,
  userData            UserData,
  cause               EventCause,
  servicesPermitted    [1] IMPLICIT ServicesPermitted,
  mediaCallCharacteristics[2] IMPLICIT MediaCallCharacteristics,
  callCharacteristics  [3] IMPLICIT CallCharacteristics,
  connectionInfo      [4] IMPLICIT ConnectionInformation,
  networkCallingDevice NetworkCallingDeviceID,
  networkCalledDevice  NetworkCalledDeviceID,
  associatedCallingDevice AssociatedCallingDeviceID,
  associatedCalledDevice AssociatedCalledDeviceID,
  callLinkageData      [5] IMPLICIT CallLinkageData,
  extensions           CSTACommonArguments
}

END -- of diverted-event
```

## 15.2.8 Established

```
CSTA-established-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) established-event( 27) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CalledDeviceID, CallingDeviceID, RedirectionDeviceID,
AssociatedCalledDeviceID, AssociatedCallingDeviceID,
NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

EstablishedEvent ::=
SEQUENCE
{
  establishedConnection      ConnectionID,
  answeringDevice            SubjectDeviceID,
  callingDevice               CallingDeviceID,
  calledDevice                CalledDeviceID,
  lastRedirectionDevice       RedirectionDeviceID,
  originatingNIDConnection   ConnectionID              OPTIONAL,
  localConnectionInfo         LocalConnectionState      OPTIONAL,
  correlatorData               [1] IMPLICIT CorrelatorData  OPTIONAL,
  userData                     UserData                  OPTIONAL,
  cause                       EventCause,
  servicesPermitted           [2] IMPLICIT ServicesPermitted OPTIONAL,
  networkCallingDevice         NetworkCallingDeviceID     OPTIONAL,
  networkCalledDevice          NetworkCalledDeviceID      OPTIONAL,
  associatedCallingDevice       AssociatedCallingDeviceID  OPTIONAL,
  associatedCalledDevice        AssociatedCalledDeviceID   OPTIONAL,
  mediaCallCharacteristics     [3] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics          [4] IMPLICIT CallCharacteristics  OPTIONAL,
  establishedConnectionInfo    [5] IMPLICIT ConnectionInformation OPTIONAL,
  callLinkageData              [6] IMPLICIT CallLinkageData     OPTIONAL,
  extensions                   CSTACommonArguments        OPTIONAL}

END -- of CSTA-established-event
```



## 15.2.9 Failed

```
CSTA-failed-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) failed-event( 28) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CallingDeviceID, CalledDeviceID, RedirectionDeviceID,
AssociatedCalledDeviceID, AssociatedCallingDeviceID,
NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

FailedEvent ::= SEQUENCE
{
    failedConnection          ConnectionID,
    failingDevice             SubjectDeviceID,
    callingDevice             CallingDeviceID,
    calledDevice              CalledDeviceID,
    lastRedirectionDevice     RedirectionDeviceID,
    originatingNIDConnection ConnectionID          OPTIONAL,
    localConnectionInfo      LocalConnectionState  OPTIONAL,
    correlatorData            [0] IMPLICIT CorrelatorData  OPTIONAL,
    userData                  UserData              OPTIONAL,
    cause                     EventCause,
    servicesPermitted         [1] IMPLICIT ServicesPermitted  OPTIONAL,
    networkCallingDevice      NetworkCallingDeviceID  OPTIONAL,
    networkCalledDevice       NetworkCalledDeviceID   OPTIONAL,
    associatedCallingDevice    AssociatedCallingDeviceID  OPTIONAL,
    associatedCalledDevice     AssociatedCalledDeviceID  OPTIONAL,
    mediaCallCharacteristics  [2] IMPLICIT MediaCallCharacteristics  OPTIONAL,
    callCharacteristics       [3] IMPLICIT CallCharacteristics      OPTIONAL,
    establishedConnectionInfo [4] IMPLICIT ConnectionInformation  OPTIONAL,
    callLinkageData           [5] IMPLICIT CallLinkageData        OPTIONAL,
    extensions                 CSTACommonArguments      OPTIONAL}

END -- of CSTA-failed-event
```

## 15.2.10 Held

```
CSTA-held-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) held-event( 29) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

HeldEvent ::=
SEQUENCE
{
  heldConnection          ConnectionID,
  holdingDevice           SubjectDeviceID,
  localConnectionInfo     LocalConnectionState          OPTIONAL,
  correlatorData          [0] IMPLICIT CorrelatorData    OPTIONAL,
  cause                  EventCause,
  servicesPermitted       [1] IMPLICIT ServicesPermitted OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics     [3] IMPLICIT CallCharacteristics OPTIONAL,
  heldConnectionInfo      [4] IMPLICIT ConnectionInformation OPTIONAL,
  callLinkageData         [5] IMPLICIT CallLinkageData    OPTIONAL,
  extensions              CSTACommonArguments            OPTIONAL}

END -- of CSTA-held-event
```

### 15.2.11 Network capabilities changed

```
CSTA-network-capabilities-changed-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) network-capabilities-changed-event( 226) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CalledDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, NetworkCapability, ProgressIndicator,
ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

NetworkCapabilitiesChangedEvent ::= SEQUENCE
{
  outboundConnection      ConnectionID,
  networkInterfaceUsed    SubjectDeviceID,
  calledDevice            CalledDeviceID,
  progressIndicator       ProgressIndicator,
  localConnectionInfo     LocalConnectionState      OPTIONAL,
  correlatorData          CorrelatorData            OPTIONAL,
  userData               UserData                  OPTIONAL,
  networkCapability       [0] IMPLICIT NetworkCapability OPTIONAL,
  cause                  EventCause,
  servicesPermitted       [1] IMPLICIT ServicesPermitted OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics     [3] IMPLICIT CallCharacteristics OPTIONAL,
  outboundConnectionInfo  [4] IMPLICIT ConnectionInformation OPTIONAL,
  callLinkageData         [5] IMPLICIT CallLinkageData  OPTIONAL,
  extensions              CSTACommonArguments      OPTIONAL}

END -- of CSTA-network-capabilities-changed-event
```

## 15.2.12 Network reached

```
CSTA-network-reached-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) network-reached-event( 30) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CallingDeviceID, CalledDeviceID, RedirectionDeviceID,
AssociatedCallingDeviceID, NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, NetworkCapability,
ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

NetworkReachedEvent ::=
SEQUENCE
{
  outboundConnection      ConnectionID,
  networkInterfaceUsed    SubjectDeviceID,
  callingDevice           CallingDeviceID,
  calledDevice            CalledDeviceID,
  lastRedirectionDevice   RedirectionDeviceID,
  originatingNIDConneciton ConnectionID OPTIONAL,
  localConnectionInfo     LocalConnectionState OPTIONAL,
  correlatorData          [0] IMPLICIT CorrelatorData OPTIONAL,
  userData               UserData OPTIONAL,
  networkCapability       [1] IMPLICIT NetworkCapability OPTIONAL,
  cause                  EventCause,
  servicesPermitted       [2] IMPLICIT ServicesPermitted OPTIONAL,
  mediaCallCharacteristics [3] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics     [4] IMPLICIT CallCharacteristics OPTIONAL,
  outboundConnectionInfo [5] IMPLICIT ConnectionInformation OPTIONAL,
  networkCallingDevice    NetworkCallingDeviceID OPTIONAL,
  networkCalledDevice     NetworkCalledDeviceID OPTIONAL,
  associatedCallingDevice AssociatedCallingDeviceID OPTIONAL,
  callLinkageData         [6] IMPLICIT CallLinkageData OPTIONAL,
  extensions              CSTACommonArguments OPTIONAL}

END -- of CSTA-network-reached-event
```

### 15.2.13 Offered

```
CSTA-offered-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) offered-event( 227) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, CallingDeviceID, CalledDeviceID, RedirectionDeviceID, AssociatedCalledDeviceID,
AssociatedCallingDeviceID, NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

OfferedEvent ::= SEQUENCE
{
  offeredConnection      ConnectionID,
  offeredDevice          SubjectDeviceID,
  callingDevice          CallingDeviceID,
  calledDevice           CalledDeviceID,
  lastRedirectionDevice  RedirectionDeviceID,
  originatingNIDConnection ConnectionID OPTIONAL,
  localConnectionInfo   LocalConnectionState OPTIONAL,
  correlatorData        CorrelatorData OPTIONAL,
  userData              UserData OPTIONAL,
  cause                 EventCause,
  servicesPermitted     [0] IMPLICIT ServicesPermitted OPTIONAL,
  networkCallingDevice  NetworkCallingDeviceID OPTIONAL,
  networkCalledDevice   NetworkCalledDeviceID OPTIONAL,
  associatedCallingDevice AssociatedCallingDeviceID OPTIONAL,
  associatedCalledDevice AssociatedCalledDeviceID OPTIONAL,
  mediaCallCharacteristics [1] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics    [2] IMPLICIT CallCharacteristics OPTIONAL,
  offeredConnectionInfo [3] IMPLICIT ConnectionInformation OPTIONAL,
  callLinkageData        [4] IMPLICIT CallLinkageData OPTIONAL,
  extensions             CSTACCommonArguments OPTIONAL}

END -- of CSTA-offered-event
```

## 15.2.14 Originated

```
CSTA-originated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) originated-event( 31) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
DeviceID, CallingDeviceID, CalledDeviceID, AssociatedCalledDeviceID,
AssociatedCallingDeviceID, NetworkCalledDeviceID, NetworkCallingDeviceID, SubjectDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

OriginatedEvent ::= SEQUENCE
{
  originatedConnection      ConnectionID,
  callingDevice              SubjectDeviceID,
  calledDevice               CalledDeviceID,
  originatingDevice          DeviceID
  localConnectionInfo        LocalConnectionState
  correlatorData              [2] IMPLICIT CorrelatorData
  cause                      EventCause,
  servicesPermitted           [3] IMPLICIT ServicesPermitted
  networkCallingDevice        NetworkCallingDeviceID
  networkCalledDevice         NetworkCalledDeviceID
  associatedCallingDevice      AssociatedCallingDeviceID
  associatedCalledDevice       AssociatedCalledDeviceID
  mediaCallCharacteristics     [4] IMPLICIT MediaCallCharacteristics
  callCharacteristics          [5] IMPLICIT CallCharacteristics
  originatedConnectionInfo    [6] IMPLICIT ConnectionInformation
  callLinkageData             [7] IMPLICIT CallLinkageData
  extensions                  CSTACommonArguments
}

END -- of CSTA-originated-event
```

### 15.2.15 Queued

```
CSTA-queued-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) queued-event( 32) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
CalledDeviceID, CallingDeviceID, RedirectionDeviceID, SubjectDeviceID, AssociatedCalledDeviceID,
AssociatedCallingDeviceID, NetworkCalledDeviceID, NetworkCallingDeviceID
FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

QueuedEvent ::=
SEQUENCE
{
  queuedConnection      ConnectionID,
  queue                 SubjectDeviceID,
  callingDevice          CallingDeviceID,
  calledDevice           CalledDeviceID,
  lastRedirectionDevice  RedirectionDeviceID,
  numberQueued           [0] IMPLICIT INTEGER          OPTIONAL,
  callsInFront           [1] IMPLICIT INTEGER          OPTIONAL,
  localConnectionInfo    LocalConnectionState          OPTIONAL,
  correlatorData          [2] IMPLICIT CorrelatorData   OPTIONAL,
  userData               UserData                      OPTIONAL,
  cause                  EventCause,
  servicesPermitted       [3] IMPLICIT ServicesPermitted OPTIONAL,
  networkCallingDevice    NetworkCallingDeviceID        OPTIONAL,
  networkCalledDevice     NetworkCalledDeviceID          OPTIONAL,
  associatedCallingDevice  AssociatedCallingDeviceID      OPTIONAL,
  associatedCalledDevice   AssociatedCalledDeviceID       OPTIONAL,
  mediaCallCharacteristics [4] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics      [5] IMPLICIT CallCharacteristics  OPTIONAL,
  queuedConnectionInfo    [6] IMPLICIT ConnectionInformation OPTIONAL,
  callLinkageData          [7] IMPLICIT CallLinkageData      OPTIONAL,
  extensions              CSTACommonArguments            OPTIONAL}

END -- of CSTA-queued-event
```

## 15.2.16 Retrieved

```
CSTA-retrieved-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) retrieved-event( 33) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

RetrievedEvent ::=
SEQUENCE
{
  retrievedConnection      ConnectionID,
  retrievingDevice         SubjectDeviceID,
  localConnectionInfo      LocalConnectionState      OPTIONAL,
  correlatorData           [0] IMPLICIT CorrelatorData  OPTIONAL,
  cause                   EventCause,
  servicesPermitted        [1] IMPLICIT ServicesPermitted  OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics      [3] IMPLICIT CallCharacteristics  OPTIONAL,
  retrievedConnectionInfo  [4] IMPLICIT ConnectionInformation OPTIONAL,
  callLinkageData          [5] IMPLICIT CallLinkageData      OPTIONAL,
  extensions               CSTACommonArguments           OPTIONAL}

END -- of CSTA-retrieved-event
```



### 15.2.17 Service initiated

```
CSTA-service-initiated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) service-initiated-event( 34) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID, AssociatedCallingDeviceID, NetworkCalledDeviceID,
NetworkCallingDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

ServiceInitiatedEvent ::=
SEQUENCE
{
  initiatedConnection      ConnectionID,
  initiatingDevice         SubjectDeviceID,
  localConnectionInfo     LocalConnectionState      OPTIONAL,
  correlatorData          [0] IMPLICIT CorrelatorData  OPTIONAL,
  cause                   EventCause,
  servicesPermitted       [1] IMPLICIT ServicesPermitted  OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics  OPTIONAL,
  callCharacteristics      [3] IMPLICIT CallCharacteristics  OPTIONAL,
  initiatedConnectionInfo [4] IMPLICIT ConnectionInformation  OPTIONAL,
  networkCallingDevice     NetworkCallingDeviceID      OPTIONAL,
  networkCalledDevice     NetworkCalledDeviceID       OPTIONAL,
  associatedCallingDevice  AssociatedCallingDeviceID   OPTIONAL,
  callLinkageData          [5] IMPLICIT CallLinkageData    OPTIONAL,
  extensions               CSTACommonArguments        OPTIONAL}

END -- of CSTA-service-initiated-event
```

## 15.2.18 Transferred

```
CSTA-transferred-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) transferred-event( 35) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState, ConnectionList FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageDataList, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ChargingInfo FROM CSTA-charge-info
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charge-info( 133) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

TransferredEvent ::=
SEQUENCE
{
  primaryOldCall          ConnectionID,
  secondaryOldCall        [0] IMPLICIT ConnectionID          OPTIONAL,
  transferringDevice      SubjectDeviceID,
  transferredToDevice     SubjectDeviceID,
  transferredConnections  [1] IMPLICIT ConnectionList,
  localConnectionInfo     LocalConnectionState                OPTIONAL,
  correlatorData          [2] IMPLICIT CorrelatorData          OPTIONAL,
  userData                UserData                            OPTIONAL,
  chargingInfo            [3] IMPLICIT ChargingInfo            OPTIONAL,
  cause                  EventCause,
  servicesPermitted       [4] IMPLICIT ServicesPermitted      OPTIONAL,
  mediaCallCharacteristics [5] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics     [6] IMPLICIT CallCharacteristics     OPTIONAL,
  callLinkageDataList     [7] IMPLICIT CallLinkageDataList     OPTIONAL,
  extensions              CSTACommonArguments                 OPTIONAL}

END -- of CSTA-transferred-event
```

## 16 Call associated features

### 16.1 Services

#### 16.1.1 Associate data

```
CSTA-associate-data
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) associate-data( 230) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallQualifyingData FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) };

associateData      OPERATION ::=
{
  ARGUMENT      AssociateDataArgument
  RESULT        AssociateDataResult
  ERRORS        {universalFailure}
  CODE          local: 230
}

AssociateDataArgument ::= SEQUENCE
{
  existingCall      ConnectionID,
  accountCode       [0] IMPLICIT AccountInfo      OPTIONAL,
  authCode          [1] IMPLICIT AuthCode          OPTIONAL,
  correlatorData    [2] IMPLICIT CorrelatorData     OPTIONAL,
  callQualifyingData [3] IMPLICIT CallQualifyingData OPTIONAL,
  extensions        CSTACommonArguments            OPTIONAL}

AssociateDataResult ::=
CHOICE
{extensions        CSTACommonArguments,
 noData            NULL}

END -- of CSTA-associate-data
```

## 16.1.2 Cancel telephony tones

```
CSTA-cancel-telephony-tones
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) cancel-telephony-tones( 231) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

cancelTelephonyTones          OPERATION ::=
{
    ARGUMENT      CancelTelephonyTonesArgument
    RESULT        CancelTelephonyTonesResult
    ERRORS        {universalFailure}
    CODE          local: 231
}

CancelTelephonyTonesArgument ::= SEQUENCE
{
    connectionToStopTone      ConnectionID,
    extensions                 CSTACommonArguments    OPTIONAL}

CancelTelephonyTonesResult ::=
CHOICE
{extensions                 CSTACommonArguments,
 noData                     NULL}

END -- of CSTA-cancel-telephony-tones
```

### 16.1.3 Generate digits

```
CSTA-generate-digits
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) generate-digits( 232) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

generateDigits      OPERATION ::=
{
  ARGUMENT      GenerateDigitsArgument
  RESULT        GenerateDigitsResult
  ERRORS        {universalFailure}
  CODE          local: 232
}

GenerateDigitsArgument ::= SEQUENCE
{
  connectionToSendDigits  ConnectionID,
  digitMode                DigitMode,
  charactersToSend         IA5String,
  toneDuration             [0] IMPLICIT INTEGER OPTIONAL,
  pulseRate                [1] IMPLICIT INTEGER OPTIONAL,
  pauseDuration            [2] IMPLICIT INTEGER OPTIONAL,
  extensions               CSTACommonArguments OPTIONAL
}

GenerateDigitsResult ::=
CHOICE
{extensions          CSTACommonArguments,
 noData              NULL}

DigitMode ::= ENUMERATED
{
  rotaryPulse (0),
  dtmf        (1)}

END -- of CSTA-generate-digits
```

## 16.1.4 Generate telephony tones

```
CSTA-generate-telephony-tones
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) generate-telephony-tones( 233) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
TelephonyTone FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

generateTelephonyTones          OPERATION ::=
{
    ARGUMENT      GenerateTelephonyTonesArgument
    RESULT        GenerateTelephonyTonesResult
    ERRORS        {universalFailure}
    CODE          local: 233
}

GenerateTelephonyTonesArgument ::= SEQUENCE
{
    connectionToSendTone      ConnectionID,
    toneToSend                TelephonyTone,
    toneDuration              INTEGER
                              OPTIONAL,
    extensions                CSTACommonArguments
                              OPTIONAL}

GenerateTelephonyTonesResult ::=
CHOICE
{extensions                CSTACommonArguments,
 noData                    NULL}

END -- of CSTA-generate-telephony-tones
```

### 16.1.5 Send user information

```
CSTA-send-user-information
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) send-user-information( 234) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
UserData FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

sendUserInfo      OPERATION ::=
{
    ARGUMENT      SendUserInfoArgument
    RESULT        SendUserInfoResult
    ERRORS        {universalFailure}
    CODE          local: 234
}

SendUserInfoArgument ::= SEQUENCE
{
    existingCall      ConnectionID,
    userData          UserData,
    extensions        CSTACommonArgumentsOPTIONAL}

SendUserInfoResult ::=
CHOICE
{extensions          CSTACommonArguments,
 noData              NULL}

END -- of CSTA-send-user-information
```

## 16.2 Events

### 16.2.1 Call information

```
CSTA-call-information-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-information-event( 41) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
CallingDeviceID, SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AccountInfo, AuthCode, CorrelatorData, UserData FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallLinkageDataList, CallQualifyingData, ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

CallInformationEvent ::= SEQUENCE
{
  connection          ConnectionID,
  device              SubjectDeviceID,
  callingDevice        CallingDeviceID
  accountInfo          [0] IMPLICIT AccountInfo      OPTIONAL,
  authCode             [1] IMPLICIT AuthCode         OPTIONAL,
  correlatorData       [2] IMPLICIT CorrelatorData    OPTIONAL,
  servicesPermitted    [3] IMPLICIT ServicesPermitted OPTIONAL,
  userData             UserData                      OPTIONAL,
  callQualifyingData   [4] IMPLICIT CallQualifyingData OPTIONAL,
  connectionInfo       ConnectionInformation         OPTIONAL,
  callLinkageDataList  [5] IMPLICIT CallLinkageDataList OPTIONAL,
  extensions           CSTACommonArguments          OPTIONAL}

END -- of CSTA-call-information-event
```



## 16.2.2 Charging

```
CSTA-charging-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charging-event( 240) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ChargingInfo FROM CSTA-charge-info
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) charge-info( 133) };

ChargingEvent ::= SEQUENCE
{
  connection          ConnectionID,
  chargedDevice       DeviceID,
  chargingInfo        ChargingInfo,
  cause               EventCause          OPTIONAL,
  extensions          CSTACommonArguments OPTIONAL}

END -- of CSTA-charging-event
```

### 16.2.3 Digits generated

```
CSTA-digits-generated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) digits-generated-event( 241) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

DigitsGeneratedEvent ::= SEQUENCE
{
  connection          ConnectionID,
  digitGeneratedList  IA5String,
  digitDurationList   [0] IMPLICIT SEQUENCE OF INTEGER OPTIONAL,
  pauseDurationList   [1] IMPLICIT SEQUENCE OF INTEGER OPTIONAL,
  connectionInfo      ConnectionInformation OPTIONAL,
  extensions          CSTACommonArguments OPTIONAL}

END -- of CSTA-digits-generated-event
```

#### 16.2.4 Telephony tones generated

```
CSTA-telephony-tones-generated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) telephony-tones-generated-event( 242) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
TelephonyTone FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) };

TelephonyTonesGeneratedEvent ::= SEQUENCE
{
  connection          ConnectionID,
  toneGenerated       TelephonyTone          OPTIONAL,
  toneFrequency       [0] IMPLICIT INTEGER   OPTIONAL,
  toneDuration        [1] IMPLICIT INTEGER   OPTIONAL,
  pauseDuration       [2] IMPLICIT INTEGER   OPTIONAL,
  connectionInfo      ConnectionInformation   OPTIONAL,
  extensions          CSTACCommonArguments    OPTIONAL}

END -- of CSTA-telephony-tones-generated-event
```

## 16.2.5 Service completion failure

```
CSTA-service-completion-failure-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) service-completion-failure-event( 243) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
MediaCallCharacteristics, ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

ServiceCompletionFailureEvent ::= SEQUENCE
{
  primaryCall          PrimaryOrSecondaryCall,
  secondaryCall        [0] IMPLICIT PrimaryOrSecondaryCall  OPTIONAL,
  otherDevsPrimaryCallList [1] IMPLICIT SEQUENCE OF OtherCall  OPTIONAL,
  otherDevsSecondaryCallList [2] IMPLICIT SEQUENCE OF OtherCall  OPTIONAL,
  mediaCallCharacteristics [3] IMPLICIT MediaCallCharacteristics  OPTIONAL,
  cause                EventCause,
  extensions            CSTACCommonArguments  OPTIONAL}

PrimaryOrSecondaryCall ::= SEQUENCE
{
  deviceID          DeviceID,
  connectionID      ConnectionID,
  localConnectionState LocalConnectionState,
  connectionInfo    ConnectionInformation  OPTIONAL}

OtherCall ::= SEQUENCE
{
  deviceID          DeviceID,
  connectionID      ConnectionID,
  localConnectionState LocalConnectionState  OPTIONAL,
  connectionInfo    ConnectionInformation  OPTIONAL}

END -- of CSTA-charging-event
```

## 17 Media attachment services and events

### 17.1 Services

#### 17.1.1 Attach media service

```
CSTA-attach-media-service
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) attach-media-service( 244) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{ joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
MediaServiceType, MediaServiceInstanceID, ConnectionMode,
ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

attachMediaService OPERATION ::=
{
  ARGUMENT    AttachMediaServiceArgument
  RESULT      AttachMediaServiceResult
  ERRORS      {universalFailure}
  CODE        local: 244
}

AttachMediaServiceArgument ::= SEQUENCE
{
  connection          ConnectionID,
  mediaServiceType    MediaServiceType,
  mediaServiceVersion INTEGER OPTIONAL,
  mediaServiceInstanceID MediaServiceInstanceID OPTIONAL,
  connectionMode      ConnectionMode,
  requestedConnectionState LocalConnectionState OPTIONAL,
  extensions           CSTACommonArguments OPTIONAL}

AttachMediaServiceResult ::= SEQUENCE
{
  mediaConnection      ConnectionID OPTIONAL,
  mediaDevice          [0] IMPLICIT DeviceID OPTIONAL,
  mediaServiceInstanceID MediaServiceInstanceID OPTIONAL,
  mediaConnectionInfo  [1] IMPLICIT ConnectionInformation OPTIONAL,
  extensions           CSTACommonArguments OPTIONAL}

END -- of CSTA-attach-media-service
```

## 17.1.2 Detach media service

```
CSTA-detach-media-service
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) detach-media-service( 245) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
MediaServiceType FROM CSTA-media-services
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) media-services( 136) };

detachMediaService OPERATION ::=
{
    ARGUMENT    DetachMediaServiceArgument
    RESULT      DetachMediaServiceResult
    ERRORS      {universalFailure}
    CODE        local: 245
}

DetachMediaServiceArgument ::= SEQUENCE
{
    connection      ConnectionID,
    mediaServiceType MediaServiceType,
    extensions       CSTACommonArguments    OPTIONAL}

DetachMediaServiceResult ::= CHOICE
{
    extensions  CSTACommonArguments,
    noData      NULL}

END -- of CSTA-detach-media-service
```

## 17.2 Events

### 17.2.1 Media attached

```
CSTA-media-attached-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-attached-event( 246) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
MediaServiceType, MediaServiceInstanceID, MediaStreamID,
MediaCallCharacteristics, ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

MediaAttachedEvent ::= SEQUENCE
{
  mediaConnection          ConnectionID,
  mediaDevice              SubjectDeviceID,
  mediaServiceType         MediaServiceType,
  mediaServiceVersion      INTEGER OPTIONAL,
  mediaServiceInstanceID   [0] IMPLICIT MediaServiceInstanceID OPTIONAL,
  mediaStreamID            [1] IMPLICIT MediaStreamID OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics      CallCharacteristics OPTIONAL,
  localConnectionInfo      LocalConnectionState OPTIONAL,
  mediaConnectionInfo      [3] IMPLICIT ConnectionInformation OPTIONAL,
  extension                CSTACommonArguments OPTIONAL}

END -- of CSTA-media-attached-service
```

## 17.2.2 Media detached

```
CSTA-media-detached-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-detached-event( 247) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{ joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
LocalConnectionState FROM CSTA-connection-states
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) connection-states( 125) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
MediaServiceType, MediaServiceInstanceID, MediaStreamID,
MediaCallCharacteristics, ConnectionInformation FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

MediaDetachedEvent ::= SEQUENCE
{
  mediaConnection          ConnectionID,
  mediaDevice              SubjectDeviceID,
  mediaServiceType         MediaServiceType,
  mediaServiceVersion      INTEGER OPTIONAL,
  mediaServiceInstanceID   [0] IMPLICIT MediaServiceInstanceID OPTIONAL,
  mediaStreamID            [1] IMPLICIT MediaStreamID OPTIONAL,
  mediaCallCharacteristics [2] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics      CallCharacteristics OPTIONAL,
  localConnectionInfo      LocalConnectionState OPTIONAL,
  mediaConnectionInfo      [3] IMPLICIT ConnectionInformation OPTIONAL,
  extension                CSTACommonArguments OPTIONAL
}

END -- of CSTA-media-detached-service
```



## 18 Routeing services

### 18.1 Registration services

#### 18.1.1 Route register

```
CSTA-route-register
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) route-register( 248) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
RouteRegisterReqID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
MediaClass FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

routeRegister OPERATION ::=
{
  ARGUMENT    RouteRegisterArgument
  RESULT      RouteRegisterResult
  ERRORS      {universalFailure}
  CODE        local: 248
}

RouteRegisterArgument ::= SEQUENCE
{
  routeingDevice          DeviceID          OPTIONAL,
  requestedRouteingMediaClass MediaClass    OPTIONAL,
  extensions               CSTACommonArguments OPTIONAL}

RouteRegisterResult ::= SEQUENCE
{
  routeRegisterReqID      RouteRegisterReqID,
  actualRouteingMediaClassMediaClass    OPTIONAL,
  extensions               CSTACommonArguments    OPTIONAL}

END -- of CSTA-route-register
```

## 18.1.2 Route register abort

```
CSTA-route-register-abort
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) route-register-abort( 249) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
RouteRegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

routeRegisterAbort OPERATION ::=
{
    ARGUMENT          RouteRegisterAbortArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS   FALSE
    CODE              local: 249
}

RouteRegisterAbortArgument ::= SEQUENCE
{
    routeRegisterReqID    RouteRegisterReqID,
    extensions            CSTACommonArguments    OPTIONAL}

END -- of CSTA-route-register-abort
```

### 18.1.3 Route register cancel

```
CSTA-route-register-cancel
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) route-register-cancel( 250) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
RouteRegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

routeRegisterCancel OPERATION ::=
{
    ARGUMENT    RouteRegisterCancelArgument
    RESULT      RouteRegisterCancelResult
    ERRORS      {universalFailure}
    CODE        local: 250
}

RouteRegisterCancelArgument ::= SEQUENCE
{
    routeRegisterReqID    RouteRegisterReqID,
    extensions             CSTACommonArguments    OPTIONAL}

RouteRegisterCancelResult ::= CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

END -- of CSTA-route-register-cancel
```

## 18.2 Services

### 18.2.1 Re-Route

```
CSTA-re-route-request
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) re-route-request( 82) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
CorrelatorData, RouteRegisterReqID, RouteingCrossRefID
    FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CallLinkageData FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) }
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) };

reRouteRequest OPERATION ::=
{
    ARGUMENT          ReRouteRequestArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS    FALSE
    CODE               local: 32
}

ReRouteRequestArgument ::= SEQUENCE
{
    crossRefIdentifier    RouteingCrossRefID,
    routeRegisterReqID    [0] IMPLICIT RouteRegisterReqID    OPTIONAL,
    replyTimeout          [1] IMPLICIT INTEGER                OPTIONAL,
    correlatorData         [2] IMPLICIT CorrelatorData         OPTIONAL,
    callLinkageData        [3] IMPLICIT CallLinkageData        OPTIONAL,
    extensions             CSTACommonArguments                OPTIONAL}

END -- of CSTA-re-route-request
```

## 18.2.2 Route end

```
CSTA-route-end-request
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) route-end-request( 85) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure, ErrorValue FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CorrelatorData, RouteRegisterReqID, RouteingCrossRefID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

routeEndRequest OPERATION ::=
{
    ARGUMENT          RouteEndRequestArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS    FALSE
    CODE               local: 35
}

RouteEndRequestArgument ::= SEQUENCE {
    crossRefIdentifier    RouteingCrossRefID,
    routeRegisterReqID    [ 0] IMPLICIT RouteRegisterReqID      OPTIONAL,
    errorValue            [ 1] ErrorValue                        OPTIONAL,
    correlatorData        [ 2] IMPLICIT CorrelatorData          OPTIONAL,
    extensions            CSTACommonArguments                   OPTIONAL}

END -- of CSTA-route-end-request
```

### 18.2.3 Route reject

```
CSTA-route-reject
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) route-reject( 86) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
CorrelatorData, RouteRegisterReqID, RouteingCrossRefID
FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

routeReject OPERATION ::=
{
  ARGUMENT          RouteRejectArgument
  ERRORS            {universalFailure}
  ALWAYS RESPONDS   FALSE
  CODE              local: 36
}

RouteRejectArgument ::=
SEQUENCE
{crossRefIdentifier      RouteingCrossRefID,
 routeRegisterReqID     [0] IMPLICIT RouteRegisterReqID OPTIONAL,
 rejectCause             [1] IMPLICIT RejectCause          OPTIONAL,
 correlatorData          [2] IMPLICIT CorrelatorData        OPTIONAL,
 extensions              CSTACommonArguments              OPTIONAL}

RejectCause ::= ENUMERATED
{
  busyOverflow           (1),
  queueTimeOverflow      (2),
  capacityOverflow       (3),
  calendarOverflow       (4),
  unknownOverflow        (5)}

END -- of CSTA-route-reject
```

## 18.2.4 Route request

```
CSTA-route-request
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) route-request( 81) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
AssociatedCallingDeviceID, AssociatedCalledDeviceID, CalledDeviceID,
CallingDeviceID, SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
CorrelatorData, SelectValue, RouteRegisterReqID, RouteingCrossRefID
FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
CallCharacteristics, CallLinkageData FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
ConnectionInformation, MediaCallCharacteristics FROM CSTA-media-services
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) media-services( 136) };

routeRequest OPERATION ::=
{
  ARGUMENT          RouteRequestArgument
  ERRORS             {universalFailure}
  ALWAYS RESPONDS    FALSE
  CODE               local: 31
}

RouteRequestArgument ::= SEQUENCE
{
  crossRefIdentifier      RouteingCrossRefID,
  routeRegisterReqID      [0] IMPLICIT RouteRegisterReqID      OPTIONAL,
  currentRoute            CalledDeviceID,
  callingDevice            CallingDeviceID                      OPTIONAL,
  routeingDevice           SubjectDeviceID                      OPTIONAL,
  routedCall              ConnectionID                          OPTIONAL,
  routeSelAlgorithm        [1] IMPLICIT SelectValue            OPTIONAL,
  associatedCallingDevice   AssociatedCallingDeviceID           OPTIONAL,
  associatedCalledDevice    AssociatedCalledDeviceID            OPTIONAL,
  priority                 [2] IMPLICIT BOOLEAN                OPTIONAL,
  replyTimeout             [3] IMPLICIT INTEGER                OPTIONAL,
  correlatorData           [4] IMPLICIT CorrelatorData          OPTIONAL,
  mediaCallCharacteristics [5] IMPLICIT MediaCallCharacteristics OPTIONAL,
  callCharacteristics       [6] IMPLICIT CallCharacteristics    OPTIONAL,
  routeCallInfo            [7] IMPLICIT ConnectionInformation  OPTIONAL,
  callLinkageData          [8] IMPLICIT CallLinkageData          OPTIONAL,
  extensions               CSTACommonArguments                 OPTIONAL}

END -- of CSTA-route-request
```

## 18.2.5 Route select

```
CSTA-route-select-request
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) route-select-request( 83) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CorrelatorData, RetryValue, RouteingCrossRefID, RouteRegisterReqID
    FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

routeSelectRequest      OPERATION ::=
{
    ARGUMENT              RouteSelectRequestArgument
    ERRORS                 {universalFailure}
    ALWAYS RESPONDS       FALSE
    CODE                   local: 33
}

RouteSelectRequestArgument ::=
SEQUENCE
{crossRefIdentifier      RouteingCrossRefID,
 routeRegisterReqID      [0] IMPLICIT RouteRegisterReqID      OPTIONAL,
 routeSelected            [1] DeviceID,
 alternateRoutes          [2] IMPLICIT SEQUENCE OF DeviceID    OPTIONAL,
 remainRetries            [3] RetryValue                        OPTIONAL,
 routeUsedReq            [4] IMPLICIT BOOLEAN                  OPTIONAL,
 correlatorData           [5] IMPLICIT CorrelatorData           OPTIONAL,
 extensions               CSTACommonArguments                  OPTIONAL}

END -- of CSTA-route-select-request
```



## 18.2.6 Route used

```
CSTA-route-used-request
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) route-used-request( 84) }
DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CallingDeviceID, CalledDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CorrelatorData, RouteRegisterReqID, RouteingCrossRefID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CallLinkageData FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) }
;

routeUsedRequest      OPERATION ::=
{
    ARGUMENT          RouteUsedRequestArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS   FALSE
    CODE               local: 34
}

RouteUsedRequestArgument ::= SEQUENCE
{
    crossRefIdentifier  RouteingCrossRefID,
    routeRegisterReqID [0] IMPLICIT RouteRegisterReqID    OPTIONAL,
    routeUsed           CalledDeviceID,
    callingDevice       CallingDeviceID                    OPTIONAL,
    domain              BOOLEAN                            OPTIONAL,
    correlatorData      [1] IMPLICIT CorrelatorData        OPTIONAL,
    callLinkageData     [2] IMPLICIT CallLinkageData        OPTIONAL,
    extensions          CSTACommonArguments                OPTIONAL}

END -- of CSTA-route-used-request
```

## 19 Physical device features

### 19.1 Services

#### 19.1.1 Button press

```
CSTA-button-press
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) button-press( 260) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ButtonID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

buttonPress OPERATION ::=
{
  ARGUMENT    ButtonPressArgument
  RESULT      ButtonPressResult
  ERRORS      {universalFailure}
  CODE        local: 260
}

ButtonPressArgument ::= SEQUENCE
{
  device      DeviceID,
  button      ButtonID,
  extensions  CSTACCommonArguments OPTIONAL}

ButtonPressResult ::= CHOICE
{
  extensions  CSTACCommonArguments,
  noData      NULL}

END -- of CSTA-button-press
```

### 19.1.2 Get auditory apparatus information

```
CSTA-get-auditory-apparatus-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-auditory-apparatus-information( 261) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, AuditoryApparatusList FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getAuditoryApparatusInformation OPERATION ::=
{
  ARGUMENT    GetAuditoryApparatusInformationArgument
  RESULT      GetAuditoryApparatusInformationResult
  ERRORS      {universalFailure}
  CODE        local: 261
}

GetAuditoryApparatusInformationArgument ::= SEQUENCE
{
  device          DeviceID,
  auditoryApparatus AuditoryApparatusID OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

GetAuditoryApparatusInformationResult ::= SEQUENCE
{
  auditoryApparatusList AuditoryApparatusList,
  extensions            CSTACommonArguments OPTIONAL}

END -- of CSTA-get-auditory-apparatus-information
```

### 19.1.3 Get button information

```
CSTA-get-button-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-button-information( 262) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ButtonID, LampID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getButtonInformation OPERATION ::=
{
  ARGUMENT    GetButtonInformationArgument
  RESULT      GetButtonInformationResult
  ERRORS      {universalFailure}
  CODE        local: 262
}

GetButtonInformationArgument ::= SEQUENCE
{
  device      DeviceID,
  button      ButtonID
  extensions  CSTACCommonArguments OPTIONAL,
}

GetButtonInformationResult ::= SEQUENCE
{
  buttonList  ButtonList,
  extensions  CSTACCommonArguments OPTIONAL,
}

ButtonList ::= SEQUENCE OF SEQUENCE
{
  button      ButtonID,
  buttonLabel [0] IMPLICIT IA5String OPTIONAL,
  buttonLabelSettable [1] IMPLICIT BOOLEAN OPTIONAL,
  buttonFunction [2] IMPLICIT IA5String OPTIONAL,
  buttonAssociatedNumber [3] IMPLICIT DeviceID OPTIONAL,
  buttonAssociatedNumberSettable [4] IMPLICIT BOOLEAN OPTIONAL,
  buttonPressIndicator [5] IMPLICIT BOOLEAN OPTIONAL,
  lampList     SEQUENCE OF LampID OPTIONAL,
}
```

END -- of CSTA-get-button-information

## 19.1.4 Get display

```
CSTA-get-display
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-display( 263) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
DisplayID, CharacterSet FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

getDisplay OPERATION ::=
{
    ARGUMENT    GetDisplayArgument
    RESULT      GetDisplayResult
    ERRORS      {universalFailure}
    CODE        local: 263
}

GetDisplayArgument ::= SEQUENCE
{
    device      DeviceID,
    display     DisplayID,
    extensions  CSTACommonArguments OPTIONAL,
}

GetDisplayResult ::= SEQUENCE
{
    displayList DisplayList,
    extensions  CSTACommonArguments OPTIONAL
}

DisplayList ::= SEQUENCE OF SEQUENCE
{
    displayID      DisplayID,
    logicalRows    INTEGER,
    logicalColumns INTEGER,
    physicalRows   [0] IMPLICIT INTEGER OPTIONAL,
    physicalColumns [1] IMPLICIT INTEGER OPTIONAL,
    physicalBaseRowNumber [2] IMPLICIT INTEGER OPTIONAL,
    physicalBaseColumnNumber [3] IMPLICIT INTEGER OPTIONAL,
    characterSet    CharacterSet OPTIONAL,
    contentsOfDisplay IA5String
}

END -- of CSTA-get-display
```

### 19.1.5 Get hookswitch status

```
CSTA-get-hookswitch-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-hookswitch-status( 264) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
HookswitchID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getHookswitchStatus OPERATION ::=
{
  ARGUMENT    GetHookswitchStatusArgument
  RESULT      GetHookswitchStatusResult
  ERRORS      {universalFailure}
  CODE        local: 264
}

GetHookswitchStatusArgument ::= SEQUENCE
{
  device      DeviceID,
  hookswitch  HookswitchID          OPTIONAL,
  extensions  CSTACommonArguments  OPTIONAL}

GetHookswitchStatusResult ::= SEQUENCE
{
  hookswitchStatusList  HookswitchStatusList,
  extensions            CSTACommonArguments  OPTIONAL}

HookswitchStatusList ::= SEQUENCE OF SEQUENCE
{
  hookswitch      HookswitchID,
  hookswitchOnHook  BOOLEAN}

END -- of CSTA-get-hookswitch-status
```

### 19.1.6 Get lamp information

```
CSTA-get-lamp-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-lamp-information( 265) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ButtonID, LampID, LampColor FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getLampInformation OPERATION ::=
{
  ARGUMENT    GetLampInformationArgument
  RESULT      GetLampInformationResult
  ERRORS      {universalFailure}
  CODE        local: 265
}

GetLampInformationArgument ::= SEQUENCE
{
  device      DeviceID,
  lamp        LampID
  extensions  CSTACommonArguments OPTIONAL,
}

GetLampInformationResult ::= SEQUENCE
{
  lampList    LampList,
  extensions  CSTACommonArguments OPTIONAL
}

LampList ::= SEQUENCE OF SEQUENCE
{
  lamp        LampID,
  lampLabel   [0] IMPLICIT OCTET STRING      OPTIONAL,
  button      [1] IMPLICIT ButtonID          OPTIONAL,
  lampColor   LampColor                      OPTIONAL
}

END -- of CSTA-get-lamp-information
```

### 19.1.7 Get lamp mode

```
CSTA-get-lamp-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-lamp-mode( 266) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ButtonID, LampID, LampColor, LampMode, LampBrightness
  FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getLampMode OPERATION ::=
{
  ARGUMENT    GetLampModeArgument
  RESULT      GetLampModeResult
  ERRORS      {universalFailure}
  CODE        local: 266
}

GetLampModeArgument ::= SEQUENCE
{
  device      DeviceID,
  lamp        LampID,
  extensions  CSTACommonArguments OPTIONAL,
}

GetLampModeResult ::= SEQUENCE
{
  lampModeList LampModeList,
  lamp          LampID,
  extensions    CSTACommonArguments OPTIONAL,
}

LampModeList ::= SEQUENCE OF SEQUENCE
{
  lamp          LampID,
  lampMode      LampMode,
  lampBrightness [0] IMPLICIT LampBrightness OPTIONAL,
  lampColor      [1] IMPLICIT LampColor OPTIONAL,
  button         [2] IMPLICIT ButtonID OPTIONAL,
}

END -- of CSTA-get-lamp-mode
```



### 19.1.8 Get message waiting indicator

```
CSTA-get-message-waiting-indicator
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-message-waiting-indicator( 267) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

getMessageWaitingIndicator OPERATION ::=
{
    ARGUMENT    GetMessageWaitingIndicatorArgument
    RESULT      GetMessageWaitingIndicatorResult
    ERRORS      {universalFailure}
    CODE        local: 267
}

GetMessageWaitingIndicatorArgument ::= SEQUENCE
{
    device      DeviceID,
    extensions  CSTACCommonArguments    OPTIONAL}

GetMessageWaitingIndicatorResult ::= SEQUENCE
{
    messageWaitingOn      BOOLEAN,
    deviceForMessage      DeviceID          OPTIONAL,
    lampIsPresent         BOOLEAN          OPTIONAL,
    extensions            CSTACCommonArguments    OPTIONAL}

END -- of CSTA-get-message-waiting-indicator
```

### 19.1.9 Get microphone gain

```
CSTA-get-microphone-gain
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-microphone-gain( 268) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, MicGainAbs FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getMicrophoneGain OPERATION ::=
{
  ARGUMENT    GetMicrophoneGainArgument
  RESULT      GetMicrophoneGainResult
  ERRORS      {universalFailure}
  CODE        local: 268
}

GetMicrophoneGainArgument ::= SEQUENCE
{
  device          DeviceID,
  auditoryApparatus AuditoryApparatusID OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

GetMicrophoneGainResult ::= SEQUENCE
{
  microphoneGainList MicrophoneGainList,
  extensions          CSTACommonArguments OPTIONAL}

MicrophoneGainList ::= SEQUENCE OF SEQUENCE
{
  auditoryApparatus AuditoryApparatusID,
  micGainAbs        MicGainAbs          OPTIONAL}

END -- of CSTA-get-microphone-gain
```

### 19.1.10 Get microphone mute

```
CSTA-get-microphone-mute
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-microphone-mute( 269) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

getMicrophoneMute OPERATION ::=
{
    ARGUMENT    GetMicrophoneMuteArgument
    RESULT      GetMicrophoneMuteResult
    ERRORS      {universalFailure}
    CODE        local: 269
}

GetMicrophoneMuteArgument ::= SEQUENCE
{
    device                DeviceID,
    auditoryApparatus     AuditoryApparatusID    OPTIONAL,
    extensions            CSTACommonArguments    OPTIONAL}

GetMicrophoneMuteResult ::= SEQUENCE
{
    microphoneMuteList    MicrophoneMuteList,
    extensions            CSTACommonArguments    OPTIONAL}

MicrophoneMuteList ::= SEQUENCE OF SEQUENCE
{
    auditoryApparatus     AuditoryApparatusID,
    microphoneMuteOn      BOOLEAN}

END -- of CSTA-get-microphone-mute
```

### 19.1.11 Get ringer status

```
CSTA-get-ringer-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-ringer-status( 270) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
RingerID, RingMode FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getRingerStatus OPERATION ::=
{
  ARGUMENT    GetRingerStatusArgument
  RESULT      GetRingerStatusResult
  ERRORS      {universalFailure}
  CODE        local: 270
}

GetRingerStatusArgument ::= SEQUENCE
{
  device      DeviceID,
  ringer      RingerID,
  extensions  CSTACommonArguments OPTIONAL,
}

GetRingerStatusResult ::= SEQUENCE
{
  ringerStatusList RingerStatusList,
  extensions       CSTACommonArguments OPTIONAL}

RingerStatusList ::= SEQUENCE OF SEQUENCE
{
  ringer      RingerID,
  ringMode    RingMode,
  ringCount   [0] IMPLICIT INTEGER (0..1000)    OPTIONAL,
  ringPattern [1] IMPLICIT INTEGER              OPTIONAL,
  ringVolAbs  [2] IMPLICIT INTEGER (0..100)      OPTIONAL}

END -- of CSTA-get-ringer-status
```

### 19.1.12 Get speaker mute

```
CSTA-get-speaker-mute
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-speaker-mute( 271) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getSpeakerMute OPERATION ::=
{
  ARGUMENT    GetSpeakerMuteArgument
  RESULT      GetSpeakerMuteResult
  ERRORS      {universalFailure}
  CODE        local: 271
}

GetSpeakerMuteArgument ::= SEQUENCE
{
  device          DeviceID,
  auditoryApparatus AuditoryApparatusID OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

GetSpeakerMuteResult ::= SEQUENCE
{
  speakerMuteList SpeakerMuteList,
  extensions      CSTACommonArguments OPTIONAL}

SpeakerMuteList ::= SEQUENCE OF SEQUENCE
{
  auditoryApparatus AuditoryApparatusID,
  speakerMuteOn     BOOLEAN}

END -- of CSTA-get-speaker-mute
```

### 19.1.13 Get speaker volume

```
CSTA-get-speaker-volume
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-speaker-volume( 272) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, VolAbs FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

getSpeakerVolume OPERATION ::=
{
  ARGUMENT    GetSpeakerVolumeArgument
  RESULT      GetSpeakerVolumeResult
  ERRORS      {universalFailure}
  CODE        local: 272
}

GetSpeakerVolumeArgument ::= SEQUENCE
{
  device          DeviceID,
  auditoryApparatus AuditoryApparatusID OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

GetSpeakerVolumeResult ::= SEQUENCE
{
  speakerVolumeList SpeakerVolumeList,
  extensions         CSTACommonArguments OPTIONAL}

SpeakerVolumeList ::= SEQUENCE OF SEQUENCE
{
  auditoryApparatus AuditoryApparatusID,
  speakerVolAbs     VolAbs OPTIONAL}

END -- of CSTA-get-speaker-volume
```

#### 19.1.14 Set button information

```
CSTA-set-button-information
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-button-information( 273) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ButtonID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

setButtonInformation OPERATION ::=
{
    ARGUMENT      SetButtonInformationArgument
    RESULT        SetButtonInformationResult
    ERRORS        {universalFailure}
    CODE          local: 273
}

SetButtonInformationArgument ::= SEQUENCE
{
    device          DeviceID,
    button          ButtonID,
    buttonLabel     IA5String (SIZE(0..64)) OPTIONAL,
    buttonAssociatedNumber DeviceID OPTIONAL,
    extensions      CSTACommonArguments OPTIONAL}

SetButtonInformationResult ::= CHOICE
{
    extensions CSTACommonArguments,
    noData     NULL}

END -- of CSTA-set-button-information
```

### 19.1.15 Set display

```
CSTA-set-display
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-display( 274) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DisplayID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setDisplay OPERATION ::=
{
  ARGUMENT      SetDisplayArgument
  RESULT        SetDisplayResult
  ERRORS        {universalFailure}
  CODE          local: 274
}

SetDisplayArgument ::= SEQUENCE
{
  device          DeviceID,
  display         DisplayID,
  physicalBaseRowNumber [0] IMPLICIT INTEGER,
  physicalBaseColumnNumber [1] IMPLICIT INTEGER,
  contentsOfDisplay IA5String (SIZE(0..240)),
  offset          [2] IMPLICIT INTEGER,
  extensions      CSTACommonArguments
}

SetDisplayResult ::= CHOICE
{
  extensions CSTACommonArguments,
  noData      NULL}

END -- of CSTA-set-display
```



### 19.1.16 Set hookswitch status

```
CSTA-set-hookswitch-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-hookswitch-status( 275) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
HookswitchID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

setHookswitchStatus OPERATION ::=
{
    ARGUMENT      SetHookswitchStatusArgument
    RESULT        SetHookswitchStatusResult
    ERRORS        {universalFailure}
    CODE          local: 275
}

SetHookswitchStatusArgument ::= SEQUENCE
{
    device          DeviceID,
    hookswitch      HookswitchID,
    hookswitchOnHook  BOOLEAN,
    extensions      CSTACommonArguments OPTIONAL}

SetHookswitchStatusResult ::= CHOICE
{
    extensions      CSTACommonArguments,
    noData          NULL}

END -- of CSTA-set-hookswitch-status
```

### 19.1.17 Set lamp mode

```
CSTA-set-lamp-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-lamp-mode( 276) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
LampID, LampColor, LampMode, LampBrightness
FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setLampMode OPERATION ::=
{
  ARGUMENT    SetLampModeArgument
  RESULT      SetLampModeResult
  ERRORS      {universalFailure}
  CODE        local: 276
}

SetLampModeArgument ::= SEQUENCE
{
  device          DeviceID,
  lamp            LampID,
  lampMode        LampMode,
  lampBrightness  LampBrightness OPTIONAL,
  lampColor       LampColor OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

SetLampModeResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

END -- of CSTA-set-lamp-mode
```

### 19.1.18 Set message waiting indicator

```
CSTA-set-message-waiting-indicator
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-message-waiting-indicator( 277) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

setMessageWaitingIndicator OPERATION ::=
{
    ARGUMENT    SetMessageWaitingIndicatorArgument
    RESULT      SetMessageWaitingIndicatorResult
    ERRORS      {universalFailure}
    CODE        local: 277
}

SetMessageWaitingIndicatorArgument ::= SEQUENCE
{
    device                DeviceID,
    messageWaitingOn      BOOLEAN,
    deviceForMessage      DeviceID          OPTIONAL,
    extensions            CSTACommonArguments  OPTIONAL}

SetMessageWaitingIndicatorResult ::= CHOICE
{
    extensions  CSTACommonArguments,
    noData     NULL}

END -- of CSTA-set-message-waiting-indicator
```

### 19.1.19 Set microphone gain

```
CSTA-set-microphone-gain
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-microphone-gain( 278) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, MicrophoneGain FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setMicrophoneGain OPERATION ::=
{
  ARGUMENT    SetMicrophoneGainArgument
  RESULT      SetMicrophoneGainResult
  ERRORS      {universalFailure}
  CODE        local: 278
}

SetMicrophoneGainArgument ::= SEQUENCE
{
  device          DeviceID,
  auditoryApparatus AuditoryApparatusID,
  microphoneGain  MicrophoneGain,
  extensions      CSTACommonArguments OPTIONAL}

SetMicrophoneGainResult ::= CHOICE
{
  extensions CSTACommonArguments,
  noData      NULL}

END -- of CSTA-set-microphone-gain
```

### 19.1.20 Set microphone mute

```
CSTA-set-microphone-mute
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-microphone-mute( 279) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

setMicrophoneMute OPERATION ::=
{
    ARGUMENT      SetMicrophoneMuteArgument
    RESULT        SetMicrophoneMuteResult
    ERRORS        {universalFailure}
    CODE          local: 279
}

SetMicrophoneMuteArgument ::= SEQUENCE
{
    device          DeviceID,
    auditoryApparatus AuditoryApparatusID,
    microphoneMuteOn BOOLEAN,
    extensions      CSTACommonArguments OPTIONAL}

SetMicrophoneMuteResult ::= CHOICE
{
    extensions CSTACommonArguments,
    noData      NULL}

END -- of CSTA-set-microphone-mute
```

### 19.1.21 Set ringer status

```
CSTA-set-ringer-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-ringer-status( 280) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
RingerID, RingMode, Volume FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setRingerStatus OPERATION ::=
{
  ARGUMENT    SetRingerStatusArgument
  RESULT      SetRingerStatusResult
  ERRORS      {universalFailure}
  CODE        local: 280
}

SetRingerStatusArgument ::= SEQUENCE
{
  device          DeviceID,
  ringer          RingerID,
  ringMode        RingMode
  ringPattern     [1] IMPLICIT INTEGER
  ringVolume      [2] Volume
  extensions      CSTACCommonArguments
}

SetRingerStatusResult ::= CHOICE
{
  extensions      CSTACCommonArguments,
  noData          NULL}

END -- of CSTA-set-ringer-status
```

### 19.1.22 Set speaker mute

```
CSTA-set-speaker-mute
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-speaker-mute( 281) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

setSpeakerMute OPERATION ::=
{
    ARGUMENT      SetSpeakerMuteArgument
    RESULT        SetSpeakerMuteResult
    ERRORS        {universalFailure}
    CODE          local: 281
}

SetSpeakerMuteArgument ::= SEQUENCE
{
    device          DeviceID,
    auditoryApparatus AuditoryApparatusID,
    speakerMuteOn   BOOLEAN,
    extensions      CSTACommonArguments OPTIONAL}

SetSpeakerMuteResult ::= CHOICE
{
    extensions      CSTACommonArguments,
    noData          NULL}

END -- of CSTA-set-speaker-mute
```

### 19.1.23 Set speaker volume

```
CSTA-set-speaker-volume
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-speaker-volume( 282) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, Volume FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

setSpeakerVolume OPERATION ::=
{
  ARGUMENT    SetSpeakerVolumeArgument
  RESULT      SetSpeakerVolumeResult
  ERRORS      {universalFailure}
  CODE        local: 282
}

SetSpeakerVolumeArgument ::= SEQUENCE
{
  device          DeviceID,
  auditoryApparatus AuditoryApparatusID,
  speakerVolume   Volume,
  extensions      CSTACommonArguments OPTIONAL}

SetSpeakerVolumeResult ::= CHOICE
{
  extensions CSTACommonArguments,
  noData      NULL}

END -- of CSTA-set-speaker-volume
```



## 19.2 Events

### 19.2.1 Button information

```
CSTA-button-information-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) button-information-event( 283) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ButtonID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

ButtonInformationEvent ::= SEQUENCE
{
    device                SubjectDeviceID,
    button                ButtonID,
    buttonLabel           IA5String (SIZE(0..64)) OPTIONAL,
    buttonAssociatedNumber DeviceID                OPTIONAL,
    buttonPressIndicator  BOOLEAN                  OPTIONAL,
    extensions            CSTACCommonArguments    OPTIONAL}

END -- of CSTA-button-information-event
```

## 19.2.2 Button press

```
CSTA-button-press-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) button-press-event( 284) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ButtonID FROM CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) };

ButtonPressEvent ::= SEQUENCE
{
  device                               SubjectDeviceID,
  button                               ButtonID,
  buttonLabel                          IA5String (SIZE(0..64))    OPTIONAL,
  buttonAssociatedNumber DeviceID                                     OPTIONAL,
  extensions                           CSTACCommonArguments      OPTIONAL}

END -- of CSTA-button-press-event
```

### 19.2.3 Display updated

```
CSTA-display-updated-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) display-updated-event( 285) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
DisplayID, CharacterSet FROM CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) };

DisplayUpdatedEvent ::= SEQUENCE
{
  device                               SubjectDeviceID,
  displayID                           DisplayID           OPTIONAL,
  logicalRows                         INTEGER,
  logicalColumns                      INTEGER,
  physicalRows                        [0] IMPLICIT INTEGER OPTIONAL,
  physicalColumns                     [1] IMPLICIT INTEGER OPTIONAL,
  physicalBaseRowNumber               [2] IMPLICIT INTEGER OPTIONAL,
  physicalBaseColumnNumber            [3] IMPLICIT INTEGER OPTIONAL,
  characterSet                        CharacterSet          OPTIONAL,
  contentsOfDisplay                   IA5String,
  extensions                          CSTACCommonArguments OPTIONAL}

END -- of CSTA-display-updated-event
```

## 19.2.4 Hookswitch

```
CSTA-hookswitch-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) hookswitch-event( 286) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
HookswitchID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

HookswitchEvent ::= SEQUENCE
{
    device                SubjectDeviceID,
    hookswitch            HookswitchID,
    hookswitchOnHook      BOOLEAN,
    extensions            CSTACCommonArguments    OPTIONAL}

END -- of CSTA-hookswitch-event
```

### 19.2.5 Lamp mode

```
CSTA-lamp-mode-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) lamp-mode-event( 287) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
LampID, LampMode, LampBrightness, LampColor
FROM CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) };

LampModeEvent ::= SEQUENCE
{
    device                SubjectDeviceID,
    lamp                  LampID,
    lampLabel              OCTET STRING (SIZE(0..64))          OPTIONAL,
    lampMode               LampMode,
    lampBrightness         LampBrightness                      OPTIONAL,
    lampColor              LampColor                          OPTIONAL,
    extensions             CSTACommonArguments                 OPTIONAL}

END -- of CSTA-lamp-mode-event
```

## 19.2.6 Message waiting

```
CSTA-message-waiting-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) message-waiting-event( 44) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

MessageWaitingEvent ::=SEQUENCE
{
    targetDevice          SubjectDeviceID,
    deviceForMessage      DeviceID          OPTIONAL,
    messageWaitingOn      BOOLEAN,
    extensions            CSTACCommonArguments  OPTIONAL}

END -- of CSTA-message-waiting-event
```

### 19.2.7 Microphone gain

```
CSTA-microphone-gain-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) microphone-gain-event( 288) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, MicrophoneGain FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

MicrophoneGainEvent ::= SEQUENCE
{
    invokingDevice          SubjectDeviceID,
    auditoryApparatus       AuditoryApparatusID,
    microphoneGain          MicrophoneGain,
    extensions              CSTACommonArguments    OPTIONAL}

END -- of CSTA-microphone-gain-event
```

## 19.2.8 Microphone mute

```
CSTA-microphone-mute-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) microphone-mute-event( 45) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

MicrophoneMuteEvent ::= SEQUENCE
{
    invokingDevice          SubjectDeviceID,
    auditoryApparatus       AuditoryApparatusID,
    microphoneMuteOn        BOOLEAN,
    extensions              CSTACCommonArguments    OPTIONAL}

END -- of CSTA-microphone-mute-event
```



### 19.2.9 Ringer status

```
CSTA-ringer-status-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) ringer-status-event( 289) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
RingerID, RingMode, Volume FROM CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) };

RingerStatusEvent ::= SEQUENCE
{
  device          SubjectDeviceID,
  ringer          RingerID,
  ringMode        RingMode
  ringCount       [0] IMPLICIT INTEGER (0..1000)    OPTIONAL,
  ringPattern     [1] IMPLICIT INTEGER              OPTIONAL,
  ringVolume      [2] Volume                        OPTIONAL,
  extensions      CSTACCommonArguments              OPTIONAL}

END -- of CSTA-ringer-status-event
```

### 19.2.10 Speaker mute

```
CSTA-speaker-mute-event
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) speaker-mute-event( 46) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

SpeakerMuteEvent ::= SEQUENCE
{
    invokingDevice          SubjectDeviceID,
    auditoryApparatus       AuditoryApparatusID,
    speakerMuteOn           BOOLEAN,
    extensions              CSTACCommonArguments    OPTIONAL}

END -- of CSTA-speaker-mute-event
```

### 19.2.11 Speaker volume

```
CSTA-speaker-volume-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) speaker-volume-event( 47) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
AuditoryApparatusID, Volume FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

SpeakerVolumeEvent ::= SEQUENCE
{
    invokingDevice      SubjectDeviceID,
    auditoryApparatus   AuditoryApparatusID,
    speakerVolume       Volume,
    extensions          CSTACommonArguments    OPTIONAL}

END -- of CSTA-speaker-volume-event
```

## 20 Logical device features

### 20.1 Services

#### 20.1.1 Call back non-call-related

```
CSTA-call-back-non-call-related
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-back-non-call-related( 300) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

callBackNonCallRelated OPERATION ::=
{
  ARGUMENT    CallBackNonCallRelatedArgument
  RESULT      CallBackNonCallRelatedResult
  ERRORS      {universalFailure}
  CODE        local: 300
}

CallBackNonCallRelatedArgument ::= SEQUENCE
{
  originatingDevice    DeviceID,
  targetDevice          DeviceID,
  extensions            CSTACommonArguments OPTIONAL}

CallBackNonCallRelatedResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-call-back-non-call-related
```

## 20.1.2 Call back message non-call-related

```
CSTA-call-back-message-non-call-related
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-back-message-non-call-related( 301) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

callBackMessageNonCallRelated OPERATION ::=
{
  ARGUMENT    CallBackMessageNonCallRelatedArgument
  RESULT      CallBackMessageNonCallRelatedResult
  ERRORS      {universalFailure}
  CODE        local: 301
}

CallBackMessageNonCallRelatedArgument ::= SEQUENCE
{
  originatingDevice    DeviceID,
  targetDevice          DeviceID,
  extensions            CSTACommonArguments OPTIONAL}

CallBackMessageNonCallRelatedResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-call-back-message-non-call-related
```

### 20.1.3 Cancel call back

```
CSTA-cancel-call-back
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) cancel-call-back( 302) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

cancelCallBack OPERATION ::=
{
  ARGUMENT    CancelCallBackArgument
  RESULT      CancelCallBackResult
  ERRORS      {universalFailure}
  CODE        local: 302
}

CancelCallBackArgument ::= SEQUENCE
{
  originatingDevice  DeviceID,
  targetDevice       DeviceID,
  extensions         CSTACommonArguments OPTIONAL}

CancelCallBackResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

END -- of CSTA-cancel-call-back
```

#### 20.1.4 Cancel call back message

```
CSTA-cancel-call-back-message
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) cancel-call-back-message( 303) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

cancelCallBackMessage OPERATION ::=
{
    ARGUMENT    CancelCallBackMessageArgument
    RESULT      CancelCallBackMessageResult
    ERRORS      {universalFailure}
    CODE        local: 303
}

CancelCallBackMessageArgument ::= SEQUENCE
{
    originatingDevice    DeviceID,
    targetDevice          DeviceID,
    extensions            CSTACommonArguments OPTIONAL}

CancelCallBackMessageResult ::= CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

END -- of CSTA-cancel-call-back-message
```

## 20.1.5 Get agent state

```
CSTA-get-agent-state
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-agent-state( 304) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
AgentID, AgentState, PendingAgentState FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getAgentState OPERATION ::=
{
  ARGUMENT    GetAgentStateArgument
  RESULT      GetAgentStateResult
  ERRORS      {universalFailure}
  CODE        local: 304
}

GetAgentStateArgument ::= SEQUENCE
{
  device      DeviceID,
  acdGroup    DeviceID                OPTIONAL,
  extensions  CSTACommonArguments    OPTIONAL}

GetAgentStateResult ::= SEQUENCE
{
  agentStateList  AgentStateList,
  extensions      CSTACommonArguments OPTIONAL}

AgentStateList ::= SEQUENCE SIZE (1..32) OF AgentStateEntry

AgentStateEntry ::= SEQUENCE
{
  agentID      AgentID                OPTIONAL,
  loggedOnState  BOOLEAN,
  agentInfo    SEQUENCE OF AgentInfo  OPTIONAL}

AgentInfo ::= SEQUENCE
{
  acdGroup      DeviceID                OPTIONAL,
  agentState    AgentState,
  pendingAgentState  [0] IMPLICIT PendingAgentState  OPTIONAL,
  agentStateCondition  [1] IMPLICIT AgentStateCondition  OPTIONAL}

AgentStateCondition ::= ENUMERATED
{
  forcedPause (0),
  other       (1)}

END -- of CSTA-get-agent-state
```



## 20.1.6 Get auto answer

```
CSTA-get-auto-answer
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-auto-answer( 305) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

getAutoAnswer OPERATION ::=
{
    ARGUMENT    GetAutoAnswerArgument
    RESULT      GetAutoAnswerResult
    ERRORS      {universalFailure}
    CODE        local: 305
}

GetAutoAnswerArgument ::= SEQUENCE
{
    device      DeviceID,
    extensions  CSTACommonArguments OPTIONAL}

GetAutoAnswerResult ::= SEQUENCE
{
    autoAnswerOn      BOOLEAN,
    numberOfRings      INTEGER          OPTIONAL,
    extensions         CSTACommonArguments OPTIONAL}

END -- of CSTA-get-auto-answer
```

### 20.1.7 Get auto work mode

```
CSTA-get-auto-work-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-auto-work-mode( 306) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getAutoWorkMode OPERATION ::=
{
  ARGUMENT    GetAutoWorkModeArgument
  RESULT      GetAutoWorkModeResult
  ERRORS      {universalFailure}
  CODE        local: 306
}

GetAutoWorkModeArgument ::= SEQUENCE
{
  device      DeviceID,
  extensions  CSTACommonArguments OPTIONAL}

GetAutoWorkModeResult ::= SEQUENCE
{
  autoWorkOn      BOOLEAN,
  autoWorkInterval INTEGER          OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

END -- of CSTA-get-auto-work-mode
```

## 20.1.8 Get caller id status

```
CSTA-get-caller-id-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-caller-id-status( 307) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

getCallerIDStatus OPERATION ::=
{
    ARGUMENT    GetCallerIDStatusArgument
    RESULT      GetCallerIDStatusResult
    ERRORS      {universalFailure}
    CODE        local: 307
}

GetCallerIDStatusArgument ::= SEQUENCE
{
    device      DeviceID,
    extensions  CSTACommonArguments OPTIONAL}

GetCallerIDStatusResult ::= SEQUENCE
{
    callerIDProvided    BOOLEAN,
    extensions          CSTACommonArguments OPTIONAL}

END -- of CSTA-get-caller-id-status
```

## 20.1.9 Get do not disturb

```
CSTA-get-do-not-disturb
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-do-not-disturb( 308) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CallOrigination FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

getDoNotDisturb OPERATION ::=
{
  ARGUMENT    GetDoNotDisturbArgument
  RESULT      GetDoNotDisturbResult
  ERRORS      {universalFailure}
  CODE        local: 308
}

GetDoNotDisturbArgument ::= SEQUENCE
{
  device      DeviceID,
  extensions  CSTACommonArguments OPTIONAL}

GetDoNotDisturbResult ::= SEQUENCE
{
  doNotDisturbOn      BOOLEAN,
  callOrigination      CallOrigination      OPTIONAL,
  callingDeviceList    SEQUENCE OF DeviceID  OPTIONAL,
  extensions           CSTACommonArguments  OPTIONAL}

END -- of CSTA-get-do-not-disturb
```

### 20.1.10 Get forwarding

```
CSTA-get-forwarding
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-forwarding( 309) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
ForwardList FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

getForwarding OPERATION ::=
{
    ARGUMENT    GetForwardingArgument
    RESULT      GetForwardingResult
    ERRORS      {universalFailure}
    CODE        local: 309
}

GetForwardingArgument ::= SEQUENCE
{
    device      DeviceID,
    extensions  CSTACommonArguments OPTIONAL}

GetForwardingResult ::= SEQUENCE
{
    forwardingList ForwardList,
    extensions     CSTACommonArguments OPTIONAL}

END -- of CSTA-get-forwarding
```

### 20.1.11 Get last number dialed

```
CSTA-get-last-number-dialed
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-last-number-dialed( 310) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

getLastNumberDialed OPERATION ::=
{
    ARGUMENT    GetLastNumberDialedArgument
    RESULT      GetLastNumberDialedResult
    ERRORS      {universalFailure}
    CODE        local: 310
}

GetLastNumberDialedArgument ::= SEQUENCE
{
    device      DeviceID,
    extensions  CSTACommonArguments OPTIONAL}

GetLastNumberDialedResult ::= SEQUENCE
{
    numberDialed      DeviceID,
    extensions        CSTACommonArguments    OPTIONAL}

END -- of CSTA-get-last-number-dialed
```

## 20.1.12 Get routing mode

```
CSTA-get-routing-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) get-routing-mode( 311) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

getRoutingMode OPERATION ::=
{
    ARGUMENT    GetRoutingModeArgument
    RESULT      GetRoutingModeResult
    ERRORS      {universalFailure}
    CODE        local: 311
}

GetRoutingModeArgument ::= SEQUENCE
{
    device      DeviceID,
    extensions  CSTACommonArguments OPTIONAL}

GetRoutingModeResult ::= SEQUENCE
{
    routingMode    BOOLEAN,
    extensions     CSTACommonArguments    OPTIONAL}

END -- of CSTA-get-routing-mode
```

### 20.1.13 Set agent state

```
CSTA-set-agent-state
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-agent-state( 312) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
AgentID, AgentPassword, PendingAgentState FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setAgentState OPERATION ::=
{
  ARGUMENT    SetAgentStateArgument
  RESULT      SetAgentStateResult
  ERRORS      {universalFailure}
  CODE        local: 312
}

SetAgentStateArgument ::= SEQUENCE
{
  device                DeviceID,
  requestedAgentState    ReqAgentState,
  agentID                [2] IMPLICIT AgentID                OPTIONAL,
  password                [3] IMPLICIT AgentPassword          OPTIONAL,
  group                  DeviceID                              OPTIONAL,
  extensions              CSTACommonArguments                 OPTIONAL}

SetAgentStateResult ::= SEQUENCE
{
  pendingAgentState      PendingAgentState                    OPTIONAL,
  extensions              CSTACommonArguments                 OPTIONAL}

ReqAgentState ::= ENUMERATED
{
  loggedOn                (0),
  loggedOff                (1),
  notReady                (2),
  ready                   (3),
  workingAfterCall        (4)}

END -- of CSTA-set-agent-state
```



#### 20.1.14 Set auto answer

```
CSTA-set-auto-answer
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-auto-answer( 313) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

setAutoAnswer OPERATION ::=
{
    ARGUMENT    SetAutoAnswerArgument
    RESULT      SetAutoAnswerResult
    ERRORS      {universalFailure}
    CODE        local: 313
}

SetAutoAnswerArgument ::= SEQUENCE
{
    device          DeviceID,
    autoAnswerOn    BOOLEAN,
    numberOfRings   INTEGER          OPTIONAL,
    extensions      CSTACommonArguments OPTIONAL}

SetAutoAnswerResult ::= CHOICE
{
    extensions      CSTACommonArguments,
    noData          NULL}

END -- of CSTA-set-auto-answer
```

### 20.1.15 Set auto work mode

```
CSTA-set-auto-work-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-auto-work-mode( 314) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setAutoWorkMode OPERATION ::=
{
  ARGUMENT    SetAutoWorkModeArgument
  RESULT      SetAutoWorkModeResult
  ERRORS      {universalFailure}
  CODE        local: 314
}

SetAutoWorkModeArgument ::= SEQUENCE
{
  device          DeviceID,
  autoWorkOn      BOOLEAN,
  autoWorkInterval INTEGER (0..6000)    OPTIONAL,
  extensions      CSTACCommonArguments  OPTIONAL}

SetAutoWorkModeResult ::= CHOICE
{
  extensions  CSTACCommonArguments,
  noData      NULL}

END -- of CSTA-set-auto-work-mode
```

## 20.1.16 Set caller id status

```
CSTA-set-caller-id-status
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-caller-id-status( 315) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

setCallerIDStatus OPERATION ::=
{
    ARGUMENT    SetCallerIDStatusArgument
    RESULT      SetCallerIDStatusResult
    ERRORS      {universalFailure}
    CODE        local: 315
}

SetCallerIDStatusArgument ::= SEQUENCE
{
    device                DeviceID,
    callerIDProvided      BOOLEAN,
    extensions             CSTACommonArguments OPTIONAL}

SetCallerIDStatusResult ::= CHOICE
{
    extensions CSTACommonArguments,
    noData      NULL}

END -- of CSTA-set-caller-id-status
```

### 20.1.17 Set do not disturb

```
CSTA-set-do-not-disturb
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-do-not-disturb( 316) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CallOrigination FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setDoNotDisturb OPERATION ::=
{
  ARGUMENT    SetDoNotDisturbArgument
  RESULT      SetDoNotDisturbResult
  ERRORS      {universalFailure}
  CODE        local: 316
}

SetDoNotDisturbArgument ::= SEQUENCE
{
  device          DeviceID,
  doNotDisturbOn  BOOLEAN,
  callOrigination CallOrigination    OPTIONAL,
  callingDeviceList SEQUENCE OF DeviceID OPTIONAL,
  extensions      CSTACommonArguments OPTIONAL}

SetDoNotDisturbResult ::= CHOICE
{
  extensions CSTACommonArguments,
  noData     NULL}

END -- of CSTA-set-do-not-disturb
```

## 20.1.18 Set forwarding

```
CSTA-set-forwarding
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-forwarding( 317) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ForwardingType FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setForwarding OPERATION ::=
{
  ARGUMENT      SetForwardingArgument
  RESULT        SetForwardingResult
  ERRORS        {universalFailure}
  CODE          local: 317
}

SetForwardingArgument ::= SEQUENCE
{
  device          DeviceID,
  forwardingType  ForwardingType          OPTIONAL,
  activateForward BOOLEAN,
  forwardDN       DeviceID                OPTIONAL,
  ringCount       INTEGER (1..100)         OPTIONAL,
  extensions      CSTACommonArguments     OPTIONAL}

SetForwardingResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

END -- of CSTA-set-forwarding
```

### 20.1.19 Set routing mode

```
CSTA-set-routeing-mode
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) set-routeing-mode( 318) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

setRouteingMode OPERATION ::=
{
  ARGUMENT    SetRouteingModeArgument
  RESULT      SetRouteingModeResult
  ERRORS      {universalFailure}
  CODE        local: 318
}

SetRouteingModeArgument ::= SEQUENCE
{
  device          DeviceID,
  routeingMode    BOOLEAN,
  extensions      CSTACommonArguments OPTIONAL}

SetRouteingModeResult ::= CHOICE
{
  extensions      CSTACommonArguments,
  noData          NULL}

END -- of CSTA-set-routeing-mode
```

## 20.2 Events

### 20.2.1 Agent busy

```
CSTA-agent-busy-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-busy-event( 319) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
AgentID, PendingAgentState FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentBusyEvent ::= SEQUENCE
{
  agentDevice          SubjectDeviceID,
  agentID              AgentID              OPTIONAL,
  acdGroup             DeviceID             OPTIONAL,
  pendingAgentState    [2] IMPLICIT PendingAgentState OPTIONAL,
  cause               [3] IMPLICIT EventCause  OPTIONAL,
  extensions           CSTACommonArguments  OPTIONAL}

END -- of CSTA-agent-busy-event
```

## 20.2.2 Agent logged off

```
CSTA-agent-logged-off-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-logged-off-event( 320) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
AgentID, AgentPassword FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentLoggedOffEvent ::= SEQUENCE
{
  agentDevice          SubjectDeviceID,
  agentID              [2] IMPLICIT AgentID          OPTIONAL,
  acdGroup             DeviceID                      OPTIONAL,
  agentPassword        [3] IMPLICIT AgentPassword    OPTIONAL,
  cause               EventCause                    OPTIONAL,
  extensions           CSTACommonArguments           OPTIONAL}

END -- of CSTA-agent-logged-off-event
```



### 20.2.3 Agent logged on

```
CSTA-agent-logged-on-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-logged-on-event( 321) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
AgentID, AgentPassword FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentLoggedOnEvent ::= SEQUENCE
{
  agentDevice          SubjectDeviceID,
  agentID              [2] IMPLICIT AgentID          OPTIONAL,
  acdGroup             DeviceID                      OPTIONAL,
  agentPassword        [3] IMPLICIT AgentPassword    OPTIONAL,
  cause               EventCause                    OPTIONAL,
  extensions           CSTACommonArguments           OPTIONAL}

END -- of CSTA-agent-logged-on-event
```

## 20.2.4 Agent not ready

```
CSTA-agent-not-ready-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-not-ready-event( 322) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
AgentID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentNotReadyEvent ::= SEQUENCE
{
  agentDevice          SubjectDeviceID,
  agentID              AgentID              OPTIONAL,
  acdGroup             DeviceID              OPTIONAL,
  cause                EventCause           OPTIONAL,
  extensions           CSTACommonArguments  OPTIONAL}
END -- of CSTA-agent-not-ready-event
```

## 20.2.5 Agent ready

```
CSTA-agent-ready-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-ready-event( 323) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
AgentID, AgentPassword FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentReadyEvent ::= SEQUENCE
{
  agentDevice          SubjectDeviceID,
  agentID              AgentID          OPTIONAL,
  acdGroup             DeviceID         OPTIONAL,
  cause               EventCause        OPTIONAL,
  extensions           CSTACommonArguments OPTIONAL}

END -- of CSTA-agent-ready-event
```

## 20.2.6 Agent working after call

```
CSTA-agent-working-after-call-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) agent-working-after-call-event( 324) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) event-causes( 121) }
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
AgentID, PendingAgentState FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AgentWorkingAfterCallEvent ::= SEQUENCE
{
  agentDevice          SubjectDeviceID,
  agentID              AgentID              OPTIONAL,
  acdGroup             DeviceID             OPTIONAL,
  pendingAgentState    [2] IMPLICIT ENUMERATED
                        {notReady    (0),
                         ready       (1),
                         null        (2)}
                        OPTIONAL,
  cause                [3] IMPLICIT EventCause OPTIONAL,
  extensions           CSTACommonArguments OPTIONAL}

END -- of CSTA-agent-working-after-call-event
```

## 20.2.7 Auto answer

```
CSTA-auto-answer-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) auto-answer-event( 40) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AutoAnswerEvent ::= SEQUENCE
{
  invokingDevice      SubjectDeviceID,
  autoAnswerOn        BOOLEAN,
  numberOfRings       INTEGER          OPTIONAL,
  extensions          CSTACCommonArguments  OPTIONAL}

END -- of CSTA-auto-answer-event
```

## 20.2.8 Auto work mode

```
CSTA-auto-work-mode-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) auto-work-mode-event( 326) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

AutoWorkModeEvent ::= SEQUENCE
{
  invokingDevice      SubjectDeviceID,
  autoWorkOn          BOOLEAN,
  autoWorkInterval    INTEGER,
  extensions           CSTACCommonArguments OPTIONAL}

END -- of CSTA-auto-work-mode-event
```

## 20.2.9 Call back

```
CSTA-call-back-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-back-event( 327) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

CallBackEvent ::= SEQUENCE
{
  originatingDevice      SubjectDeviceID,
  targetDevice           SubjectDeviceID,
  callBackSetCanceled    BOOLEAN,
  extensions             CSTACCommonArguments OPTIONAL}

END -- of CSTA-call-back-event
```

## 20.2.10 Call back message

```
CSTA-call-back-message-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-back-message-event( 328) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

CallBackMessageEvent ::= SEQUENCE
{
  originatingDevice      SubjectDeviceID,
  targetDevice           SubjectDeviceID,
  callBackMsgSetCanceled BOOLEAN,
  extensions             CSTACCommonArguments    OPTIONAL}

END -- of CSTA-call-back-message-event
```



### 20.2.11 Caller id status

```
CSTA-caller-id-status-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) caller-id-status-event( 329) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

CallerIDStatusEvent ::= SEQUENCE
{
  device                DeviceID,
  callerIDProvided      BOOLEAN,
  extensions            CSTACommonArguments    OPTIONAL}

END -- of CSTA-caller-id-status-event
```

## 20.2.12 Do not disturb

```
CSTA-do-not-disturb-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) do-not-disturb-event( 42) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CallOrigination FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

DoNotDisturbEvent ::= SEQUENCE
{
  device                SubjectDeviceID,
  doNotDisturbOn        BOOLEAN,
  callOrigination        CallOrigination      OPTIONAL,
  callingDeviceList      SEQUENCE OF DeviceID  OPTIONAL,
  extensions             CSTACommonArguments  OPTIONAL}

END -- of CSTA-do-not-disturb-event
```

### 20.2.13 Forwarding

```
CSTA-forwarding-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) forwarding-event( 43) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
DeviceID, SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ForwardingType, ForwardDefault FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

ForwardingEvent ::= SEQUENCE
{
  device                SubjectDeviceID,
  forwardingType         ForwardingType         OPTIONAL,
  forwardStatus          BOOLEAN,
  forwardTo             DeviceID                OPTIONAL,
  forwardDefault         ForwardDefault          OPTIONAL,
  ringCount             INTEGER (1..100)        OPTIONAL,
  extensions             CSTACommonArguments    OPTIONAL}

END -- of CSTA-forwarding-event
```

## 20.2.14 Routing mode

```
CSTA-routeing-mode-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) routeing-mode-event( 332) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
SubjectDeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

RouteingModeEvent ::= SEQUENCE
{
  device                SubjectDeviceID,
  routeingMode          BOOLEAN,
  extensions             CSTACommonArguments OPTIONAL}

END -- of CSTA-routeing-mode-event
```

## 21 Device maintenance events

### 21.1 Events

#### 21.1.1 Back in service

```
CSTA-back-in-service-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) back-in-service-event( 333) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

BackInServiceEvent ::= SEQUENCE
{
    device          SubjectDeviceID,
    cause           EventCause          OPTIONAL,
    extensions      CSTACCommonArguments OPTIONAL}

END -- of CSTA-back-in-service-event
```

### 21.1.2 Device capabilities changed

```
CSTA-device-capabilities-changed-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-capabilities-changed-event( 334) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

DeviceCapsChangedEvent ::= SEQUENCE
{
    device                SubjectDeviceID,
    cause                 EventCause          OPTIONAL,
    extensions            CSTACommonArguments OPTIONAL}

END -- of CSTA-device-capabilities-changed-event
```

### 21.1.3 Out of service

```
CSTA-out-of-service-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) out-of-service-event( 335) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
SubjectDeviceID FROM CSTA-device-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-identifiers( 123) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
;

OutOfServiceEvent ::= SEQUENCE
{
    device          SubjectDeviceID,
    cause           EventCause          OPTIONAL,
    extensions      CSTACommonArguments OPTIONAL}

END -- of CSTA-out-of-service-event
```

## 22 I/O services

### 22.1 Registration services

#### 22.1.1 I/O register

```
CSTA-io-register
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) io-register( 340) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-identifiers( 123) }
IORegisterReqID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

ioRegister      OPERATION ::=
{
  ARGUMENT      IORegisterArgument
  RESULT        IORegisterResult
  ERRORS        {universalFailure}
  CODE          local: 340
}

IORegisterArgument ::= SEQUENCE
{
  ioDevice      DeviceID          OPTIONAL,
  extensions    CSTACommonArguments OPTIONAL}

IORegisterResult ::= SEQUENCE
{
  ioRegisterReqID      IORegisterReqID,
  extensions            CSTACommonArguments    OPTIONAL}

END -- of CSTA-io-register
```



### 22.1.2 I/O register abort

```
CSTA-io-register-abort
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) io-register-abort( 341) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
IORegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

ioRegisterAbort      OPERATION ::=
{
    ARGUMENT          IORegisterAbortArgument
    ERRORS             {universalFailure}
    ALWAYS RESPONDS   FALSE
    CODE               local: 341
}

IORegisterAbortArgument ::= SEQUENCE
{
    ioRegisterReqID    IORegisterReqID,
    extensions          CSTACommonArguments    OPTIONAL}

END -- of CSTA-io-register-abort
```

### 22.1.3 I/O register cancel

```
CSTA-io-register-cancel
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) io-register-cancel( 342) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
IORegisterReqID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

ioRegisterCancelOPERATION ::=
{
  ARGUMENT      IORegisterCancelArgument
  RESULT        IORegisterCancelResult
  ERRORS        {universalFailure}
  CODE          local: 342
}

IORegisterCancelArgument ::= SEQUENCE
{
  ioRegisterReqID      IORegisterReqID,
  extensions            CSTACCommonArguments    OPTIONAL}

IORegisterCancelResult ::= CHOICE
{
  extensions    CSTACCommonArguments,
  noData        NULL}

END -- of CSTA-io-register-cancel
```

## 22.2 Services

### 22.2.1 Data path resumed

```
CSTA-data-path-resumed
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-path-resumed( 118) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

dataPathResumedOPERATION ::=
{
  ARGUMENT      DataPathResumedArgument
  RESULT        DataPathResumedResult
  ERRORS        {universalFailure}
  CODE          local: 118
}

DataPathResumedArgument ::= SEQUENCE
{
  ioCrossRefID      IOCrossRefID,
  ioRegisterReqID   IORegisterReqID      OPTIONAL,
  extensions        CSTACommonArguments  OPTIONAL}

DataPathResumedResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL }

END -- of CSTA-data-path-resumed
```

## 22.2.2 Data path suspended

```
CSTA-data-path-suspended
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-path-suspended( 116) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

dataPathSuspendedOPERATION ::=
{
  ARGUMENT      DataPathSuspendedArgument
  RESULT        DataPathSuspendedResult
  ERRORS        {universalFailure}
  CODE          local: 116
}

DataPathSuspendedArgument ::= SEQUENCE
{
  ioCrossRefID      IOCrossRefID,
  ioReqRegisterID   IORegisterReqID      OPTIONAL,
  extensions        CSTACCommonArguments OPTIONAL}

DataPathSuspendedResult ::= CHOICE
{
  extensions  CSTACCommonArguments,
  noData      NULL }

END -- of CSTA-data-path-suspended
```

### 22.2.3 Fast data

```
CSTA-fast-data
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) fast-data( 119) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTAObject FROM CSTA-switching-function-objects
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) switching-function-objects( 122) }
DataPathType, IORegisterReqID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DisplayID FROM CSTA-physical-device-feature
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) physical-device-feature( 137) };

fastData      OPERATION ::=
{
  ARGUMENT    FastDataArgument
  RESULT      FastDataResult
  ERRORS      {universalFailure}
  CODE        local: 119
}

FastDataArgument ::= SEQUENCE
{
  ioRegisterReqID      IORegisterReqID      OPTIONAL,
  object               CSTAObject,
  dataPathType         DataPathType         OPTIONAL,
  displayAttributes    DisplayAttribute     OPTIONAL,
  ioData               OCTET STRING (SIZE(0..240)) OPTIONAL,
  extensions           CSTACommonArguments  OPTIONAL}

FastDataResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData     NULL}

DisplayAttribute ::= SEQUENCE
{
  displayID          DisplayID          OPTIONAL,
  physicalBaseRowNumber  [0] IMPLICIT INTEGER OPTIONAL,
  physicalBaseColumnNumber [1] IMPLICIT INTEGER OPTIONAL,
  offset             [2] IMPLICIT INTEGER OPTIONAL}

END -- of CSTA-fast-data
```

## 22.2.4 Resume data path

```
CSTA-resume-data-path
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) resume-data-path( 117) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

resumeDataPath      OPERATION ::=
{
    ARGUMENT      ResumeDataPathArgument
    RESULT        ResumeDataPathResult
    ERRORS        {universalFailure}
    CODE          local: 117
}

ResumeDataPathArgument ::= SEQUENCE
{
    ioCrossRefID      IOCrossRefID,
    ioRegisterReqID   IORegisterReqID      OPTIONAL,
    extensions        CSTACCommonArguments OPTIONAL}

ResumeDataPathResult ::= CHOICE
{
    extensions        CSTACCommonArguments,
    noData            NULL }

END -- of CSTA-resume-data-path
```

## 22.2.5 Send broadcast data

```
CSTA-send-broadcast-data
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) send-broadcast-data( 114) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
DataPathType, DisplayAttributeList FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

sendBroadcastData  OPERATION ::=
{
    ARGUMENT      SendBroadcastDataArgument
    RESULT        SendBroadcastDataResult
    ERRORS        {universalFailure}
    CODE          local: 114
}

SendBroadcastDataArgument ::= SEQUENCE
{
    ioData          OCTET STRING (SIZE(0..240)),
    dataPathType    DataPathType
    displayAttributes DisplayAttributeList
    extensions      CSTACommonArguments
}

SendBroadcastDataResult ::= CHOICE
{
    extensions      CSTACommonArguments,
    noData          NULL}

END -- of CSTA-send-broadcast-data
```

## 22.2.6 Send data

```
CSTA-send-data
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) send-data( 112) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
IOCrossRefID, IORegisterReqID, DisplayAttributeList FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

sendData      OPERATION ::=
{
  ARGUMENT      SendDataArgument
  RESULT        SendDataResult
  ERRORS        {universalFailure}
  CODE          local: 112
}

SendDataArgument ::= SEQUENCE
{
  ioCrossRefID      IOCrossRefID,
  ioRegisterReqID   [0] IMPLICIT IORegisterReqID      OPTIONAL,
  displayAttributes DisplayAttributeList              OPTIONAL,
  ioData            OCTET STRING (SIZE(0..240)),
  ioCause           EventCause                        OPTIONAL,
  extensions        CSTACCommonArguments              OPTIONAL}

SendDataResult ::= CHOICE
{
  extensions CSTACCommonArguments,
  noData     NULL}

END -- of CSTA-send-data
```



## 22.2.7 Send multicast data

```
CSTA-send-multicast-data
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) send-multicast-data( 113) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, DisplayAttributeList FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

sendMulticastDataOPERATION ::=
{
    ARGUMENT      SendMulticastDataArgument
    RESULT        SendMulticastDataResult
    ERRORS        {universalFailure}
    CODE          local: 113
}

SendMulticastDataArgument ::= SEQUENCE
{
    ioCrossRefIDList      SEQUENCE OF IOCrossRefID,
    ioData                OCTET STRING (SIZE(0..240))      OPTIONAL,
    displayAttributes     DisplayAttributeList             OPTIONAL,
    extensions            CSTACommonArguments              OPTIONAL}

SendMulticastDataResult ::= CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

END -- of CSTA-send-multicast-data
```

## 22.2.8 Start data path

```
CSTA-start-data-path
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) start-data-path( 110) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{ joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0) }
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
CSTAObject FROM CSTA-switching-function-objects
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) switching-function-objects( 122) }
DataPathType, IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
DisplayID FROM CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) };

startDataPathOPERATION ::=
{
  ARGUMENT      StartDataPathArgument
  RESULT        StartDataPathResult
  ERRORS        { universalFailure }
  CODE          local: 110
}

StartDataPathArgument ::= SEQUENCE
{
  ioRegisterReqID      IORegisterReqID          OPTIONAL,
  object               CSTAObject,
  dataPathDirection    [0] IMPLICIT DataPathDirection  OPTIONAL,
  dataPathType         [1] IMPLICIT DataPathType        OPTIONAL,
  displayID            DisplayID                  OPTIONAL,
  numberOfCharactersToCollect [2] IMPLICIT INTEGER      OPTIONAL,
  terminationCharacter  IA5String (SIZE(1..1))         OPTIONAL,
  timeout              [3] IMPLICIT INTEGER            OPTIONAL,
  extensions           CSTACommonArguments          OPTIONAL
}

StartDataPathResult ::= SEQUENCE
{
  ioCrossRefID      IOCrossRefID,
  numberOfCharactersToCollect [0] IMPLICIT INTEGER  OPTIONAL,
  terminationCharacter  IA5String (SIZE(1..1))  OPTIONAL,
  timeout              [1] IMPLICIT INTEGER      OPTIONAL,
  extensions           CSTACommonArguments      OPTIONAL
}

DataPathDirection ::= ENUMERATED
{
  computeFunctionToObject      (0),
  objectToComputeFunction      (1),
  bidirectional                (2)
}

END -- of CSTA-start-data-path
```

## 22.2.9 Stop data path

```
CSTA-stop-data-path
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) stop-data-path( 111) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

stopDataPathOPERATION ::=
{
  ARGUMENT      StopDataPathArgument
  RESULT        StopDataPathResult
  ERRORS        {universalFailure}
  CODE          local: 111
}

StopDataPathArgument ::= SEQUENCE
{
  ioCrossRefID      IOCrossRefID,
  ioRegisterReqID   IORegisterReqID      OPTIONAL,
  extensions        CSTACCommonArguments OPTIONAL}

StopDataPathResult ::= CHOICE
{
  extensions CSTACCommonArguments,
  noData      NULL}

END -- of CSTA-stop-data-path
```

## 22.2.10 Suspend data path

```
CSTA-suspend-data-path
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) suspend-data-path( 115) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
IOCrossRefID, IORegisterReqID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

suspendDataPathOPERATION ::=
{
  ARGUMENT      SuspendDataPathArgument
  RESULT        SuspendDataPathResult
  ERRORS        {universalFailure}
  CODE          local: 115
}

SuspendDataPathArgument ::= SEQUENCE
{
  ioCrossRefID      IOCrossRefID,
  ioRegisterReqID   IORegisterReqID      OPTIONAL,
  extensions        CSTACommonArguments  OPTIONAL}

SuspendDataPathResult ::= CHOICE
{
  extensions        CSTACommonArguments,
  noData            NULL }

END -- of CSTA-suspend-data-path
```

## 23 Data Collection Services

### 23.1 Services

#### 23.1.1 Data Collected

```
CSTA-data-collected
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-collected( 343) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
ConnectionInformation FROM CSTA-media-services
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) media-services( 136) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

dataCollected OPERATION ::=
{
  ARGUMENT    DataCollectedArgument
  RESULT      DataCollectedResult
  ERRORS      {universalFailure}
  CODE        local: 343
}

DataCollectedArgument ::= SEQUENCE
{
  dcollCrossRefID      DcollCrossRefID,
  digitsData           [0] IMPLICIT DigitsData           OPTIONAL,
  telTonesData         [1] IMPLICIT TelTonesData          OPTIONAL,
  connectionInformation [2] IMPLICIT ConnectionInformation OPTIONAL,
  dcollCause           DcollCause                         OPTIONAL,
  extensions           CSTACommonArguments                OPTIONAL}

DataCollectedResult ::= CHOICE
{
  extensions CSTACommonArguments,
  noData      NULL}

DigitsData ::= SEQUENCE
{
  digitsDetected      IA5String (SIZE(0..64)),
  digitsDuration      [0] IMPLICIT SEQUENCE OF INTEGER  OPTIONAL,
  digitsPauseDuration [1] IMPLICIT SEQUENCE OF INTEGER  OPTIONAL}

TelTonesData ::= SEQUENCE
{
  toneDetected      ToneDetected,
  toneFrequency      [0] IMPLICIT INTEGER              OPTIONAL,
  toneDuration       [1] IMPLICIT INTEGER              OPTIONAL,
  tonePauseDuration [2] IMPLICIT INTEGER              OPTIONAL}

ToneDetected ::= ENUMERATED
{
  beep           ( 0),
  billing        ( 1),
  busy           ( 2),
  carrier        ( 3),
  confirmation   ( 4),
  dial           ( 5),
  faxCNG         ( 6),
  hold           ( 7),
  howler         ( 8),
```

```
intrusion          ( 9),
modemCNG           (10),
park               (11),
recordWarning      (12),
reorder            (13),
ringback           (14),
silence            (15),
sitVC              (16),
sitIC              (17),
sitRO              (18),
sitNC              (19),
other              (20)}

DcollCause ::= ENUMERATED
{
    flushCharReceived    (0),
    charCountReached     (1),
    timeout               (2),
    sfTerminated          (3)}

END -- of CSTA-data-collected
```

### 23.1.2 Data Collection Resumed

```
CSTA-data-collection-resumed
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-collection-resumed( 344) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

dataCollectionResumed OPERATION ::=
{
  ARGUMENT    DataCollectionResumedArgument
  RESULT      DataCollectionResumedResult
  ERRORS      {universalFailure}
  CODE        local: 344
}

DataCollectionResumedArgument ::= SEQUENCE
{
  dcollCrossRefID      DcollCrossRefID,
  extensions            CSTACCommonArguments    OPTIONAL}

DataCollectionResumedResult ::= CHOICE
{
  extensions  CSTACCommonArguments,
  noData      NULL}

END -- of CSTA-data-collection-resumed
```

### 23.1.3 Data Collection Suspended

```
CSTA-data-collection-suspended
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) data-collection-suspended( 345) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

dataCollectionSuspended OPERATION ::=
{
  ARGUMENT    DataCollectionSuspendedArgument
  RESULT      DataCollectionSuspendedResult
  ERRORS      {universalFailure}
  CODE        local: 345
}

DataCollectionSuspendedArgument ::= SEQUENCE
{
  dcollCrossRefID      DcollCrossRefID,
  extensions            CSTACommonArguments    OPTIONAL}

DataCollectionSuspendedResult ::= CHOICE
{
  extensions    CSTACommonArguments,
  noData        NULL}

END -- of CSTA-data-collection-suspended
```



### 23.1.4 Resume Data Collection

```
CSTA-resume-data-collection
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) resume-data-collection( 346) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

resumeDataCollection OPERATION ::=
{
  ARGUMENT    ResumeDataCollectionArgument
  RESULT      ResumeDataCollectionResult
  ERRORS      {universalFailure}
  CODE        local: 346
}

ResumeDataCollectionArgument ::= SEQUENCE
{
  dcollCrossRefID    DcollCrossRefID,
  extensions          CSTACCommonArguments    OPTIONAL}

ResumeDataCollectionResult ::= CHOICE
{
  extensions    CSTACCommonArguments,
  noData        NULL}

END -- of CSTA-resume-data-collection
```

### 23.1.5 Start Data Collection

```
CSTA-start-data-collection
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) start-data-collection( 347) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
DeviceID FROM CSTA-device-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-identifiers( 123) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

startDataCollection OPERATION ::=
{
  ARGUMENT    StartDataCollectionArgument
  RESULT      StartDataCollectionResult
  ERRORS      {universalFailure}
  CODE        local: 347
}

StartDataCollectionArgument ::= SEQUENCE
{
  object          CallObject,
  dataCollType    DataCollType          OPTIONAL,
  digitsReportingCriteria DigitsReportingCriteria OPTIONAL,
  extensions      CSTACommonArguments    OPTIONAL}

StartDataCollectionResult ::= SEQUENCE
{
  dcollCrossRefID DcollCrossRefID,
  extensions      CSTACommonArguments    OPTIONAL}

CallObject ::= CHOICE
{
  device          DeviceID,
  call            ConnectionID}

DataCollType ::= ENUMERATED
{
  digits          (0),
  telTones        (1)}

DigitsReportingCriteria ::= SEQUENCE
{
  numChars        [0] IMPLICIT INTEGER    OPTIONAL,
  flushChar        IA5String (SIZE(1..1)) OPTIONAL,
  timeout          [1] IMPLICIT INTEGER    OPTIONAL}

END -- of CSTA-start-data-collection
```

### 23.1.6 Stop Data Collection

```
CSTA-stop-data-collection
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) stop-data-collection( 348) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) data-collection( 138) };

stopDataCollection OPERATION ::=
{
    ARGUMENT    StopDataCollectionArgument
    RESULT      StopDataCollectionResult
    ERRORS      {universalFailure}
    CODE        local: 348
}

StopDataCollectionArgument ::= SEQUENCE
{
    dcollCrossRefID    DcollCrossRefID,
    extensions          CSTACommonArguments    OPTIONAL}

StopDataCollectionResult ::= CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

END -- of CSTA-stop-data-collection
```

### 23.1.7 Suspend Data Collection

```
CSTA-suspend-data-collection
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) suspend-data-collection( 349) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACCommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
DcollCrossRefID FROM CSTA-data-collection
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) data-collection( 138) };

suspendDataCollection OPERATION ::=
{
  ARGUMENT    SuspendDataCollectionArgument
  RESULT      SuspendDataCollectionResult
  ERRORS      {universalFailure}
  CODE        local: 349
}

SuspendDataCollectionArgument ::= SEQUENCE
{
  dcollCrossRefID      DcollCrossRefID,
  extensions            CSTACCommonArguments    OPTIONAL}

SuspendDataCollectionResult ::= CHOICE
{
  extensions    CSTACCommonArguments,
  noData        NULL}

END -- of CSTA-suspend-data-collection
```

## 24 Voice unit services and events

### 24.1 Services

#### 24.1.1 Concatenate message

```
CSTA-concatenate-message
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) concatenate-message( 500) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

concatenateMessage OPERATION ::=
{
    ARGUMENT    ConcatenateMessageArgument
    RESULT      ConcatenateMessageResult
    ERRORS      {universalFailure}
    CODE        local: 500
}

ConcatenateMessageArgument ::= SEQUENCE
{
    messagesToConcatenate  SEQUENCE OF MessageID,
    extensions             CSTACommonArguments          OPTIONAL}

ConcatenateMessageResult ::= SEQUENCE
{
    concatenatedMessage    MessageID,
    extensions             CSTACommonArguments          OPTIONAL}

END -- of CSTA-concatenate-message
```

### 24.1.2 Delete message

```
CSTA-delete-message
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) delete-message( 501) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

deleteMessageOPERATION ::=
{
    ARGUMENT    DeleteMessageArgument
    RESULT      DeleteMessageResult
    ERRORS      {universalFailure}
    CODE        local: 501
}

DeleteMessageArgument ::= SEQUENCE
{
    messageToBeDeleted    MessageID,
    extensions             CSTACommonArguments    OPTIONAL}

DeleteMessageResult ::=CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

END -- of CSTA-delete-message
```

### 24.1.3 Play message

```
CSTA-play-message
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) play-message( 502) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID, TerminatingConditions FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

playMessage      OPERATION ::=
{
  ARGUMENT      PlayMessageArgument
  RESULT        PlayMessageResult
  ERRORS        {universalFailure}
  CODE          local: 502
}

PlayMessageArgument ::= SEQUENCE
{
  messageToBePlayed      MessageID,
  overConnection          ConnectionID,
  duration                INTEGER OPTIONAL,
  termination             TerminatingConditions OPTIONAL,
  extensions              CSTACCommonArguments OPTIONAL}

PlayMessageResult ::= CHOICE
{
  extensions CSTACCommonArguments,
  noData     NULL}

END -- of CSTA-play-message
```

#### 24.1.4 Query voice attribute

```
CSTA-query-voice-attribute
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) query-voice-attribute( 503) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
AttributeInfo, MessageID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

queryVoiceAttributeOPERATION ::=
{
  ARGUMENT    QueryVoiceAttributeArgument
  RESULT      QueryVoiceAttributeResult
  ERRORS      {universalFailure}
  CODE        local: 503
}

QueryVoiceAttributeArgument ::= SEQUENCE
{
  messageToQuery      MessageID,
  attributeToQuery     AttributeToQuery,
  connection           ConnectionID          OPTIONAL,
  extensions           CSTACommonArguments   OPTIONAL}

QueryVoiceAttributeResult ::= SEQUENCE
{
  attribute            AttributeInfo,
  extensions           CSTACommonArguments   OPTIONAL}

AttributeToQuery ::= ENUMERATED
{
  encodingAlgorithm    (0),
  samplingRate         (1),
  duration             (2),
  fileName             (3),
  currentPosition      (4),
  currentSpeed         (5),
  currentVolume        (6),
  currentLevel         (7),
  currentState         (8)      }

END -- of CSTA-query-voice-attribute
```



### 24.1.5 Record message

```
CSTA-record-message
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) record-message( 511) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID, EncodingAlgorithm, TerminatingConditions
    FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

recordMessageOPERATION ::=
{
    ARGUMENT      RecordMessageArgument
    RESULT        RecordMessageResult
    ERRORS        {universalFailure}
    CODE          local: 511
}

RecordMessageArgument ::= SEQUENCE
{
    callToBeRecorded      ConnectionID,
    samplingRate           [0] IMPLICIT INTEGER    OPTIONAL,
    encodingAlgorithm      EncodingAlgorithm        OPTIONAL,
    maxDuration            [1] IMPLICIT INTEGER    OPTIONAL,
    termination            TerminatingConditions  OPTIONAL,
    extensions             CSTACommonArguments      OPTIONAL}

RecordMessageResult ::= SEQUENCE
{
    resultingMessage      MessageID,
    extensions            CSTACommonArguments      OPTIONAL}

END -- of CSTA-record-message
```

## 24.1.6 Reposition

```
CSTA-reposition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) reposition( 504) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

reposition      OPERATION ::=
{
  ARGUMENT      RepositionArgument
  RESULT        RepositionResult
  ERRORS        {universalFailure}
  CODE          local: 504
}

RepositionArgument ::= SEQUENCE
{
  connection      ConnectionID,
  periodOfReposition  Period,
  messageToReposition  MessageID
  extensions      CSTACommonArguments  OPTIONAL
}

RepositionResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL
}

Period ::= CHOICE
{
  absolutePosition  ENUMERATED
    {
      startOfMessage(0),
      endOfMessage(1)},
  relativePosition  INTEGER
}

END -- of CSTA-reposition
```

## 24.1.7 Resume

```
CSTA-resume
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) resume( 505) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

resume
{
    ARGUMENT    ResumeArgument
    RESULT      ResumeResult
    ERRORS      {universalFailure}
    CODE        local: 505
}

ResumeArgument ::= SEQUENCE
{
    connection          ConnectionID,
    messageToResume     MessageID          OPTIONAL,
    duration            INTEGER            OPTIONAL,
    extensions          CSTACCommonArguments  OPTIONAL}

ResumeResult ::= CHOICE
{
    extensions  CSTACCommonArguments,
    noData      NULL}

END -- of CSTA-resume
```

## 24.1.8 Review

```
CSTA-review
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) review( 506) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

review          OPERATION ::=
{
  ARGUMENT      ReviewArgument
  RESULT        ReviewResult
  ERRORS        {universalFailure}
  CODE          local: 506
}

ReviewArgument ::= SEQUENCE
{
  connection          ConnectionID,
  periodToReview      PeriodToReview,
  messageToReview     MessageID          OPTIONAL,
  extensions          CSTACommonArguments OPTIONAL}

ReviewResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

PeriodToReview ::= CHOICE
{
  startOfMessage  NULL,
  lengthOfReview  INTEGER}

END -- of CSTA-review
```

### 24.1.9 Set voice attribute

```
CSTA-set-voice-attribute
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) set-voice-attribute( 507) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
Volume FROM CSTA-physical-device-feature
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) physical-device-feature( 137) };

setVoiceAttributeOPERATION ::=
{
    ARGUMENT      SetVoiceAttributeArgument
    RESULT        SetVoiceAttributeResult
    ERRORS        {universalFailure}
    CODE          local: 507
}

SetVoiceAttributeArgument ::= SEQUENCE
{
    connection          ConnectionID,
    attributeToSet       AttributeToSet,
    message              MessageID          OPTIONAL,
    extensions           CSTACommonArguments OPTIONAL}

SetVoiceAttributeResult ::= CHOICE
{
    extensions CSTACommonArguments,
    noData     NULL}

AttributeToSet ::= CHOICE
{
    currentSpeed      [0] IMPLICIT INTEGER,
    currentVolume     [1] Volume,
    currentGain        [2] IMPLICIT INTEGER (0 .. 100)}

END -- of CSTA-set-voice-attribute
```

### 24.1.10 Stop

```
CSTA-stop
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) stop( 508) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

stop
{
  ARGUMENT      StopArgument
  RESULT        StopResult
  ERRORS        {universalFailure}
  CODE          local: 508
}

StopArgument ::= SEQUENCE
{
  connection      ConnectionID,
  messageToBeStopped MessageID
  extensions      CSTACommonArguments OPTIONAL
}

StopResult ::= CHOICE
{
  extensions CSTACommonArguments,
  noData      NULL
}

END -- of CSTA-stop
```

### 24.1.11 Suspend

```
CSTA-suspend
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) suspend( 509) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
ConnectionID FROM CSTA-call-connection-identifiers
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) };

suspend OPERATION ::=
{
  ARGUMENT    SuspendArgument
  RESULT      SuspendResult
  ERRORS      {universalFailure}
  CODE        local: 509
}

SuspendArgument ::= SEQUENCE
{
  connection  ConnectionID,
  message     MessageID          OPTIONAL,
  extensions  CSTACommonArguments OPTIONAL}

SuspendResult ::= CHOICE
{
  extensions  CSTACommonArguments,
  noData      NULL}

END -- of CSTA-suspend
```

#### 24.1.12 Synthesize message

```
CSTA-synthesize-message
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) synthesize-message( 510) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
{joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) error-definition( 120) }
ControlData, MessageID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) };

synthesizeMessage OPERATION ::=
{
  ARGUMENT    SynthesizeMessageArgument
  RESULT      SynthesizeMessageResult
  ERRORS      {universalFailure}
  CODE        local: 510
}

SynthesizeMessageArgument ::= SEQUENCE
{
  textToBeSynthesized    IA5String,
  control                 ControlData          OPTIONAL,
  extensions              CSTACommonArguments  OPTIONAL}

SynthesizeMessageResult ::= SEQUENCE
{
  synthesizedMessage      MessageID,
  extensions              CSTACommonArguments  OPTIONAL}

END -- of CSTA-synthesize-message
```



## 24.2 Events

### 24.2.1 Play

```
CSTA-play-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) play( 75) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) };

PlayEvent ::=SEQUENCE
{
  connection          ConnectionID,
  message             MessageID,
  length              [0] IMPLICIT INTEGER OPTIONAL,
  currentPosition     [1] IMPLICIT INTEGER OPTIONAL,
  speed               [2] IMPLICIT INTEGER OPTIONAL,
  cause               EventCause OPTIONAL,
  servicesPermitted   ServicesPermitted OPTIONAL,
  extensions          CSTACommonArguments OPTIONAL}

END -- of CSTA-play-event
```

## 24.2.2 Record

```
CSTA-record-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) record( 76) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) };

RecordEvent ::= SEQUENCE
{
  connection          ConnectionID,
  message             MessageID,
  length              [0] IMPLICIT INTEGER    OPTIONAL,
  currentPosition     [1] IMPLICIT INTEGER    OPTIONAL,
  cause               EventCause              OPTIONAL,
  servicesPermitted   ServicesPermitted        OPTIONAL,
  extensions          CSTACommonArguments      OPTIONAL}

END -- of CSTA-record-event
```

### 24.2.3 Review

```
CSTA-review-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) review( 77) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) };

ReviewEvent ::= SEQUENCE
{
    connection          ConnectionID,
    message              MessageID,
    length               [0] IMPLICIT INTEGER    OPTIONAL,
    currentPosition     [1] IMPLICIT INTEGER    OPTIONAL,
    cause                EventCause              OPTIONAL,
    servicesPermitted    ServicesPermitted        OPTIONAL,
    extensions           CSTACCommonArguments    OPTIONAL}

END -- of CSTA-review-event
```

## 24.2.4 Stop

```
CSTA-stop-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) stop( 78) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) };

StopEvent ::= SEQUENCE
{
  connection          ConnectionID,
  message             MessageID,
  length              [0] IMPLICIT INTEGER    OPTIONAL,
  currentPosition     [1] IMPLICIT INTEGER    OPTIONAL,
  cause               EventCause              OPTIONAL,
  servicesPermitted   ServicesPermitted        OPTIONAL,
  extensions          CSTACommonArguments     OPTIONAL}

END -- of CSTA-stop-event
```

### 24.2.5 Suspend play

```
CSTA-suspend-play-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) suspend-play( 79) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) };

SuspendPlayEvent ::= SEQUENCE
{
    connection          ConnectionID,
    message              MessageID,
    length               [0] IMPLICIT INTEGER    OPTIONAL,
    currentPosition     [1] IMPLICIT INTEGER    OPTIONAL,
    cause                EventCause              OPTIONAL,
    servicesPermitted    ServicesPermitted        OPTIONAL,
    extensions           CSTACCommonArguments     OPTIONAL}

END -- of CSTA-suspend-play-event
```

## 24.2.6 Suspend record

```
CSTA-suspend-record-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) suspend-record( 80) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) device-feature-types( 127) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-control( 130) };

SuspendRecordEvent ::= SEQUENCE
{
    connection          ConnectionID,
    message              MessageID,
    length               [0] IMPLICIT INTEGER    OPTIONAL,
    currentPosition      [1] IMPLICIT INTEGER    OPTIONAL,
    cause                EventCause              OPTIONAL,
    servicesPermitted     ServicesPermitted       OPTIONAL,
    extensions            CSTACCommonArguments    OPTIONAL}

END -- of CSTA-suspend-record-event
```

## 24.2.7 Voice attribute changed

```
CSTA-voice-attributes-change-event
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) voice-attributes-change-event( 74) }

DEFINITIONS ::=
BEGIN
IMPORTS
-- Data Types --
EventCause FROM CSTA-event-causes
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) event-causes( 121) }
ConnectionID FROM CSTA-call-connection-identifiers
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-connection-identifiers( 124) }
MessageID FROM CSTA-device-feature-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) device-feature-types( 127) }
CSTACommonArguments FROM CSTA-extension-types
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) extension-types( 129) }
ServicesPermitted FROM CSTA-call-control
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) call-control( 130) }
Volume FROM CSTA-physical-device-feature
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) physical-device-feature( 137) };

VoiceAttributesChangeEvent ::= SEQUENCE
{
  connection          ConnectionID,
  message             MessageID,
  playVolume          [0] Volume OPTIONAL,
  recordingGain       [1] IMPLICIT INTEGER (0 .. 100) OPTIONAL,
  speed               [2] IMPLICIT INTEGER OPTIONAL,
  currentPosition     [3] IMPLICIT INTEGER OPTIONAL,
  cause               EventCause OPTIONAL,
  servicesPermitted   ServicesPermitted OPTIONAL,
  extensions           CSTACommonArguments OPTIONAL
}

END -- of CSTA-voice-attributes-change-event
```

## 25 Call detail record services

### 25.1 Services

#### 25.1.1 Call detail records notification

```
CSTA-call-detail-records-notification
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-records-notification( 360) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CDRCrossRefID, CDRReason FROM CSTA-call-detail-record
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-record( 132) };

CDRNotification OPERATION ::=
{
    ARGUMENT      CDRNotificationArgument
    RESULT        CDRNotificationResult
    ERRORS        {universalFailure}
    CODE          local: 360
}

CDRNotificationArgument ::= SEQUENCE
{
    cdrCrossRefID  CDRCrossRefID,
    cdrReason      CDRReason          OPTIONAL,
    extensions     CSTACommonArguments OPTIONAL}

CDRNotificationResult ::= CHOICE
{
    extensions     CSTACommonArguments,
    noData         NULL}

END -- of CSTA-call-detail-records-notification
```



## 25.1.2 Call detail records report

```
CSTA-call-detail-records-report
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-records-report( 361) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACCommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CDRCrossRefID, CDRInfo FROM CSTA-call-detail-record
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-record( 132) };

CDRReport      OPERATION ::=
{
    ARGUMENT      CDRReportArgument
    RESULT        CDRReportResult
    ERRORS        {universalFailure}
    CODE          local: 361
}

CDRReportArgument ::= SEQUENCE
{
    cdrCrossRefID          CDRCrossRefID,
    numberOfRecordsSent    INTEGER (1..128),
    cdrInfo                CDRInfo,
    lastStoredCDRReportSent    BOOLEAN          OPTIONAL,
    extensions              CSTACCommonArguments    OPTIONAL}

CDRReportResult ::= CHOICE
{
    extensions      CSTACCommonArguments,
    noData          NULL}

END -- of CSTA-call-detail-records-report
```

### 25.1.3 Send stored call detail records

```
CSTA-send-stored-call-detail-records
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) send-stored-call-detail-records( 362) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CDRCrossRefID, CDRTIMEPERIOD FROM CSTA-call-detail-record
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-record( 132) };

sendStoredCDR    OPERATION ::=
{
    ARGUMENT      SendStoredCDRArgument
    RESULT        SendStoredCDRResult
    ERRORS        {universalFailure}
    CODE          local: 362
}

SendStoredCDRArgument ::= SEQUENCE
{
    cdrCrossRefID  CDRCrossRefID,
    timePeriod     CDRTIMEPERIOD          OPTIONAL,
    extensions     CSTACommonArguments     OPTIONAL}

SendStoredCDRResult ::= CHOICE
{
    extensions     CSTACommonArguments,
    noData         NULL}

END -- of CSTA-send-stored-call-detail-records
```

#### 25.1.4 Start call detail records transmission

```
CSTA-start-call-detail-records-transmission
{ iso( 1) identified-organization( 3) icd-ecma( 12)
  standard( 0) csta3( 285) start-call-detail-records-transmission( 363) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
CDRCrossRefID, CDRTransferMode FROM CSTA-call-detail-record
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) call-detail-record( 132) };

startCDRTransmission      OPERATION ::=
{
  ARGUMENT      StartCDRTransmissionArgument
  RESULT        StartCDRTransmissionResult
  ERRORS        {universalFailure}
  CODE          local: 363
}

StartCDRTransmissionArgument ::= SEQUENCE
{
  transferMode    CDRTransferMode,
  extensions      CSTACommonArguments      OPTIONAL}

StartCDRTransmissionResult ::= SEQUENCE
{
  cdrCrossRefID   CDRCrossRefID,
  extensions      CSTACommonArguments      OPTIONAL}

END -- of CSTA-start-call-detail-records-transmission
```

### 25.1.5 Stop call detail records transmission

```
CSTA-stop-call-detail-records
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) stop-call-detail-records( 364) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
CDRCrossRefID, CDRTermReason FROM CSTA-call-detail-record
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) call-detail-record( 132) };

stopCDRTransmission      OPERATION ::=
{
    ARGUMENT      StopCDRTransmissionArgument
    RESULT        StopCDRTransmissionResult
    ERRORS        {universalFailure}
    CODE          local: 364
}

StopCDRTransmissionArgument ::= SEQUENCE
{
    cdrCrossRefID   CDRCrossRefID,
    cdrTermReason   CDRTermReason          OPTIONAL,
    extensions      CSTACommonArguments    OPTIONAL}

StopCDRTransmissionResult ::= CHOICE
{
    extensions      CSTACommonArguments,
    noData          NULL}

END -- of CSTA-stop-call-detail-records
```

## 26 Vendor specific extensions services and events

### 26.1 Registration services

#### 26.1.1 Escape register

```
CSTA-escape-register
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-register( 365) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
EscapeRegisterID FROM CSTA-escape-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-types( 135) };

escapeRegister OPERATION ::=
{
    ARGUMENT    EscapeRegisterArgument
    RESULT      EscapeRegisterResult
    ERRORS      {universalFailure}
    CODE        local: 365
}

EscapeRegisterArgument ::= CHOICE
{
    extensions    CSTACommonArguments,
    noData        NULL}

EscapeRegisterResult ::= SEQUENCE
{
    escapeRegisterID    EscapeRegisterID,
    extensions          CSTACommonArguments    OPTIONAL}

END -- of CSTA-escape-register
```

## 26.1.2 Escape register abort

```
CSTA-escape-register-abort
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) escape-register-abort( 366) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
  {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) extension-types( 129) }
EscapeRegisterID FROM CSTA-escape-types
  { iso( 1) identified-organization( 3) icd-ecma( 12)
    standard( 0) csta3( 285) escape-types( 135) };

escapeRegisterAbort OPERATION ::=
{
  ARGUMENT          EscapeRegisterAbortArgument
  ERRORS            {universalFailure}
  ALWAYS RESPONDS   FALSE
  CODE              local: 366
}

EscapeRegisterAbortArgument ::= SEQUENCE
{
  escapeRegisterID   EscapeRegisterID,
  extensions         CSTACommonArguments    OPTIONAL}

END -- of CSTA-escape-register-abort
```

### 26.1.3 Escape register cancel

```
CSTA-escape-register-cancel
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-register-cancel( 367) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
EscapeRegisterID FROM CSTA-escape-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-types( 135) };

escapeRegisterCancel OPERATION ::=
{
    ARGUMENT    EscapeRegisterCancelArgument
    RESULT      EscapeRegisterCancelResult
    ERRORS      {universalFailure}
    CODE        local: 367
}

EscapeRegisterCancelArgument ::= SEQUENCE
{
    escapeRegisterID      EscapeRegisterID,
    extensions            CSTACommonArguments    OPTIONAL}

EscapeRegisterCancelResult ::= CHOICE
{
    extensions            CSTACommonArguments,
    noData                NULL}

END -- of CSTA-escape-register-cancel
```

## 26.2 Services

### 26.2.1 Escape

```
CSTA-escape-service
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-service( 91) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTASecurityData FROM CSTA-security
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) security( 128) }
CSTACCommonArguments, CSTAPrivateData FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) }
EscapeRegisterID FROM CSTA-escape-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) escape-types( 135) };

escape OPERATION ::=
{
    ARGUMENT      EscapeArgument
    RESULT        EscapeResult
    ERRORS        {universalFailure}
    CODE          local: 51
}

EscapeArgument ::= SEQUENCE
{
    escapeRegisterID      EscapeRegisterID      OPTIONAL,
    security              CSTASecurityData      OPTIONAL,
    privateData           CSTAPrivateData
}

EscapeResult ::= CHOICE
{
    extensions          CSTACCommonArguments,
    noData              NULL}

END -- of CSTA-escape-service
```



## 26.2.2 Private data version selection

```
CSTA-private-data-version-selection
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) private-data-version-selection( 368) }

DEFINITIONS ::=
BEGIN
IMPORTS
OPERATION, ERROR FROM Remote-Operations-Information-Objects
    {joint-iso-itu-t remote-operations(4) informationObjects(5) version1(0)}
-- Data Types --
universalFailure FROM CSTA-error-definition
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) error-definition( 120) }
CSTACommonArguments FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

privateDataVersionSelection OPERATION ::=
{
    ARGUMENT    PrivateDataVersionSelectionArgument
    RESULT      PrivateDataVersionSelectionResult
    ERRORS      {universalFailure}
    CODE        local: 368
}

PrivateDataVersionSelectionArgument ::= INTEGER

PrivateDataVersionSelectionResult ::= CHOICE
{
    extensions      CSTACommonArguments,
    noData          NULL}

END -- of CSTA-private-data-version-selection
```

## 26.3 Events

### 26.3.1 Private event

```
CSTA-private-event
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) private-event( 71) }

DEFINITIONS ::=
BEGIN

IMPORTS
-- Data Types --
CSTASecurityData FROM CSTA-security
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) security( 128) }
CSTAPrivateData FROM CSTA-extension-types
    { iso( 1) identified-organization( 3) icd-ecma( 12)
      standard( 0) csta3( 285) extension-types( 129) };

PrivateEvent ::= SEQUENCE
{
    security          CSTASecurityData          OPTIONAL,
    privateData       CSTAPrivateData           }

END -- of CSTA-private-event
```

## **Annex A**

(normative)

### **Protocol Implementation Conformance Statement (PICS) Proforma**

#### **A.1 Introduction**

The Protocol Implementation Conformance Statement (PICS) is a statement of which capabilities and options of the protocol have been implemented. The PICS can have a number of uses, including use:

- by the protocol implementor, as a check-list to reduce the risk of failure to conform to the standard through oversight;
- by the supplier and acquirer (or potential acquirer) of the implementation, as a detailed indication of the capabilities of the implementation, stated relative to the common basis for understanding provided by the standard PICS proforma;
- by the user (or potential user) of the implementation, as a basis for initially checking the possibility of interworking with another implementation (note that, while interworking cannot be guaranteed, failure to interwork can often be predicted from incompatible PICS);
- by a protocol tester, as the basis for selecting appropriate tests against which to assess the claim for conformance of the implementation.

#### **A.2 Conformance**

The supplier of a protocol implementation which is claimed to conform to this Standard shall complete a copy of the Protocol Implementation Conformance Statement (PICS) proforma in A.5, “PICS proforma”.

#### **A.3 Instructions for completing the PICS proforma**

The first part of the PICS proforma, the Implementation Identification (A.4, “Implementation identification”, on page 308), is to be completed as indicated with the information necessary to identify fully both the supplier and the implementation.

The main part of the PICS proforma, A.5, “PICS proforma”, is a fixed format questionnaire divided into subclauses each containing a group of individual items. These items represent options specified in ECMA-269 (mandatory items are not represented). Answers to the questionnaire items are to be provided in the appropriate columns by marking an answer to indicate a restricted choice (Yes or No), and optionally clarifying this response with a comment.

Where a service or event is not supported, as indicated by entering No for the first entry in a table, any parameters or dependent service components in the rest of that table are not applicable, it is then not necessary to complete items in any subsidiary entries in the table.

Note that ECMA-269 should be used as a reference when completing the PICS proforma.

## A.4 Implementation identification

<b>Supplier</b>	
<b>Protocol Version</b>	Phase III, First Edition
<b>Date of Statement</b>	
<b>Contact point for queries about the PICS</b>	
<b>Implementation Name(s) and Version(s)</b>	
<b>Other information necessary for full identification - e.g. Name(s) and Version(s) for machines and/or operating systems; system name(s)</b>	

The first five items are required for all implementations; other information may be completed as appropriate in meeting the requirement for full identification.

The terms Name and Version should be interpreted appropriately to correspond with a supplier's terminology (e.g. Type, Series, Model).

## A.5 PICS proforma

### A.5.1 CSTA Profiles

CSTA Profiles group together services and events, where each profile specifies a set of services and events that are supported by the implementation. Switching Function implementors shall indicate support for one or more profiles in the table below. Specifying support for a profile shall be accompanied by specifying support for the services and events encompassed by the profile, as well as any other services and events that the implementation supports.

Refer to ECMA-269 for a description of the CSTA Services and Events that must be supported for a specific CSTA profile.

Description: Profile(s) Supported	Supported?		Comments
	Yes	No	
Basic Telephony Profile			
Routeing Profile			

## A.5.2 Capability Exchange Services

### A.5.2.1 Get Logical Device Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Logical Device Information</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
groupDeviceAttributes			
namedDeviceTypes			
shortFormDeviceID			
agentLogOnModels			
appearanceList			
otherPhysicalDeviceList			
miscMonitorCaps			
associatedGroupList			
maxCallbacks			
maxAutoAnswerRings			
maxActiveCalls			
maxHeldCalls			
maxFwdSettings			
maxDevicesInConf			
transAndConfSetup			
deviceOnDeviceMonitorFilter			
deviceOnConnectionMonitorFilter			
callOnDeviceMonitorFilter			
callOnConnectionMonitorFilter			
mediaClassSupport			
mediaServiceCapsList			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
connectionRateList			
delayToleranceList			
numberOfChannels			
maxChannelBind			
routeingServList			
logDevServList			
logDevEvtsList			
deviceMaintEvtsList			
security			
privateData			

#### A.5.2.2 Get Physical Device Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Physical Device Information</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
groupDeviceAttributes			
namedDeviceTypes			
otherLogicalDeviceList			
deviceModelName			
deviceOnDeviceMonitorFilter			
deviceOnConnectionMonitorFilter			
callOnDeviceMonitorFilter			
callOnConnectionMonitorFilter			
maxDisplays			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
maxButtons			
maxLamps			
maxRingPatterns			
physDevServList			
physDevEvtsList			
security			
privateData			

#### A.5.2.3 Get Switching Function Capabilities

This service shall be supported by a switching function.

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Switching Function Capabilities</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
callCharacteristicsSupported			
mediaClassSupport			
numberOfChannels			
maxChannelBind			
miscMediaCallCharacteristics			
connectionRateList			
delayToleranceRateList			
pauseTime			
currentTime			
messageSeqNumbers			
timeStampMode			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
securityMode			
securityFormat			
privateDataFormat			
transAndConfSetup			
deviceOnDeviceMonitorFilter			
deviceOnConnectionMonitorFilter			
callOnDeviceMonitorFilter			
callOnConnectionMonitorFilter			
miscMonitorCaps			
correlatorDataSupported			
dynamicFeatureSupported			
callLinkageOptionsSupported			
acdModels			
agentLogonModels			
agentStateModels			
routeingServList			
logDevServList			
logDevEvtsList			
physDevServList			
physDevEvtsList			
deviceMaintEvtsList			
statusReportingServList			
capExchangeServList			
cdrServList			
vendorSpecificServList			
vendorSpecificEvtsList			
privateDataVersionList			
systemStatusTimer			



Description: Service, optional parameters	Supported?		Comments
	Yes	No	
simpleThreshold			
filterThreshold			
mediaServiceCapsList			
security			
privateData			

#### A.5.2.4 Get Switching Function Devices

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Switching Function Devices</b>			
<b>Service Request optional parameters</b>			
requestedDeviceID			
requestedDeviceCategory			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.2.5 Switching Function Devices

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Switching Function Devices</b>			
<b>Service Request optional parameters</b>			
segmentID			
security			
privateData			

### A.5.3 System Services

#### A.5.3.1 Change System Status Filter

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Change System Status Filter			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.3.2 System Register

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
System Register			
Service Request optional parameters			
requestedStatusFilter			
security			
privateData			
Service Response optional parameters			
actualStatusFilter			
security			
privateData			

### A.5.3.3 System Register Abort

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
System Register Abort			
Service Request optional parameters			
security			
privateData			

### A.5.3.4 System Register Cancel

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
System Register Cancel			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

### A.5.3.5 Request System Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Request System Status			
Service Request optional parameters			
sysStatRegisterID			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.3.6 System Status

The System Status service shall be supported as part of the Application Association Initialisation as specified in Clause 7 of ECMA-269.

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>System Status</b>			
<b>Service Request optional parameters</b>			
sysStatRegisterID			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.3.7 Switching Function Capabilities Changed

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Switching Function Capabilities Changed</b>			
<b>Service Request optional parameters</b>			
sysStatRegisterID			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.3.8 Switching Function Devices Changed

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Switching Function Devices Changed			
Service Request optional parameters			
sysStatRegisterID			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.4 Monitoring Services

##### A.5.4.1 Change Monitor Filter

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Change Monitor Filter			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
actualFilterList			
security			
privateData			

#### A.5.4.2 Monitor Start

This service must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Monitor Start</b>			
<b>Service Request optional parameters</b>			
requestedMonitorFilter			
monitorType			
requestedMonitorMediaClass			
security			
privateData			
<b>Service Response optional parameters</b>			
actualMonitorFilter			
actualMonitorMediaClass			
monitorExistingCalls			
security			
privateData			

#### A.5.4.3 Monitor Stop

This service must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Monitor Stop</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

## A.5.5 Snapshot Services

### A.5.5.1 Snapshot Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Snapshot Call</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
serviceCrossRefID			
snapshotData			
mediaCallCharacteristics			
callCharacteristics			
callingDevice			
calledDevice			
associatedCallingDevice			
associatedCalledDevice			
correlatorData			
security			
privateData			

### A.5.5.2 Snapshot Device

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Snapshot Device</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
serviceCrossRefID			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
snapshotData			
security			
privateData			

**A.5.5.3 Snapshot CallData**

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Snapshot CallData</b>			
<b>Service Request optional parameters</b>			
segmentID			
security			
privateData			

**A.5.5.4 Snapshot DeviceData**

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Snapshot DeviceData</b>			
<b>Service Request optional parameters</b>			
segmentID			
security			
privateData			



## A.5.6 Call Control Services

### A.5.6.1 Accept Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Accept Call</b>			
<b>Service Request optional parameters</b>			
correlatorData			
userData			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

### A.5.6.2 Alternate Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Alternate Call</b>			
<b>Service Request optional parameters</b>			
connectionReservation			
consultOptions			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.6.3 Answer Call

This service must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Answer Call			
Service Request optional parameters			
correlatorData			
userData			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.6.4 Call Back Call-Related

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Call Back Call-Related			
Service Request optional parameters			
callCharateristics			
security			
privateData			
Service Response optional parameters			
targetDevice			
security			
privateData			

#### A.5.6.5 Call Back Message Call-Related

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Call Back Message Call-Related</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
targetDevice			
security			
privateData			

#### A.5.6.6 Camp On Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Camp On Call</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.6.7 Clear Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Clear Call</b>			
<b>Service Request optional parameters</b>			
userData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.6.8 Clear Connection

This service must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Clear Connection</b>			
Service Request optional parameters			
correlatorData			
userData			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.6.9 Conference Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Conference Call</b>			
Service Request optional parameters			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
connections			
conferenceCallInfo			
security			
privateData			

#### A.5.6.10 Consultation Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Consultation Call</b>			
<b>Service Request optional parameters</b>			
connectionReservation			
accountCode			
authCode			
correlatorData			
userData			
callCharacteristics			
mediaCallCharacteristics			
callingConnectionInfo			
consultOptions			
security			
privateData			
<b>Service Response optional parameters</b>			
mediaCallCharacteristics			
initiatedCallInfo			
security			
privateData			

#### A.5.6.11 Deflect Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Deflect Call</b>			
<b>Service Request optional parameters</b>			
correlatorData			
userData			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.6.12 Dial Digits

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Dial Digits</b>			
<b>Service Request optional parameters</b>			
correlatorData			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.6.13 Directed Pickup Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Directed Pickup Call</b>			
<b>Service Request optional parameters</b>			
correlatorData			
userData			
security			
privateData			
<b>Service Response optional parameters</b>			
pickedCall			
pickedCallInfo			
security			
privateData			

#### A.5.6.14 Group Pickup Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Group Pickup Call</b>			
<b>Service Request optional parameters</b>			
pickGroup			
correlatorData			
userData			
security			
privateData			
<b>Service Response optional parameters</b>			
pickedCall			
pickedCallInfo			
security			
privateData			

#### A.5.6.15 Hold Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Hold Call</b>			
<b>Service Request optional parameters</b>			
connectionReservation			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.6.16 Intrude Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Intrude Call</b>			
<b>Service Request optional parameters</b>			
participationType			
userData			
security			
privateData			
<b>Service Response optional parameters</b>			
conferencedCall			
conferencedCallInfo			
security			
privateData			



#### A.5.6.17 Join Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Join Call</b>			
<b>Service Request optional parameters</b>			
autoOriginate			
participationType			
accountCode			
authCode			
correlatorData			
userData			
security			
privateData			
<b>Service Response optional parameters</b>			
conferencedCallInfo			
security			
privateData			

#### A.5.6.18 Make Call

This service must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Make Call</b>			
<b>Service Request optional parameters</b>			
accountCode			
authCode			
autoOriginate			
correlatorData			
userData			
callCharacteristics			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
medaCallCharacteristics			
callingConnectionInfo			
security			
privateData			
<b>Service Response optional parameters</b>			
mediaCallCharacteristics			
initiatedCallInfo			
security			
privateData			

#### A.5.6.19 Make Predictive Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Make Predictive Call</b>			
<b>Service Request optional parameters</b>			
signallingDetection			
destinationDetection			
defaultAction			
accountCode			
authCode			
autoOriginate			
alertTime			
correlatorData			
callCharacteristics			
userData			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
initiatedCallInfo			
security			
privateData			

#### A.5.6.20 Park Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Park Call</b>			
<b>Service Request optional parameters</b>			
correlatorData			
security			
privateData			
<b>Service Response optional parameters</b>			
parkedTo			
security			
privateData			

#### A.5.6.21 Reconnect Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Reconnect Call</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.6.22 Retrieve Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Retrieve Call</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.6.23 Single Step Conference Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Single Step Conference Call</b>			
<b>Service Request optional parameters</b>			
participationType			
accountCode			
authCode			
correlatorData			
userData			
security			
privateData			
<b>Service Response optional parameters</b>			
conferencedCallInfo			
security			
privateData			

#### A.5.6.24 Single Step Transfer Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Single Step Transfer Call</b>			
<b>Service Request optional parameters</b>			
accountCode			
authCode			
correlatorData			
userData			
security			
privateData			
<b>Service Response optional parameters</b>			
connections			
transferredCallInfo			
security			
privateData			

#### A.5.6.25 Transfer Call

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Transfer Call</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
connections			
transferredCallInfo			
security			
privateData			

## A.5.7 Call Control Events

### A.5.7.1 Bridged

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Bridged</b>			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
bridgedConnectionInfo			
callLinkageData			
security			
privateData			

### A.5.7.2 Call Cleared

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Call Cleared</b>			
correlatorData			
userData			
mediaCallCharacteristics			
callCharacteristics			
callLinkageData			
security			
privateData			

#### A.5.7.3 Conferenced

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Conferenced</b>			
secondaryOldCall			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
security			
privateData			

#### A.5.7.4 Connection Cleared

This event must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Connection Cleared</b>			
localConnectionInfo			
correlatorData			
userData			
chargingInfo			
servicesPermitted			
mediaCallCharateristics			
callCharacteristics			
droppedConnectionInfo			
callLinkageData			
security			
privateData			

#### A.5.7.5 Delivered

This event must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Delivered</b>			
originatingNIDConnection			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
connectionInfo			
security			
privateData			

#### A.5.7.6 Digits Dialed

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Digits Dialed</b>			
localConnectionInfo			
correlatorData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			



Description: Event, optional parameters	Supported?		Comments
	Yes	No	
associatedCalledDevice			
diallingConnectionInfo			
callCharacteristics			
security			
privateData			

#### A.5.7.7 Diverted

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Diverted</b>			
callingDevice			
calledDevice			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
connectionInfo			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
security			
privateData			

#### A.5.7.8 Established

This event must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Established</b>			
originatingNIDConnection			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
establishConnectionInfo			
security			
privateData			

#### A.5.7.9 Failed

This event must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Failed</b>			
originatingNIDConnection			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
failedConnectionInfo			
security			
privateData			

**A.5.7.10 Held**

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Held</b>			
localConnectionInfo			
correlatorData			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
heldConnectionInfo			
callLinkageData			
security			
privateData			

#### A.5.7.11 Network Capabilities Changed

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Network Capabilities Changed</b>			
localConnectionInfo			
correlatorData			
userData			
networkCapability			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
outboundConnectionInfo			
security			
privateData			

#### A.5.7.12 Network Reached

This event must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Network Reached</b>			
originatingNIDConnection			
localConnectionInfo			
correlatorData			
userData			
networkCapability			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
outboundConnectionInfo			
networkCallingDevice			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
networkCalledDevice			
associatedCallingDevice			
security			
privateData			

#### A.5.7.13 Offered

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Offered</b>			
originatingNIDConnection			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
offeredConnectionInfo			
security			
privateData			

#### A.5.7.14 Originated

This event must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Originated</b>			
originatingDevice			
localConnectionInfo			
correlatorData			
servicesPermitted			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
originatedConnectionInfo			
security			
privateData			

#### A.5.7.15 Queued

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Queued</b>			
numberQueued			
callsInFront			
localConnectionInfo			
correlatorData			
userData			
servicesPermitted			
networkCallingDevice			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
networkCalledDevice			
associatedCallingDevice			
associatedCalledDevice			
mediaCallCharacteristics			
callCharacteristics			
queuedConnectionInfo			
security			
privateData			

#### A.5.7.16 Retrieved

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Retrieved</b>			
localConnectionInfo			
correlatorData			
servicePermitted			
mediaCallCharacteristics			
callCharacteristics			
retrievedConnectionInfo			
callLinkageData			
security			
privateData			

#### A.5.7.17 Service Initiated

This event must be supported if the Basic Telephony profile is supported (A.5.1).

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Service Initiated</b>			
localConnectionInfo			
correlatorData			
servicesPermitted			
mediaCallCharacteristics			
callCharacteristics			
initiatedConnectionInfo			
networkCallingDevice			
networkCalledDevice			
associatedCallingDevice			
security			
privateData			

#### A.5.7.18 Transferred

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Transferred</b>			
secondaryOldCall			
localConnectionInfo			
correlatorData			
userData			
chargingInfo			
servicesPermitted			
mediaCallCharacteristics			



Description: Event, optional parameters	Supported?		Comments
	Yes	No	
callCharacteristics			
security			
privateData			

## A.5.8 Call Associated Feature Services

### A.5.8.1 Associate Data

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Associate Data</b>			
<b>Service Request optional parameters</b>			
accountCode			
authCode			
correlatorData			
callQualifyingData			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

### A.5.8.2 Cancel Telephony Tones

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Cancel Telephony Tones</b>			
<b>Service Request optional parameters</b>			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

#### A.5.8.3 Generate Digits

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Generate Digits</b>			
<b>Service Request optional parameters</b>			
digitMode			
toneDuration			
pulseRate			
pauseDuration			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.8.4 Generate Telephony Tones

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Generate Telephony Tones</b>			
<b>Service Request optional parameters</b>			
toneDuration			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

#### A.5.8.5 Send User Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Send User Information			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.9 Call Associated Feature Events

##### A.5.9.1 Call Information

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Call Information			
callingDevice			
accountInfo			
authorisationCode			
correlatorData			
servicesPermitted			
userData			
callQualifyingData			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
connectionInfo			
security			
privateData			

#### A.5.9.2 Charging

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Charging</b>			
cause			
security			
privateData			

#### A.5.9.3 Digits Generated

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Digits Generated</b>			
digitDurationList			
pauseDurationList			
connectionInfo			
security			
privateData			

#### A.5.9.4 Telephony Tones Generated

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Telephony Tones Generated</b>			
toneGenerated			
toneFrequency			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
toneDuration			
pauseDuration			
connectionInfo			
security			
privateData			

#### A.5.9.5 Service Completion Failure

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Service Completion Failure</b>			
secondaryCall			
otherDevicesPrimaryCallList			
otherDevicesSecondaryCallList			
mediaCallCharacteristics			
security			
privateData			

### A.5.10 Media Attachment Services

#### A.5.10.1 Attach Media Service

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Attach Media Service</b>			
<b>Service Request optional parameters</b>			
mediaServiceVersion			
mediaServiceInstanceID			
requestedConnectionState			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
mediaConnection			
mediaDevice			
mediaServiceInstanceID			
mediaConnectionInfo			
security			
privateData			

#### A.5.10.2 Detach Media Service

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Detach Media Service</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

### A.5.11 Media Attachment Events

#### A.5.11.1 Media Attached

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Media Attached</b>			
mediaServiceVersion			
mediaServiceInstanceID			
mediaStreamID			
mediaCallCharacteristics			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
callCharacteristics			
localConnectionInfo			
mediaConnectionInfo			
security			
privateData			

#### A.5.11.2 Media Detached

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Media Detached</b>			
mediaServiceVersion			
mediaServiceInstanceID			
mediaStreamID			
mediaCallCharacteristics			
callCharacteristics			
localConnectionInfo			
mediaConnectionInfo			
security			
privateData			

### A.5.12 Routeing Services

#### A.5.12.1 Route Register

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Route Register</b>			
<b>Service Request optional parameters</b>			
routeingDevice			
requestedRouteingMediaClass			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
actualRouteingMediaClass			
security			
privateData			

#### A.5.12.2 Route Register Abort

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Route Register Abort			
Service Request optional parameters			
security			
privateData			

#### A.5.12.3 Route Register Cancel

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Route Register Cancel			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			



#### A.5.12.4 Re-Route

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Re-Route</b>			
<b>Service Request optional parameters</b>			
routeRegisterReqID			
replyTimeout			
correlatorData			
security			
privateData			

#### A.5.12.5 Route End

This service must be supported if the Routeing Profile is supported (A.5.1).

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Route End</b>			
<b>Service Request optional parameters</b>			
routeRegisterReqID			
errorValue			
correlatorData			
security			
privateData			

#### A.5.12.6 Route Reject

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Route Reject</b>			
<b>Service Request optional parameters</b>			
routeRegisterReqID			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
rejectCause			
correlatorData			
security			
privateData			

#### A.5.12.7 Route Request

This service must be supported if the Routeing Profile is supported (A.5.1).

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Route Request</b>			
<b>Service Request optional parameters</b>			
routeRegisterReqID			
callingDevice			
routeingDevice			
routedCall			
routeSelAlgorithm			
associatedCallingDevice			
associatedCalledDevice			
priority			
replyTimeout			
correlatorData			
mediaCallCharacteristics			
callCharacteristics			
routedCallInfo			
security			
privateData			

#### A.5.12.8 Route Select

This service must be supported if the Routeing Profile is supported (A.5.1).

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Route Select</b>			
<b>Service Request optional parameters</b>			
routeRegisterReqID			
alternateRoutes			
remainRetries			
routeUsedReq			
correlatorData			
security			
privateData			

#### A.5.12.9 Route Used

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Route Used</b>			
<b>Service Request optional parameters</b>			
routeRegisterReqID			
callingDevice			
domain			
correlatorData			
security			
privateData			

### A.5.13 Physical Device Services

#### A.5.13.1 Button Press

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Button Press</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.13.2 Get Auditory Apparatus Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Auditory Apparatus Information</b>			
<b>Service Request optional parameters</b>			
auditoryApparatus			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.13.3 Get Button Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Button Information</b>			
<b>Service Request optional parameters</b>			
button			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.13.4 Get Display

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Display</b>			
Service Request optional parameters			
displayID			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.13.5 Get HookSwitch Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get HookSwitch Status</b>			
Service Request optional parameters			
hookswitch			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

#### A.5.13.6 Get Lamp Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Lamp Information</b>			
<b>Service Request optional parameters</b>			
lamp			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.13.7 Get Lamp Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Lamp Mode</b>			
<b>Service Request optional parameters</b>			
lamp			
security			
privateData			
<b>Service Response optional parameters</b>			
lamp			
security			
privateData			

#### A.5.13.8 Get Message Waiting Indicator

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Message Waiting Indicator			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
deviceForMessage			
lampIsPresent			
security			
privateData			

#### A.5.13.9 Get Microphone Gain

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Microphone Gain</b>			
<b>Service Request optional parameters</b>			
auditoryApparatus			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.13.10 Get Microphone Mute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Microphone Mute</b>			
<b>Service Request optional parameters</b>			
auditoryApparatus			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.13.11 Get Ringer Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Ringer Status</b>			
<b>Service Request optional parameters</b>			
ringer			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.13.12 Get Speaker Mute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Speaker Mute</b>			
<b>Service Request optional parameters</b>			
auditoryApparatus			



Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.13.13 Get Speaker Volume

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Speaker Volume</b>			
Service Request optional parameters			
auditoryApparatus			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.13.14 Set Button Information

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Button Information</b>			
Service Request optional parameters			
buttonLabel			
buttonAssociatedNumber			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

#### A.5.13.15 Set Display

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Display</b>			
<b>Service Request optional parameters</b>			
displayID			
physicalBaseRowNumber			
physicalBaseColumnNumber			
offset			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.13.16 Set HookSwitch Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set HookSwitch Status</b>			
<b>Service Request optional parameters</b>			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

#### A.5.13.17 Set Lamp Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Lamp Mode</b>			
<b>Service Request optional parameters</b>			
lampBrightness			
lampColor			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.13.18 Set Message Waiting Indicator

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Message Waiting Indicator</b>			
<b>Service Request optional parameters</b>			
deviceForMessage			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.13.19 Set Microphone Gain

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Microphone Gain</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.13.20 Set Microphone Mute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Microphone Mute</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.13.21 Set Ringer Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Ringer Status</b>			
<b>Service Request optional parameters</b>			
ringMode			
ringPattern			
ringVolume			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.13.22 Set Speaker Mute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Speaker Mute			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.13.23 Set Speaker Volume

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Set Speaker Volume			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

## A.5.14 Physical Device Events

### A.5.14.1 Button Information

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Button Information</b>			
buttonLabel			
buttonAssociatedNumber			
buttonPressIndicator			
security			
privateData			

### A.5.14.2 Button Press

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Button Press</b>			
buttonLabel			
buttonAssociatedNumber			
security			
privateData			

### A.5.14.3 Display Updated

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Display Updated</b>			
displayID			
physicalRows			
physicalColumns			
physicalBaseRowNumber			
physicalBaseColumnNumber			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
characterSet			
security			
privateData			

#### A.5.14.4 Hookswitch

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Hookswitch</b>			
security			
privateData			

#### A.5.14.5 Lamp Mode

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Lamp Mode</b>			
lampLabel			
lampBrightness			
lampColor			
security			
privateData			

#### A.5.14.6 Message Waiting

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Message Waiting</b>			
deviceForMessage			
security			
privateData			

#### A.5.14.7 Microphone Gain

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Microphone Gain</b>			
security			
privateData			

#### A.5.14.8 Microphone Mute

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Microphone Mute</b>			
security			
privateData			

#### A.5.14.9 Ringer Status

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Ringer Status</b>			
ringMode			
ringCount			
ringPattern			
ringVolume			
security			
privateData			



#### A.5.14.10 Speaker Mute

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Speaker Mute</b>			
security			
privateData			

#### A.5.14.11 Speaker Volume

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Speaker Volume</b>			
timeStamp			
security			
privateData			

### A.5.15 Logical Device Services

#### A.5.15.1 Call Back Non-Call-Related

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Call Back Non-Call-Related</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.15.2 Call Back Message Non-Call-Related

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Call Back Message Non-Call-Related</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.15.3 Cancel Call Back

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Cancel Call Back</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.15.4 Cancel Call Back Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Cancel Call Back Message</b>			
<b>Service Request optional parameters</b>			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

#### A.5.15.5 Get Agent State

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Agent State			
Service Request optional parameters			
acdGroup			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.15.6 Get Auto Answer

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Auto Answer			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
numberOfRings			
security			
privateData			

#### A.5.15.7 Get Auto Work Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Auto Work Mode			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
autoWorkInterval			
security			
privateData			

#### A.5.15.8 Get Caller ID Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Caller ID Status			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.15.9 Get Do Not Disturb

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Get Do Not Disturb			
Service Request optional parameters			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
callOrigination			
callingDeviceList			
security			
privateData			

#### A.5.15.10 Get Forwarding

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Forwarding</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.15.11 Get Last Number Dialed

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Last Number Dialed</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.15.12 Get Routeing Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Get Routeing Mode</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.15.13 Set Agent State

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Agent State</b>			
<b>Service Request optional parameters</b>			
agentID			
password			
group			
security			
privateData			
<b>Service Response optional parameters</b>			
pendingAgentState			
security			
privateData			

#### A.5.15.14 Set Auto Answer

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Auto Answer</b>			
<b>Service Request optional parameters</b>			
numberOfRings			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.15.15 Set Auto Work Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Auto Work Mode</b>			
<b>Service Request optional parameters</b>			
autoWorkInterval			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.15.16 Set Caller ID Status

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Caller ID Status</b>			
<b>Service Request optional parameters</b>			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.15.17 Set Do Not Disturb

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Do Not Disturb</b>			
<b>Service Request optional parameters</b>			
callOrigination			
callingDeviceList			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.15.18 Set Forwarding

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Forwarding</b>			
<b>Service Request optional parameters</b>			
forwardingType			
forwardDN			
ringCount			
security			
privateData			



Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

#### A.5.15.19 Set Routeing Mode

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Routeing Mode</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

### A.5.16 Logical Device Events

#### A.5.16.1 Agent Busy

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Agent Busy</b>			
agentID			
acdGroup			
pendingAgentState			
cause			
security			
privateData			

#### A.5.16.2 Agent Logged Off

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Agent Logged Off			
agentID			
acdGroup			
agentPassword			
cause			
security			
privateData			

#### A.5.16.3 Agent Logged On

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Agent Logged On			
agentID			
acdGroup			
agentPassword			
cause			
security			
privateData			

#### A.5.16.4 Agent Not Ready

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Agent Not Ready			
agentID			
acdGroup			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
cause			
security			
privateData			

**A.5.16.5 Agent Ready**

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Agent Ready</b>			
agentID			
acdGroup			
cause			
security			
privateData			

**A.5.16.6 Agent Working After Call**

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Agent Working After Call</b>			
agentID			
acdGroup			
pendingAgentState			
cause			
security			
privateData			

**A.5.16.7 Auto Answer**

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Auto Answer</b>			
numberOfRings			
security			
privateData			

**A.5.16.8 Auto Work Mode**

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Auto Work Mode</b>			
security			
privateData			

**A.5.16.9 Call Back**

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Call Back</b>			
security			
privateData			

**A.5.16.10 Call Back Message**

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Call Back Message</b>			
security			
privateData			

#### A.5.16.11 Caller ID Status

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Caller ID Status</b>			
security			
privateData			

#### A.5.16.12 Do Not Disturb

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Do Not Disturb</b>			
callOrigination			
callingDeviceList			
security			
privateData			

#### A.5.16.13 Forwarding

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Forwarding</b>			
forwardingType			
forwardTo			
forwardDefault			
ringCount			
security			
privateData			

#### A.5.16.14 Routeing Mode

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Routeing Mode</b>			
security			
privateData			

### A.5.17 Device Maintenance Events

#### A.5.17.1 Back In Service

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Back In Service</b>			
cause			
security			
privateData			

#### A.5.17.2 Device Capabilities Changed

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Device Capabilities Changed</b>			
cause			
security			
privateData			

### A.5.17.3 Out of Service

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Out of Service</b>			
cause			
security			
privateData			

## A.5.18 I/O Services

### A.5.18.1 I/O Register

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>I/O Register</b>			
<b>Service Request optional parameters</b>			
ioDevice			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

### A.5.18.2 I/O Register Abort

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>I/O Register Abort</b>			
<b>Service Request optional parameters</b>			
security			
privateData			

#### A.5.18.3 I/O Register Cancel

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
I/O Register Cancel			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.18.4 Data Path Resumed

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Data Path Resumed			
Service Request optional parameters			
ioRegisterReqID			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.18.5 Data Path Suspended

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Data Path Suspended			
Service Request optional parameters			
ioRegisterReqID			
security			



Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.18.6 Fast Data

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Fast Data</b>			
<b>Service Request optional parameters</b>			
ioRegisterReqID			
dataPathType			
displayAttributes			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.18.7 Resume Data Path

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Resume Data Path</b>			
<b>Service Request optional parameters</b>			
ioRegisterReqID			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

#### A.5.18.8 Send Broadcast Data

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Send Broadcast Data</b>			
<b>Service Request optional parameters</b>			
dataPathType			
displayAttributes			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.18.9 Send Data

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Send Data</b>			
<b>Service Request optional parameters</b>			
ioRegisterReqID			
displayAttributes			
ioCause			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

#### A.5.18.10 Send Multicast Data

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Send Multicast Data</b>			
<b>Service Request optional parameters</b>			
ioData			
displayAttributes			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.18.11 Start Data Path

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Start Data Path</b>			
<b>Service Request optional parameters</b>			
ioRegisterReqID			
dataPathDirection			
dataPathType			
displayID			
numberOfCharsToCollect			
terminationCharacter			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
timeout			
security			
privateData			
<b>Service Response optional parameters</b>			
numberOfCharsToCollect			
terminationCharacter			
timeout			
security			
privateData			

#### A.5.18.12 Stop Data Path

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Stop Data Path</b>			
<b>Service Request optional parameters</b>			
ioRegisterReqID			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.18.13 Suspend Data Path

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Suspend Data Path</b>			
<b>Service Request optional parameters</b>			
ioRegisterReqID			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
security			
privateData			

## A.5.19 Data Collection Services

### A.5.19.1 Data Collected

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Data Collected</b>			
Service Request optional parameters			
digitsData			
telTonesData			
connectionInfo			
dcollCause			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.19.2 Data Collection Resumed

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Data Collection Resumed</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.19.3 Data Collection Suspended

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Data Collection Suspended</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.19.4 Resume Data Collection

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Resume Data Collection</b>			
<b>Service Request optional parameters</b>			
security			
privateData			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

#### A.5.19.5 Start Data Collection

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Start Data Collection</b>			
<b>Service Request optional parameters</b>			
dataCollType			
digitsReportingCriteria			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.19.6 Stop Data Collection

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Stop Data Collection</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.19.7 Suspend Data Collection

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Suspend Data Collection</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.20 Voice Unit Services

##### A.5.20.1 Concatenate Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Concatenate Message</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

##### A.5.20.2 Delete Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Delete Message</b>			
<b>Service Request optional parameters</b>			
security			
privateData			



Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Service Response optional parameters			
security			
privateData			

#### A.5.20.3 Play Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Play Message</b>			
<b>Service Request optional parameters</b>			
duration			
termination			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.20.4 Query Voice Attribute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Query Voice Attribute</b>			
<b>Service Request optional parameters</b>			
connection			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.20.5 Record Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Record Message</b>			
<b>Service Request optional parameters</b>			
samplingRate			
encodingAlgorithm			
maxDuration			
termination			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.20.6 Reposition

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Reposition</b>			
<b>Service Request optional parameters</b>			
messageToReposition			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.20.7 Resume

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Resume</b>			
<b>Service Request optional parameters</b>			
messageToResume			
duration			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.20.8 Review

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Review</b>			
<b>Service Request optional parameters</b>			
messageToReview			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.20.9 Set Voice Attribute

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Set Voice Attribute</b>			
<b>Service Request optional parameters</b>			
message			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.20.10 Stop

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Stop</b>			
<b>Service Request optional parameters</b>			
messageToBeStopped			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.20.11 Suspend

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Suspend</b>			
<b>Service Request optional parameters</b>			
message			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.20.12 Synthesize Message

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Synthesize Message			
Service Request optional parameters			
control			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.21 Voice Unit Events

##### A.5.21.1 Play

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Play			
length			
currentPosition			
speed			
cause			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
servicesPermitted			
security			
privateData			

**A.5.21.2 Record**

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Record</b>			
length			
currentPosition			
cause			
servicesPermitted			
security			
privateData			

**A.5.21.3 Review**

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Review</b>			
length			
currentPosition			
cause			
servicesPermitted			
security			
privateData			

#### A.5.21.4 Stop

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Stop</b>			
length			
currentPosition			
cause			
servicesPermitted			
security			
privateData			

#### A.5.21.5 Suspend Play

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Suspend Play</b>			
length			
currentPosition			
cause			
servicesPermitted			
security			
privateData			

#### A.5.21.6 Suspend Record

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Suspend Record</b>			
length			
currentPosition			
cause			

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
servicesPermitted			
security			
privateData			

#### A.5.21.7 Voice Attribute Changed

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
<b>Voice Attribute Changed</b>			
playVolume			
recordingGain			
speed			
currentPosition			
cause			
security			
privateData			

### A.5.22 Call Detail Record (CDR) Services

#### A.5.22.1 Call Detail Records Notification

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Call Detail Records Notification</b>			
<b>Service Request optional parameters</b>			
cdrReason			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			



#### A.5.22.2 Call Detail Records Report

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Call Detail Records Report</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.22.3 Send Stored Call Detail Records

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Send Stored Call Detail Records</b>			
<b>Service Request optional parameters</b>			
timePeriod			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.22.4 Start Call Detail Records Transmission

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Start Call Detail Records Transmission</b>			
<b>Service Request optional parameters</b>			
security			

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.22.5 Stop Call Detail Records Transmission

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Stop Call Detail Records Transmission			
Service Request optional parameters			
cdrTermReason			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.23 Vendor Specific Extension Services

##### A.5.23.1 Escape Register

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Escape Register			
Service Request optional parameters			
security			
privateData			
Service Response optional parameters			
security			
privateData			

#### A.5.23.2 Escape Register Abort

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Escape Register Abort</b>			
<b>Service Request optional parameters</b>			
security			
privateData			

#### A.5.23.3 Escape Register Cancel

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Escape Register Cancel</b>			
<b>Service Request optional parameters</b>			
security			
privateData			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.23.4 Escape

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
<b>Escape</b>			
<b>Service Request optional parameters</b>			
escapeRegisterID			
security			
<b>Service Response optional parameters</b>			
security			
privateData			

#### A.5.23.5 Private Data Version Selection

Description: Service, optional parameters	Supported?		Comments
	Yes	No	
Private Data Version Selection			
Service Response optional parameters			
security			
privateData			

#### A.5.24 Vendor Specific Extension Events

##### A.5.24.1 Private Event

Description: Event, optional parameters	Supported?		Comments
	Yes	No	
Private Event			
security			





Free printed copies can be ordered from:

**ECMA**

114 Rue du Rhône

CH-1204 Geneva

Switzerland

Fax: +41 22 849.60.01

Internet: [documents@ecma.ch](mailto:documents@ecma.ch)

Files of this Standard can be freely downloaded from the ECMA web site ([www.ecma.ch](http://www.ecma.ch)). This site gives full information on ECMA, ECMA activities, ECMA Standards and Technical Reports.

**ECMA**  
114 Rue du Rhône  
CH-1204 Geneva  
Switzerland

**See inside cover page for obtaining further soft or hard copies.**